



# MonicoView™ 3.1

Software Guide | January 2020  
LP1085 | Revision D

## **COPYRIGHT**

©2018-2020 Red Lion Controls, Inc. All rights reserved. Monico and MonicoView are trademarks of Monico Monitoring, Inc. All other company and product names are trademarks of their respective owners.

Monico Monitoring, Inc.  
18530 Klein Church Road  
Spring, TX 77379 USA

## **CONTACT INFORMATION:**

Tel: (281) 350-8751

Website: [www.monicoinc.com](http://www.monicoinc.com)

Email: [support@monicoinc.com](mailto:support@monicoinc.com)

# Table of Contents

<b>Preface .....</b>	<b>21</b>
Disclaimer.....	21
Purpose.....	21
Trademark Acknowledgments.....	21
Document History and Related Publications.....	21
<b>Chapter 1 Getting Started.....</b>	<b>23</b>
Supported Devices .....	23
System Requirements .....	23
Installing the Software.....	23
Installing the USB Drivers .....	23
Troubleshooting.....	23
Getting Assistance .....	24
The Next Steps.....	25
<b>Chapter 2 Moving from MonicoView II .....</b>	<b>27</b>
Importing Databases.....	27
Symbol Selection .....	27
Model Conversion.....	27
Converting from Asset Series HMI.....	27
Converting from Other Devices.....	28
Custom Web Sites.....	28
New Features .....	28
Zero Config.....	28
OPC UA Server.....	28
New Primitives.....	28
Symbol Library .....	29
Web Server.....	30
IEC-61131.....	31
<b>Chapter 3 MonicoView 3.1 Basics .....</b>	<b>33</b>
Window Layout.....	33
The Navigation Pane .....	33
The Resource Pane.....	33
The Editing Pane.....	33
Collapsing Panes .....	33
The Categories .....	34
Communications.....	34
Data Tags.....	34
Display Pages.....	34
Programs.....	34
Web Server.....	34

Data Logger.....	35
Security .....	35
SQL Queries .....	35
Control.....	35
I/O Modules .....	35
Getting Around.....	36
Back and Forward .....	36
Category Shortcuts.....	36
Item Shortcuts .....	36
Navigation Lists .....	36
Working with Folders.....	37
Sorting Lists and Folders.....	37
Drag and Drop Operations .....	37
Searching in Lists.....	38
Private Items .....	38
Undo and Redo.....	38
Global Searching.....	38
Working with Databases .....	39
Importing from MonicoView .....	39
Importing from MonicoView II .....	39
Database Identifiers .....	40
Saving an Image.....	40
Database Protection.....	41
Converting a Database.....	41
Finding Database Errors.....	42
Downloading to a Device.....	42
Configuring the Link.....	42
Sending the Database.....	43
Extracting Databases .....	43
Sending the Time and Date .....	44
The Memory Card.....	44
Mounting the Card.....	44
Formating the Card.....	45
Remote Monitoring.....	45
System Menu.....	45
<b>Chapter 4 Using Communications.....</b>	<b>47</b>
Network Configuration.....	47
Zero Config.....	47
Ethernet Settings .....	48
Port Settings.....	48
DNS Settings.....	49



Physical Layer.....	49
Maximum Segment Size.....	49
Multiple Ports.....	49
TLS-SSL Settings.....	49
Settings.....	50
Trusted Roots.....	50
Routing Settings.....	50
Routing Mode.....	50
Routing Table .....	50
Download Settings .....	50
Remote Update.....	51
Unit Addressing .....	51
Adding Ports.....	51
Protocol Selection.....	52
Using Virtual Ports.....	52
Serial Port Selection .....	52
Selecting a Protocol.....	53
Protocol Options.....	53
Working with Devices.....	53
Advanced Settings .....	54
Creating Tags.....	54
Port and Device Usage.....	55
Using Expansion Modules.....	55
Slave Protocols .....	56
Selecting the Protocol.....	56
Adding Gateway Blocks.....	56
Adding Items to a Block.....	57
Accessing Individual Bits.....	58
Protocol Conversion .....	58
Master and Slave.....	58
Master and Master .....	59
Which Way Around? .....	59
Controlling Master Blocks.....	59
Data Transformation.....	60
Disabling Communications .....	60
<b>Chapter 5 Working with Tags.....</b>	<b>61</b>
All About Tags .....	61
Data Sources .....	61
Types of Tags .....	61
Tag Key.....	62
Tag Attributes .....	62

Advantages of Tags .....	63
Editing Properties.....	63
Expression Properties.....	63
Selecting a Tag.....	64
Creating a Tag.....	64
Comms References.....	65
Editing an Expression.....	65
Complex Expressions .....	65
Translatable Strings.....	66
Two-Way Properties.....	66
Action Properties.....	67
Color Properties.....	67
Log Properties .....	68
Creating Tags.....	68
Duplicating Tags .....	68
Editing Multiple Tags.....	68
Using Copy From .....	68
Using Paste Special.....	69
Property Selections .....	69
Importing and Exporting.....	70
Finding Tag Usage.....	70
Numeric Tags.....	70
Data Properties.....	70
Data Source.....	71
Data Scaling.....	72
Data Simulation .....	72
Data Actions.....	72
Data Setpoint.....	72
Format Properties.....	73
Data Labels .....	73
Format Type.....	73
Data Limits .....	73
Color Properties.....	74
Color Type.....	74
Alarm Properties .....	74
For Each Alarm.....	74
Trigger Properties .....	76
For Each Trigger.....	76
Plot Properties .....	76
Security Properties .....	77
Flag Tags.....	77

Data Properties.....	77
Data Source.....	78
Data Simulation .....	79
Data Actions .....	79
Data Setpoint.....	79
Format Properties.....	79
Data Labels .....	80
Format Type .....	80
Color Properties.....	80
Color Type.....	80
Alarm Properties .....	80
For Each Alarm.....	81
Trigger Properties .....	82
For Each Trigger.....	82
Security Properties .....	82
String Tags .....	82
Data Properties.....	83
Data Source.....	83
Data Simulation .....	84
Data Actions .....	84
Format Properties.....	84
Data Labels .....	84
Format Type .....	85
Color Properties.....	85
Color Type.....	85
Security Properties .....	85
Basic Tags.....	85
Data Value.....	86
Data Simulation .....	86
Data Labels .....	86
Advanced Topics.....	86
Array Properties .....	86
Tag Data Flow .....	86
Numeric Tag Read Process.....	86
Numeric Tag Write Process.....	87
Using On Write.....	87
<b>Chapter 6 Using Formats.....</b>	<b>89</b>
Format Types .....	89
General Format.....	90
Linked Format.....	90
Numeric Format.....	90

Fixed Data Format.....	90
Dynamic Data Format.....	91
Format Units.....	91
Scientific Format.....	91
Fixed Data Format.....	91
Dynamic Data Format.....	91
Format Units.....	91
Time and Date Format.....	92
Format Mode.....	92
Time Format.....	92
Data Format.....	92
IP Address Format.....	93
Two-State Format.....	93
The Multi-State Format.....	93
Format Control.....	93
Format States.....	94
Format Commands.....	94
The String Format.....	94
<b>Chapter 7 Using Colors.....</b>	<b>95</b>
Types of Coloring.....	95
General Coloring.....	95
Linked Coloring.....	95
Fixed Coloring.....	96
Two-State Coloring.....	96
Multi-State Coloring.....	96
Format Control.....	96
Format States.....	96
Color Commands.....	96
<b>Chapter 8 Creating Display Pages.....</b>	<b>97</b>
Editor Basics.....	97
Working with Pages.....	97
Changing the Zoom Level.....	97
The Resource Pane.....	98
Primitives.....	98
Symbol Library.....	98
Data Tags.....	99
Adding Items to a Page.....	99
Using the Scratchpad.....	99
Working with Primitives.....	100
Selecting the Primitives.....	100
Buried Primitives.....	101

Using the Quick Bar .....	101
Moving Primitives Between Pages .....	101
Moving Primitives Between Databases.....	101
Changing the Size of Primitives.....	101
Rotating and Reflecting Primitives.....	102
Using Layout Handles .....	102
Smart Alignment .....	102
Quick Alignment .....	103
Using the Grid.....	103
Aligning Primitives .....	103
Spacing Primitives.....	104
Reordering Primitives .....	104
Duplicating Primitives.....	105
Editing Multiple Primitives.....	105
Using Copy From .....	105
Using Paste Special.....	105
Property Selections .....	105
Jumping to Other Items .....	106
Primitive Properties.....	106
Showing or Hiding Primitives.....	106
Defining Primitive Colors.....	107
Defining Flashing Colors.....	108
Defining 2-State Colors.....	108
Defining 4-State Colors.....	109
Defining Blended Colors.....	109
Defining Tank Fills.....	110
Defining Fill Formats .....	110
Defining Edge Formats.....	111
Defining Edge Trim .....	112
Legacy Edge Formats.....	112
Recoloring Symbols .....	112
Using Groups .....	113
Making and Breaking Groups.....	113
Editing Within Groups .....	113
Nested Group Editing.....	114
Expanding Groups.....	114
Adding Movement to Primitives.....	114
Adding Text to Primitives .....	115
Text Properties .....	116
More Properties.....	117
Adding Data to Primitives .....	117

Data Properties.....	117
More Properties.....	118
Entry Properties.....	119
Format Properties.....	120
Color Properties.....	120
Adding Actions to Primitives .....	121
Protecting Actions.....	121
Enabling Actions.....	121
The Goto Page Action.....	121
The User Defined Action.....	122
The Push Button Action.....	123
The Change Value Action.....	123
The Ramp Value Action.....	124
The Play Tune Action.....	125
The Log On User Action .....	125
The Log Off User Action.....	125
The Hide Popup Action .....	125
The Hide All Popups Action.....	125
Adding Actions to Icons .....	126
Editing Page Properties .....	126
General Properties.....	126
More Properties.....	127
Action Properties.....	128
Security Properties .....	128
User Interface Settings.....	128
Global Properties.....	128
Global Actions.....	129
Global Timeouts.....	129
Popup Position.....	129
Diagnostics.....	129
Languages .....	129
Entry Properties.....	130
Keypad Options.....	130
Data Entry Mode.....	130
Miscellaneous.....	130
Images Properties.....	131
Images.....	131
Maintenance .....	131
Fonts Properties.....	131
Maintenance .....	132
Icons Properties.....	132

Managing Images .....	132
Managing Fonts.....	133
Advanced Topics.....	134
Defining Color Expressions.....	134
Building Colors .....	135
Splitting Colors.....	135
Choosing Colors .....	135
Blending Colors.....	135
Responding to Touch.....	135
<b>Chapter 9 Primitive Types .....</b>	<b>137</b>
Core Primitives.....	137
Geometric Primitives.....	137
Basic Properties.....	137
Other Properties.....	137
The Line Primitive.....	137
Line Properties.....	138
Edge Properties .....	138
Text and Data Primitives.....	138
The Image Primitive.....	138
Defining Images.....	139
Adjusting Images.....	140
The Bevel Primitive.....	140
Figure Properties.....	140
Line Properties.....	141
The Button Primitives.....	141
Gauge Primitives.....	142
Gauge Concepts.....	142
Types .....	142
Bugs.....	142
Bands.....	142
Styles.....	143
Naked Gauges .....	143
Gauge Properties.....	143
Format Properties.....	143
Layout Properties for Radial Gauges .....	144
Layout Properties for Linear Gauges .....	144
Style Properties .....	145
Band Properties.....	145
Bug Properties .....	146
Bar and Line Graphs.....	146
The Bar Graph Primitives .....	146

Option Properties .....	146
Figure Properties.....	147
Scatter Graph Properties.....	147
Line Properties.....	147
Option Properties.....	147
Figure Properties.....	148
Action Buttons .....	148
Illuminated Buttons .....	148
Indicators.....	150
2-State Toggles .....	150
Switch Properties.....	151
Advanced Properties.....	152
3-State Toggles .....	152
Switch Properties.....	153
Advanced Properties.....	153
2-State Selectors .....	154
3-State Selectors .....	154
System Primitives .....	154
Viewer Format .....	154
The Alarm Viewer.....	155
Option Properties.....	155
Actions Properties.....	155
Time Properties .....	156
Color Properties.....	156
The Alarm Ticker.....	156
Options Properties.....	156
The Event Viewer .....	157
Options Properties.....	157
Enables Properties.....	158
Time Properties .....	158
File Viewer.....	158
Options Properties.....	158
User Manager.....	158
Trend Viewer .....	159
Options Properties.....	159
Format Properties.....	160
Buttons Properties.....	160
Time Properties .....	160
Pen Properties.....	160
Fill Properties .....	161
Touch Calibration.....	161



Touch Tester.....	161
PDF Viewer .....	161
Option Properties .....	162
Camera.....	162
Option Properties .....	162
Figure Properties.....	162
Legacy Primitives .....	162
Scale Primitive.....	163
Data Properties.....	163
Figure Properties.....	164
Limit Properties .....	164
Format Properties.....	164
<b>Chapter 10 Localization .....</b>	<b>167</b>
Selecting Languages.....	167
Configuring Auto-Translation .....	168
Translating Your Database .....	168
Entering Translations.....	169
Global Auto-Translation.....	169
Exporting and Importing.....	169
Applying a Lexicon.....	169
Previewing Translations.....	170
Switching Languages.....	170
<b>Chapter 11 Using Widgets.....</b>	<b>171</b>
Creating a Widget.....	171
Summary .....	174
Why This Matters.....	175
Down to Details .....	175
Widget Data Definitions .....	175
Filing Widgets.....	176
Folder Binding .....	177
Advanced Binding.....	178
Class Matching.....	178
Binding Prefixes.....	179
Using Bind To .....	179
Using Periods.....	179
Using Carets.....	179
Special Name .....	179
Details Widgets.....	179
Enabling Details Creation.....	180
Defining Data Items.....	180
Results of Binding.....	180

Multiple Details Pages .....	181
<b>Chapter 12 Using the Data Logger.....</b>	<b>183</b>
Creating Data Logs.....	183
Setup Properties.....	183
Contents Properties.....	184
Monitor Properties.....	184
Batch Logging.....	184
Controlling a Batch.....	185
Digital Signatures .....	185
Log File Storage .....	185
The Logging Process.....	186
Accessing Log Files .....	186
<b>Chapter 13 Using the Web Server.....</b>	<b>189</b>
Switching Versions.....	189
Web Server Properties.....	189
Control Properties.....	189
Feature Properties.....	191
Security Properties .....	193
Advanced Properties .....	194
Adding Webpages.....	194
Working with Certificates.....	195
Introduction .....	195
Using Certificates .....	196
Obtain a Commercial Certificate.....	196
Use a Local Certification Authority .....	196
Use a Self-Signed Certificate .....	197
Use the Default Certificate.....	197
Beyond the Subnet .....	198
Don't Bother .....	198
Using a Custom Website .....	198
<b>Chapter 14 Creating Custom Websites.....</b>	<b>199</b>
Naming.....	199
Resources.....	199
Server Commands.....	200
Server Include.....	200
Cache Control .....	200
Embedded Data.....	200
Tag Data.....	201
Global Data.....	201
Data Index Data .....	201
Data View Data .....	201

AJAX Updates.....	202
Reading Tags.....	202
Writing Tags.....	202
Site Deployment.....	202
<b>Chapter 15 Using the Security System.....</b>	<b>203</b>
Security Basics.....	203
Object-Based Security.....	203
Named Users.....	203
User Rights.....	203
Access Control.....	204
Write Logging.....	204
Default Access .....	204
On-Demand Logon .....	204
Maintenance Access.....	205
Check Before Operate.....	205
Security Settings.....	205
Creating Users.....	206
Specifying Tag Security.....	206
Specifying Page Security.....	207
Security Related Functions.....	207
<b>Chapter 16 Using SQL Queries.....</b>	<b>209</b>
Configuring the Server .....	209
Creating Queries.....	209
Filtering the Results .....	210
Checking the SQL Code.....	211
Creating Columns .....	211
Mapping Tags.....	212
<b>Chapter 17 Using IEC-61131.....</b>	<b>213</b>
Why Use Control?.....	213
Learning IEC-61131.....	213
Working with Programs.....	213
Types of Program.....	213
Creating Programs.....	214
Editing Programs.....	214
The Structured Text Editor.....	214
The Function Block Diagram Editor .....	215
The Ladder Diagram Editor .....	215
The Instruction List Editor.....	216
Converting Programs .....	216
Program Properties .....	216
Using Variables .....	217

Creating Variables .....	217
Variable Properties .....	217
Parameters .....	218
Project Properties.....	219
Project Rebuilding .....	220
IEC-61131 Debugging.....	220
<b>Chapter 18 Using Connectors .....</b>	<b>223</b>
Configuring Connectors .....	223
Common Settings.....	223
Network Options .....	223
Device Data Options .....	225
Tag Data Options.....	226
Triggered Mode.....	228
Connector Diagnostics.....	228
Data Buffering.....	228
JSON Data Layout.....	229
Connector Options .....	229
Connection Status.....	230
Device Data.....	230
Tag Data.....	230
Site Naming.....	234
The Generic MQTT Connector .....	234
Connector Settings .....	234
Connector Operation .....	236
The Amazon MQTT Connector.....	236
Connector Settings .....	236
Connector Operation .....	238
The Azure MQTT Connector.....	238
Connector Settings .....	238
Connector Operation .....	239
The Google MQTT Connector .....	240
Connector Settings .....	240
Connector Operation .....	241
The Sparkplug MQTT Connector.....	241
Connector Settings .....	242
Connector Operation .....	243
<b>Chapter 19 Using Services .....</b>	<b>245</b>
Using the OPC UA Server.....	245
Configuring the Service.....	245
Service Properties .....	245
Data Properties.....	246

Data Presentation.....	246
Historic Data.....	247
Using Time Management.....	247
Configuring the Service.....	247
Time Server.....	248
Time Client.....	248
Time Stamps.....	249
Choosing an SNTP Server.....	249
Time-Zone Configuration.....	249
Using the FTP Server.....	250
Configuring the Service.....	250
FTP Security.....	251
Using the OPCWorx Proxy.....	251
Configuring the Service.....	251
Using File Synchronization.....	251
Configuring the Service.....	252
FTP Client.....	252
Log Synchronization.....	253
Using Electronic Mail.....	253
Adding Contacts.....	254
Configuring SMTP.....	254
Configuring SMS.....	256
Using SQL Sync.....	256
Configuring the Service.....	256
<b>Chapter 20 Sharing Ports.....</b>	<b>259</b>
Enabling TCP/IP.....	259
Sharing the Required Ports.....	259
Connecting via Another Port.....	260
Connecting via Ethernet.....	260
Pure Virtual Ports.....	261
Limitations.....	262
<b>Chapter 21 Using Modems.....</b>	<b>263</b>
Adding a Dial-In Connection.....	263
Adding a Dial-Out Connection.....	265
Adding an SMS Connection.....	266
SMS Message Processing.....	266
Modem Expansion Cards.....	266
Checking the Modem Status.....	267
Using Multiple Interfaces.....	268
Interface Selection.....	268
Default Route.....	269

<b>Chapter 22 Using the USB Host .....</b>	<b>271</b>
Memory Stick Support .....	271
General Properties .....	271
Transfer Properties .....	272
Keyboard Support .....	272
Mouse Support .....	272
<b>Chapter 23 Using Programs .....</b>	<b>273</b>
The Program List .....	273
Finding Program Usage .....	273
Editing Programs .....	273
Getting Help .....	274
The Resource Pane .....	274
Program Data Types .....	274
Global Settings .....	275
Program Properties .....	276
Adding Comments .....	277
Returning Values .....	277
Avoiding Pitfalls .....	277
Passing Arguments .....	278
Programming Tips .....	278
Multiple Actions .....	278
If Statements .....	278
Switch Statements .....	279
Local Variables .....	280
Loop Constructs .....	280
The While Loop .....	280
The For Loop .....	281
The Do Loop .....	281
Loop Control .....	281
<b>Chapter 24 Writing Expressions .....</b>	<b>283</b>
Data Values .....	283
Constants .....	283
Integer Constants .....	283
Character Constants .....	283
Logical Constants .....	284
Floating-Point Constants .....	284
String Constants .....	284
Tag Values .....	284
Tag Properties .....	284
Page Properties .....	285
Comms References .....	285

Simple Math.....	285
Operator Priority.....	286
Type Conversion .....	286
Comparing Values .....	286
Testing Bits.....	287
Multiple Conditions.....	287
Choosing Values .....	287
Manipulating Bits .....	288
AND, OR and XOR.....	288
Shift Operators .....	288
Bitwise NOT.....	288
Indexing Arrays.....	289
Indexing Strings.....	289
Adding Strings.....	289
Calling Programs .....	289
Using Functions .....	289
Priority Summary .....	289
<b>Chapter 25 Writing Actions .....</b>	<b>291</b>
Changing Page.....	291
Changing Numeric Values.....	291
Simple Assignment.....	291
Compound Assignment.....	291
Increment and Decrement.....	291
Changing Bit Values.....	291
Running Programs .....	292
Using Functions .....	292
<b>Chapter 26 Advanced Debugging .....</b>	<b>293</b>
Accessing a Console .....	293
Viewing Output.....	293
Debugging Programs.....	293
Running Commands.....	294
Tag Commands.....	294
Program Commands .....	294
<b>Chapter 27 Asset I/O Modules.....</b>	<b>295</b>
Selecting Modules.....	295
The GMTC and GMRTD Temperature Modules .....	296
Configuration Properties.....	296
General.....	296
Inputs.....	296
Millivolt Properties (GMTC Only).....	296
General.....	297

Millivolt Scaling .....	297
Available Data .....	297
Input/Status.....	297
Input/Control.....	297
Input/ScaleMvInputs.....	297
The GMINI And GMINV Analog Input Modules .....	297
Configuration Properties .....	298
General.....	298
Inputs.....	298
Available Data .....	298
Input/Status.....	298
Input/Control.....	298
The GMOUT Analog Output Module.....	299
Configuration Properties.....	299
Output 1 to Output 4.....	299
Initial Output Properties.....	299
Initialization.....	299
Output Action .....	300
Available Data .....	300
Data.....	300
Scaling .....	300
Alarms .....	301
The GMDIO Digital I/O Module.....	301
Configuration Properties.....	301
Available Data .....	301
Variables/Inputs .....	301
Variables/Outputs.....	301
The GMUIN Universal Input Module.....	301
Input Properties.....	302
Operation.....	302
Units.....	302
Available Data .....	302
Input/Status.....	302
Input/Control.....	303



# Preface

## Disclaimer

This software guide provides guidance on how to use MonicoView™ 3.1 to develop powerful and attractive MonicoView 3.1 device solutions for supported Monico devices. It is not intended as a step-by-step guide or a complete set of all procedures necessary and sufficient to complete all operations.

While every effort has been made to ensure that this document is complete and accurate at the time of release, the information that it contains is subject to change. Monico Monitoring, Inc. is not responsible for any additions to or alterations of the original document. Industrial networks vary widely in their configurations, topologies, and traffic conditions. This document is intended as a general guide only. It has not been tested for all possible applications, and it may not be complete or accurate for some situations.

Users of this document are urged to heed warnings and cautions used throughout the document.

## Purpose

This guide is intended to be used by personnel responsible for configuring and commissioning MonicoView 3.1 devices for use in visualization, monitoring, and control applications.

## Trademark Acknowledgments

Monico acknowledges and recognizes ownership of the following trademarked terms used in this document.

- Microsoft®, Windows®, Windows NT® and Windows Vista™ are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

All other company and product names are trademarks of their respective owners.

## Document History and Related Publications

The hard copy and electronic media versions of this document are revised only at major releases and therefore, may not always contain the latest product information. Documentation Notes and/or Product Bulletins will be provided as needed between major releases to describe any new information or document changes.

The latest online version of this document can be accessed through the Monico website at <https://www.monicoinc.com/support/product-support>.



# Chapter 1 Getting Started

Welcome to MonicoView 3.1, Monico's configuration software. This guide describes how to use MonicoView 3.1 to design powerful and attractive MonicoView 3.1 device solutions.

## Supported Devices

MonicoView 3.1 supports only those Monico products that have the memory capacity and processor performance necessary to implement the additional features that the software provides. The Asset Series can be configured with MonicoView 3.1. The currently available versions of the Data Station Plus and the Modular Controller are likewise not supported by the MonicoView 3.1 software. You may need to use MonicoView II™ to configure other devices.

## System Requirements

MonicoView 3.1 is designed to run on any version of Microsoft Windows from Windows 7 onwards. Memory requirements are modest and any system that meets the minimum system requirements for its operating system will be able to run MonicoView 3.1. About 600 MB of free disk space will be needed for installation, and you should ideally have a display with sufficient resolution to allow the editing of display pages without having to scroll.

## Installing the Software


The installation process is standard and ought to proceed without much interaction beyond your specifying the target directory. Once the process complete, look at your Start Menu and find the Monico folder. Click the MonicoView 3.1 icon to start the software.

## Installing the USB Drivers

If you've followed the instructions that came with your target hardware, you will not yet have connected the hardware to your PC. Now that you have completed the MonicoView 3.1 installation, you may safely connect the device using a standard USB cable. After some churning, Windows should indicate that it has found the drivers for the new hardware and that it is ready for operation. No further user intervention should be required.

## Troubleshooting

If you connect the target device to your PC before installing MonicoView 3.1, it is possible that an aborted installation has made it impossible for you to install the drivers correctly. To check for this, open the Windows Device Manager by finding the My Computer icon, right-clicking and selecting the Manage command. A window like the one below should appear:




The exact process for getting to this point will vary from one operating system to another, but the basic idea is the same: Find the My Computer icon, either on the desktop or on your start menu, right-click it and select Manage. If that doesn't work, select the System option from the Control Panel, and activate the Device Manager from the Hardware tab.

If you have a problem with your USB drivers, you will see a yellow icon carrying an exclamation point under the Universal Serial Bus controllers category. The name of the icon may be HMI or Loader or something similar. The broken driver is shown in close-up below:



To fix the problem, right-click on the broken device and select Uninstall from the menu:



After asking for confirmation, Windows will remove the device from your system. You can now power the MonicoView 3.1 target device off. After a couple of seconds, reapply power and Windows will start the driver installation process once again.


As mentioned above, MonicoView 3.1 actually uses distinct device drivers for the boot loader and for the MonicoView 3.1 runtime. You may have to repeat this repair process for each driver, although it is unlikely that things got beyond the boot loader if that install failed.

## Getting Assistance

If you hit a problem, or need assistance, several resources are available.

### Balloon Help

MonicoView 3.1 contains a very useful feature called Balloon Help:



This feature allows you to see help information for each item within MonicoView 3.1. It is controlled via the icon at the right-hand edge of the toolbar or via options on the Help menu. The default mode allows the help text to be displayed by pressing the F1 key, providing a quick way of getting information if you are unsure of the settings for a given field. Keep this in mind, and your life will be a lot easier!

### Technical Support

Keeping your Monico products fully functional is a top priority for us. If you need technical support, we can be contacted as follows:

- Technical assistance is available on the web at: [www.monicoinc.com](http://www.monicoinc.com). Navigate to Support, Technical Support, Request Technical Support Form and complete the form. One of our Technical Support specialists will contact you in a timely manner.
- Tech Support can be contacted via email at: [support@monicoinc.com](mailto:support@monicoinc.com).
- Tech Support can also be reached by calling (281) 350-8751.

## The Next Steps

If you are migrating from MonicoView II, we recommend that you give the next chapter a cursory reading to learn about the new user interface. We also suggest that you look at the chapters on tags and display page configuration, as some of the concepts used by MonicoView II have been simplified, and many things can be achieved through easier methods. If you are completely new to MonicoView 3.1, please read at least as far as the chapter on Widgets.



## Chapter 2 Moving from MonicoView II


This chapter provides a quick guide on how to migrate your database from MonicoView II to MonicoView 3.1, and lists some of the new features that you are likely to want to use. It also explains some of the differences between the hardware supported by the two versions and how these will impact database import. If you are a new user, you may skip this chapter and move straight on to the chapter on MonicoView 3.1 Basics.

### Importing Databases

Databases created by MonicoView II can be opened directly by MonicoView 3.1 by changing the file type selection in the bottom right-hand corner of the File Open dialog box. When you come to save the database, MonicoView 3.1 will note that the file must be saved in MonicoView 3.1 format and will ask you where you wish to save it and under what name. The new name will typically be the old one with the `mv2` extension replaced with `mv31`. MonicoView 3.1 databases may also be opened via the File Import command, which essentially performs the same operation but without any need to change the selected file type.

### Symbol Selection

When you import a MonicoView 3.1 database, the symbol library will continue to supply the database with old-style symbols that do not contain the smoother edges and more subtle shading that characterize new-style versions. The images below illustrate the difference, with the tank of the left being obviously the old-style version:



You may switch your database to use new-style symbols by going to the Display Pages category and selecting the Pages item in the root of the navigation list. On the Images tab, edit the *Symbol Library* property to select the preferred symbol set. While most old-style symbols have a new equivalent, it is possible that the rendering will not be precisely the same, with, for example, a symbol being one pixel narrower or wider. If this makes a difference in your database, you may have to decide between manually adjusting each of your pages and continuing to use the old-style symbols.

### Model Conversion

MonicoView 3.1 does not support all the models supported by MonicoView II. To offer the features that our customers were demanding, we had to leave behind support for older, less powerful hardware and target only devices with sufficient memory and processing power to handle the demands of more modern software.

### Converting from Asset Series HMI

All Asset Series HMIs, the Asset Gateway Engine and the Asset Converter are supported by MonicoView 3.1, so converting your database is as simple as completing the import process described above.

## Converting from Other Devices

The HMI series, the Data Station Plus, and the Modular Controller do not currently support MonicoView 3.1 and you must therefore continue to use MonicoView II to program these products. Monico Monitoring, Inc. will be releasing updated hardware that will allow you to make the transition to MonicoView 3.1 Please check the Monico website for details.

## Custom Web Sites

If you have developed a custom website in MonicoView II, you may find that it does not operate in precisely the same way when it is transferred to MonicoView 3.1. Consulting the chapter on creating custom websites and considering how the newly-available features can help you harmonize your site with the standard MonicoView 3.1 pages is recommended.

## New Features

MonicoView 3.1 provides many new features and improvements. Lots of changes have been made to increase usability, to decrease the amount of time it takes to create a database, and a number of major features have been added.

### Zero Config

- MonicoView 3.1 supports a zero-configuration network option that allows a device to be connected to your network and referenced by name from your PC without the need to add DNS or HOST file entries. MonicoView 3.1 will also create a webserver SSL certificate using that name, allowing error-free development of secure websites.

### OPC UA Server

- MonicoView 3.1 provides an OPC UA server in mid-range and high-end units. This server exposes selected tags via the OPC UA protocol, allowing suitable clients to browse the tag folder structure, and to read and write tag values. Subscription support allows clients to receive updates only when tags change by the specified deadband value.

### New Primitives

- MonicoView 3.1 provides more attractive primitives with smoother edges:



- Newer primitives can be filled with a greater variety of graduated patterns, including patterns that simulate cylindrical containers or metallic surfaces.



- Newer primitives can be filled with a variety of texture from the Symbol Library, allowing natural or man-made materials to be represented.





- Newer primitives support edges of any thickness, providing a better quality of display on high-resolution devices where one pixel is very small. These edges may be a solid color, but they may also be filled with any of the graduated patterns or textures used to fill the figure itself. A solid line may be applied to the inside or outside of the edge, better delineating it from other display elements.



- MonicoView 3.1 provides a richer line primitive that can be an arbitrary width. The line can be filled and edged just as for other primitives. Lines may thus be filled with graduated fills and textures and may have edges applied to their outline. Lines may also have a variety of end styles applied, allowing arrows to be easily created.



- MonicoView 3.1 provides more flexible rounded, beveled and filleted figures, with the ability to omit the corner effect on any set of corners. This permits greater flexibility in creating custom shapes.



- MonicoView 3.1 supports new primitives for triangles, parallelograms and trapeziums, with proportional handles allowing the figures to be adjusted in a manner that is invariant under scaling. MonicoView 3.1 also provides a new more flexible arrow primitive with several handles to adjust its appearance.



## Symbol Library


- Symbols have smoother edges and more subtle shading.



- Symbols can be recolored dynamically at runtime to represent state information.




- Symbols can be recolored dynamically at runtime using a tank fill, allowing for example the Tank Cutaway symbols to be used with the Tank symbols to create attractive visualizations of tank level information.



## Web Server

- The web server has been completely reworked to provide a more useful appearance based on the Bootstrap and JQuery libraries. The page layouts automatically adjust for use on mobile devices.



- The web server now supports secure HTTPS operation, and allows for the provision of certificates to indicate the server identity. HTTP redirect is also supported, avoiding the need for your clients to type the https prefix.
- The web server now provides form based authentication for secure connections, providing a better log on experience, including redirection to previously selected pages. The web server now supports individual security descriptors for each feature and for each tag-driven page. This allows finer granularity of access control.
- The web server now supports input directly from the keyboard when using the remote-control facility. The user no longer needs to press the buttons on the popup keypad with the mouse. Typing the data enters it into the field.
- The web server now includes an updated remote view and remote control features that operates far more smoothly and sends only a small fraction of the data required by the previous implementation, while increasing color depth from 8 to 16 bits.



- The web server now uses AJAX technology to update tag-driven pages, providing much faster updates without any flicker and with only minimal data usage. The same techniques are made available for in custom webpages.
- The web server now supports reply compression. Together with the last two features, this vastly reduces data requirements. This is especially important cellular operation, both for performance and billing control.
- The web server allows custom stylesheets and JavaScript to be included in every page, allowing modification of the site's appearance and behavior.

## IEC-61131

- The control engine now supports more deterministic execution, ensuring that scan times and I/O updates are not disrupted by page updates and other activity.
- The control editor now supports online debugging, allowing the execution of a program in a remote device to be monitored in real time.
- The control editor support for offline simulation has been improved, allowing navigation between pages without leaving simulation mode.
- The control editor now supports clipboard and drag-and-drop operations, allowing programs and variables to be moved around within MonicoView 3.1, and even between MonicoView 3.1 databases.
- The control editor has been optimized to provide a more fluid navigation experience, and avoiding some of the pauses that could previously be seen.
- The control editor allows initial values to be defined for variables, ensuring that they are correctly initialized upon system start-up.




## Chapter 3 MonicoView 3.1 Basics

To run MonicoView 3.1, select the MonicoView 3.1 icon in the Monico Monitoring, Inc. section of your Start Menu. After a couple of seconds, MonicoView 3.1 will appear.

### Window Layout

The main MonicoView 3.1 window comprises three sections, as shown in the following figure.



### The Navigation Pane

The left-hand portion of the window is called the Navigation Pane. It is used to move between different categories of items within a MonicoView 3.1 configuration file. Each category is represented by a bar at the base of the pane, and clicking on that bar will navigate to that section. The top section of the Navigation Pane shows the available items in the current category, and provides a toolbar to allow those items to be manipulated. If you want to make the top section larger, you can pick up and drag the dividing line between it and the category bars.

### The Resource Pane

The right-hand portion of the window is called the Resource Pane. It is used to access various items that are of use when editing the current category. Just like the Navigation Pane, it contains a number of categories which can be accessed via the category bars. Items in a given resource category can be drag-and-dropped to the places where you wish to use them. For example, a data tag can be picked up from the Resource Pane and dropped on a configuration field to make that field dependent on the value of the selected tag. Many items can also be double-clicked, thereby setting the current field to that item.

### The Editing Pane

The central portion of the window is used to edit the currently selected item. Depending on the selection, it may contain a number of tabs, each showing a given set of the properties for that item, or it may contain an editor specific to the item that you are working on.

### Collapsing Panes

Either or both of the Navigation Pane and Resource Pane can be collapsed to the edge of the main window in order to free-up more space for the Editing Pane. To close a pane, click on the 'x' in the top left-hand corner of its title bar. It will then be replaced by a smaller bar marked with

arrows. Clicking this bar will expand the associated pane. Clicking the pushpin icon of a temporarily expanded pane will lock it in place.

## The Categories

The main categories in a MonicoView 3.1 database are described in this section.

### Communications



This category specifies which protocols are to be used on the target device's serial ports and Ethernet ports. Where master protocols are used (i.e. protocols in which the Monico hardware initiates data transfer to and from a remote device) you can also use this icon to specify one or more devices to be accessed. Where slave protocols are used (i.e. protocols in which the Monico hardware receives and responds to requests from other systems) you can specify which data items are to be exposed for read or write access. You can also use this category to move data between remote devices via the protocol converter, to configure expansion cards and to configure services.

### Data Tags



This category defines the data items that are to be used to access data within the remote devices, or to store information within the target device. Each tag has a variety of properties, including formatting data, which specifies how the data held within a tag is to be shown on the device's display or in other contexts such as webpages. By specifying this information within the tag, MonicoView 3.1 removes the need for you to reenter formatting data each time a tag is displayed. More advanced tag properties include alarms that may activate when various conditions relating to the tag occur, or triggers, which perform programmable actions when those conditions are met.

### Display Pages



This category is used to create and edit display pages. The page editor allows you to display various graphical items known as primitives. These vary from simple items, such as rectangles and lines, to more complex items that can be tied to the value of a particular tag or to an expression. By default, such primitives use the formatting information defined when the tag was created, although this information can be overridden if required. You may also use the editor to specify what actions should be taken when keys or primitives are pressed, released or held down.

### Programs



This category is used to create and edit programs using MonicoView 3.1's unique C-like programming language. These programs can perform complex decision-making or data manipulation operations based upon data items within the system. They serve to extend the functionality of MonicoView 3.1 beyond that of the standard functions included in the software, thereby ensuring that even the most complex applications can be tackled. Programs can call upon a variety of system functions to perform common operations.

### Web Server



This category is used to configure MonicoView 3.1's web server and to create and edit webpages. The web server can provide remote access to the target device via several mechanisms. First, you can use MonicoView 3.1 to create automatic webpages which contain lists of tags, with each formatted per the tag's properties. Second, you can create a custom

site using a third-party HTML editor and then include directives to instruct MonicoView 3.1 to insert live tag values. Finally, you can enable MonicoView 3.1's unique remote access and control feature, which allows a web browser to view the target device's display and control its keyboard. The web server can also be used to access files from the Data Logger.

## Data Logger



This category is used to create and manage data logs, each of which can record any number of variables to the target device's memory card. Data may be recorded as quickly as once per second. The recorded values will be stored in CSV (Comma Separated Variable) files that can easily be imported into applications such as Microsoft Excel. The files can be accessed by swapping-out the memory card, by mounting the card as a drive on a PC connected on the target device's USB port, or by accessing them via MonicoView 3.1's web or FTP servers using an Ethernet port or a modem. Log files can be protected via cryptographic signatures to ensure that they have not been tampered with since they were written to the memory card.

## Security



This category is used to create and manage the various users of the target device, as well as the access rights granted to each. Real names may also be given, which allows the security logger to record not only what data was changed and when, but also by whom. The rights required to modify a particular tag or to access a page are set via the security properties of the individual item. Rights can also be assigned to allow or deny access to the FTP server or the web server.

## SQL Queries



This category is used to create and manage queries written in SQL that will be used to extract data from a Microsoft SQL Server database and transfer it into a set of MonicoView 3.1 tags. Multiple queries can be created, with each column of the returned data being mapped to a set of tags that represent the rows of that data. Queries may be executed periodically or on demand, allowing, for example, production scheduling information to be passed on to a controller responsible for machine operation.

## Control



This category allows the creation and editing of IEC-61131 programs in the various languages defined in that standard. The programs may be called periodically or on demand, and may interface with any MonicoView 3.1 tags or I/O devices to provide control functionality beyond that supported by MonicoView 3.1's own programming language. Full online monitoring is provided, together with offline simulation to allow you to debug the behavior of your programs without the need to connect a remote device.


## I/O Modules



This category is available only when configuring an Asset HMI or another device that supports Asset HMI modules. It allows you to configure the I/O modules that you have directly connected to the device or that you have connected via an expansion or tethered rack. Note that only I/O modules are configured via this category. Modules that are used for comms are configured via the Communications category using a mechanism detailed in the Using Communications chapter.

## Getting Around

The easiest way to get around a MonicoView 3.1 database is to click on the category bars in the Navigation Pane, and then click on the item you want to edit. However, a number of shortcuts exist to allow quicker movement and greater productivity. Most of these shortcuts can be accessed via the Go menu, or via associated key combinations.



### Back and Forward

The first icon on the toolbar or the **ALT+LEFT** key combination can be used to move back to items that you had previously selected. The next icon or the **ALT+RIGHT** key combination can then be used to move forward again, returning to the item you first started with. This facility is very useful when switching between database categories.

### Category Shortcuts

Each category is allocated a shortcut key sequence, comprising the **CTRL** key and a number indicating the category's position in the Navigation Pane. For example, the Communications section can be accessed directly by using the **CTRL+1** combination. You can also move up and down in the category list by using the **ALT+PGUP** and **ALT+PGDOWN** key combinations.


### Item Shortcuts

If you are working in the Editing Pane, you can switch between items by using the **ALT+UP** and **ALT+DOWN** key combinations. MonicoView 3.1 will move to the previous or next item in the item list, and will try to keep the currently-selected data field the same. This is very useful if you want to change the same field on several items, as you do not have to keep navigating back to that field or switching to the Navigation Pane in order to change items.

## Navigation Lists

Several categories in MonicoView 3.1 contain lists of items. For example, selecting the Data Tags category will cause the Navigation Pane to show a list of all the data tags in your database, allowing them to be selected and edited:





Items within these Navigation Lists can be manipulated in various ways:

- To quickly find an item, type the first few letters of its name. MonicoView 3.1 will select the first item that matches the characters you have entered. Typing more characters will make the selection more specific, while pressing **ESC** will allow a new sequence of search characters to be entered.
- To create an item, click on the New button in the Navigation Pane toolbar. For those lists that support only a single type of item, you may also use the **ALT+INS** key combination. The New button on the toolbar may offer a list of available items, allowing you to choose the type of the item you wish to create.
- To delete an item, either use the Delete icon in the Navigation Pane toolbar, or press the **ALT+DEL** key combination. If you delete a folder, all of the items within that folder will be deleted, too. Warnings are provided for multiple deletes, although they can always be reversed via the Undo command.
- To rename an item, select it and press **F2**. You may then enter the new name and press **ENTER**. Alternatively, select the item and then single-click on the name once more to activate editing. Again, press **ENTER** when you are finished.

## Working with Folders

Some lists support the grouping of items into folders. Folders can be created using the New Folder icon in the Navigation Pane toolbar, and can be renamed and deleted just like more conventional items. Creating an item with a folder selected will place that item in the selected folder. Folders can be nested up to any reasonable depth.

## Sorting Lists and Folders

An entire Navigation List or the contents of a folder may be sorted by right-clicking on the root item or the folder as appropriate, and selecting one of the Sort commands. Items may be sorted in ascending or descending alphabetic order. Folders are always placed before other items, no matter which sort order is applied.

## Drag and Drop Operations

Items in Navigation Lists can be drag-and-dropped within the list to change their position or to move them between folders. Holding down the **CTRL** key while dragging will result in a copy of the original item being created. The left-to-right position of an item may sometimes be used to decide where to place an item in the folder hierarchy. If the item is being dropped into the wrong folder, try moving left or right to get to the correct position.

Database items such as tags and display pages may also be dragged between database files by opening two copies of MonicoView 3.1 and dragging the items in question from the source database's Navigation Pane to that of the target database. If the appropriate category in the target

is not already selected, temporarily holding the item that is being dragged over the required category bar for a second or so will select that category, thereby avoiding the need to abort and repeat the drag operation.

## Searching in Lists

While the shortcut detailed above is useful for jumping directly to a single item, you may sometimes want to find all the items that have names containing a particular string. This can be accomplished using the Find Item command shown on the Navigation Pane's toolbar. This command will search the current list, and place all the matching items in the Global Search Results List. You can step through this list using the **F4** and **SHIFT+F4** key combinations, or display the list in its entirety by pressing **F8**. For more information on the global search functions, refer to the section later in this chapter.

## Private Items

Tags and certain other items in navigation lists may be marked as having Private Access by right-clicking and selecting the appropriate item from the menu. Such items can be edited and manipulated normally until the database protection is set to Private Access, at which point their contents will not be visible unless the database password is provided. The items will still exist and can still be referenced in the usual way, but they cannot be edited or viewed. This mechanism is designed to allow OEMs to provide databases to their customers without revealing important intellectual property or while protecting key items from editing. Refer to the Database Protection section below for more information.


## Undo and Redo

MonicoView 3.1 implements a universal undo and redo structure. This means that you can load a database, edit it for hours, and then return it to its original state by simply holding down the **CTRL+Z** key combination. You can then re-apply your changes by holding down **CTRL+Y**. All your actions are remembered, and MonicoView 3.1 will navigate between items and categories automatically when reversing or re-implementing changes.

## Global Searching

MonicoView 3.1 provides several options for searching within a database. At the simplest level, you can search for a text string anywhere in the database by pressing the **CTRL+SHIFT+F** key combination. Alternatively, as you will see later, you may search for expressions which contain errors, or for items that reference a tag or a communications device. All of these search operations place their output in the Global Search Result List, allowing you to review the results, or to navigate back and forth between the items that have been located.

The results list can be displayed at any time by pressing the **F8** key.



The title bar of the window describes the search operation that produced the list, while each line contains the description of an item that matched the search criteria. In the example above, right-clicking on a communications device and selecting the Find Usage command listed all the locations where the device was referenced. Double-clicking a given entry will jump directly to that item,

while the **F4** and **SHIFT+F4** key combinations can be used to step back and forth through the list. The commands associated with this feature may also be accessed via the Find Global commands on the Edit menu.

## Working with Databases


MonicoView 3.1 stores all the information about a device's configuration in what is called a database file. These files have the extension of `mv31`, although Windows Explorer will hide this extension if it is left in its default configuration. While MonicoView 3.1 databases are still essentially text files, they are compressed and in some cases encrypted, and they therefore cannot be directly edited using a text editor like Notepad. Databases are manipulated via the standard commands found on the File menu.

### Importing from MonicoView


Importing from MonicoView is not directly supported by MonicoView 3.1. If you need to convert such a database, please contact Monico technical support for assistance. They will be able to process the database for you. You may alternately use MonicoView II to import the database, and then convert the resulting file to MonicoView 3.1 as described below.

### Importing from MonicoView II

Databases created by MonicoView II can be opened directly by MonicoView 3.1 by changing the file type selection in the bottom right-hand corner of the File Open dialog box. When you come to save the database, MonicoView II will note that the file must be saved in MonicoView 3.1 format and will ask you where you wish to save it and under what name. The new name will typically be the old one with the `mv2` extension replaced with `mv31`. MonicoView 3.1 databases may also be opened via the File Import command, which essentially performs the same operation but without any need to change the selected file type.



If you open or import a MonicoView 3.1 database that was designed for a product not supported by MonicoView 3.1, you will be asked to which device you wish to convert the file. You may be offered several options, depending on which products are best capable of supporting the display resolution of the original device.



If the target device's display resolution does not match that of the original device, you may be offered several options relating to how display pages will be converted. Options labeled as *Scaled* take each display page and resize its contents to the new display format, adjusting font sizes where possible. Options labeled as *Centered* leave the display page contents unchanged but center them within the new display size, leaving either vertical bars or a frame around them. Options labeled as *Emulated* switch the target device's display into a mode where it scales its display output to emulate the original device's resolution. Where the scaling is by an integral factor, this will typically produce a clear display but with larger and more noticeable pixels. Where a non-integral factor is used, you should assess the results to see if you consider the resulting display quality to be acceptable.

## Database Identifiers


Each database created by MonicoView 3.1 is given a unique identifier. This identifier is used upon download of a new database to determine if the target device should clear its internal memory and delete any log files recorded to the device's memory card. If the identifier matches that of the database already in the device, the database is assumed to be merely a different version of the same file, so the data is retained. Conversely, if the identifiers are different, the data is cleared. When you use the Save As command on the File menu to save a copy of a database file, MonicoView 3.1 will ask if you want to allocate a new identifier. Select Yes if this is going to be a new project, and select No if you are just saving a backup copy of what is essentially the same database. This will ensure that the target device's retentive data is handled appropriately.

## Saving an Image

A MonicoView 3.1-specific item on the File menu is Save Image. This command allows the creation of a file that can subsequently be used to update the database in a terminal via a memory card or USB memory stick. The file contains a non-editable form of the database, plus any firmware and boot loader updates required for execution. Placing an image file called `image.mi31` in the root directory of the target device's memory card and then resetting the device will update the boot loader, firmware and database using the image file contents. Note that image files can optionally contain upload information, thereby allowing an editable version of the database file to be extracted from a terminal.

## Database Protection

Databases can be password-protected using the Protection command on the File menu:



The Default Access parameter is used to define what level of access will be permitted without first entering the database password. Various settings are available:


- *Full Access* will allow the database to be opened and edited without any password being entered. This is the default setting.
- *Read-Only Access* will allow the database to be opened, but will not allow changes to the database to be made or saved.
- *Private Access* will allow the database to be opened, but will not allow items flagged for Private Access to be viewed or edited.
- *Download Only Access* will allow the database to be opened, but will not allow any items to be viewed or edited. Download will still be supported.
- *No Access* will prevent all access without the password.

Lost passwords can be recovered by Monico for free, or for a nominal fee if you make a habit of it! Note that for security reasons, the recovered password will only be sent to the Recovery Email configured in the protection dialog box. Be sure to set this to a valid email address or you may find yourself unable to recover your password.

**It should be noted that this database protection mechanism is intended only to offer the access levels described for trusted users. It is not intended to be 100% cryptographically secure and does not provide defense against malicious attack. You are advised to use a third party secure protection method when storing or transferring your database.**

## Converting a Database

A database designed for one target device may be converted for use on another by using the Save Conversion command on the File menu. The conversions that can be performed depend on the original target device, but most combinations are supported.




The conversion process is started by selecting the new target device using the dialog shown above. You will then be prompted for a new filename, and the converted database will be saved to disk. To avoid accidental destruction of existing databases, you may not convert a database without first saving it under a new name. Once the converted database has been saved, it will automatically be opened for editing and review.

The conversion process resizes any display pages to fit the new display format, and remaps communications devices to the appropriate ports on the new device based upon whether they use the RS-232 or RS-485 physical layer. It may not be possible to convert a database in its entirety if, for example, the new device has fewer communications ports than the original. Therefore, you may have to perform a few adjustments after the conversion.

## Finding Database Errors

Certain operations may produce errors in your database. For example, you may delete a communications device, or you may set a tag equal to an expression based on itself, thereby producing a circular reference. MonicoView 3.1 will warn you about any such errors by means of a red balloon that will appear above the status bar:




The balloon will fade after a few seconds, but the red indication in the status bar will remain to remind you of the error condition. Clicking on the indicator will search for all errors or circular references, and place them on the Global Search Results List so that you may review them using the standard **F4** and **SHIFT+F4** key combinations. You may also right-click the indicator to access commands to recompile the whole database, or to optimize the way in which device communications are organized. Manual database recompilation is rarely needed, as MonicoView 3.1 will typically perform the necessary steps without user intervention.

## Downloading to a Device

MonicoView 3.1 database files are downloaded to the target device by means of the Link menu. The download process typically takes only a few seconds, but can take somewhat longer on the first download if MonicoView 3.1 has to update the firmware in the device, or if the device does not contain an older version of the current database. After this first download, MonicoView 3.1 uses a process known as incremental download to ensure that only changes to the database are transferred. This means that updates can be made in seconds, thereby reducing your development cycle time and simplifying the debugging process.

## Configuring the Link


The programming link between the PC and the target device can be made using an RS-232 port, a USB port or a TCP/IP connection. While TCP/IP connections are typically made via the panel's Ethernet port, they may also be established via a dial-in link. Before downloading, use the Link-Options command to ensure that you have the correct method selected:



Note that this dialog does not provide any method to select the target IP address when using TCP/IP for download. This information is stored in the database file and is configured via the Download tab of the Network configuration item. This method makes it easier to switch between multiple databases without having to re-configure the target IP every time. Note also that MonicoView 3.1 maintains distinct download settings when working with multiple product families. This makes it easier to use USB for downloading to those products that support it, while falling back to serial download for less capable devices.

## Sending the Database

Once the link is configured, the database can be downloaded using either the Link-Send or Link-Update commands. The former will send the entire database, whether or not individual objects within the file have changed. The latter will only send changes, and will typically take a much shorter period of time to complete. The Update command is typically the only one that you will need, as MonicoView 3.1 will automatically fall back to a complete send if the incremental download fails for any reason. As a shortcut, you can access Link-Update via the lightning bolt symbol on the toolbar, or via the **F9** key on the keyboard.




Note that the TCP/IP download option must be enabled via the Network settings in the Communications category.

## Extracting Databases

The Link-Support Upload command can be used to include the information necessary to support database upload when sending a database to a target device. This setting is stored in the database and can be configured on a per-file basis. Enabling database upload will slow the download process somewhat and may fail with extremely large databases containing many embedded images, but it will ensure that, should you lose your database file, you will be able to extract an editable image from the device.





Note that if you lose your database file and you do not have upload support enabled, you will not be able to reconstruct your file without starting from scratch. To extract a database from a panel, use the Link-Extract command. This command will upload the database, and prompt you for a name under which to save the file. The file will then be opened for editing. If the database was password-protected, you may be required to enter the password before it can be opened. In other words, enabling upload will not circumvent password protection.

## Sending the Time and Date


The Link-Send Time command can be used to set the target device's clock to match that of the computer on which MonicoView 3.1 is executing. This command also sends the current time zone and Daylight Savings Time settings to the target device, allowing the advanced features of the Time Manager to be used. Note that an accurate clock setting is required for certain features to work reliably, most notable those associated with SSL-TLS security.

## The Memory Card

If your target device has a memory card, several additional functions are available.

## Mounting the Card

If you are connected to a suitable device via the USB port, you can instruct MonicoView 3.1 to mount the device's memory card as a drive within Windows Explorer. You can use this functionality to save files to the card or to read information from the Data Logger. The drive is mounted and dismounted by sending commands using the Mount Flash and Dismount Flash options on the Link menu. Once a command has been sent, the target device will be reset, and Windows will refresh the appropriate Explorer windows.



Note that some caution is required when mounting the memory card:

- When the card is mounted, the target device will periodically inform the PC if data on the card has been modified. This means that both the PC and the device will suffer a minor performance hit if the card is mounted during data logging operations for longer than necessary.




- If you write to the memory card from your PC, the target device will not be able to access the card until Windows releases its lock on the card. This may take several seconds, and will restrict data logging operations during that time, and prevent access to custom webpages. MonicoView 3.1 will use the device's RAM to ensure that no data is lost, but if too many writes are performed such that the card is kept locked for four minutes or more, data may be discarded.
- You should never attempt to use Windows to format a memory card that you have mounted via MonicoView 3.1, whether it be via Explorer or from the command prompt. Windows does not correctly lock the card during format operations, and the resulting format may be unreliable and lead to subsequent data loss. See below for details of how to format a card in a reliable manner.

## Formating the Card

The only supported method of formatting a card is via the Format Flash command on the Link menu. Selecting this command will explain that the formatting process will destroy all the data stored on the memory card and offer you a chance to cancel the operation. If you elect to continue, the operator panel will be instructed to format the card. Note that this process may take several minutes for a large card. Slow formats on panels that are performing data logging may therefore result in gaps in the recorded data.

## Remote Monitoring

MonicoView 3.1 supports a so-called Watch List that allows you to view the contents of the tags and mapping blocks contained within your database. The Watch List is displayed in the Watch Window. This can be shown or hidden using the F7 key or the command on the View menu.



When first displayed, the Watch Window will show the simulated data that was defined when the tags were created. Pressing the View Online button will ensure that the current database matches that in the target device, and will then begin showing live data. The tag data will be displayed according to the appropriate format object.

Items can be added to the Watch List by right-clicking and selecting the appropriate menu command. One or more tags can be added at once, as can the content of a mapping block. A command also exists to add all the tags referenced by a specific display page, thereby allowing easier debugging of the page you are working on. The buttons at the top of the Watch Window can be used to remove one item or all of the items from the Watch List.

## System Menu

The MonicoView 3.1 runtime has been extended so that HMIs running MonicoView 3.1 now support a system mode that can be used to perform various maintenance functions. These include:


- Clearing the database;
- Loading the database from the memory card;
- Calibrating or testing the touchscreen;
- Formatting the memory card;
- Formatting the USB stick; and

- Setting the real-time clock.

The system menu is accessed by holding down the small, recessed pushbutton on the back of the unit while powered-up. Continue to hold the button until the menu appears. Within the system menu, the default touchscreen calibration values are used to ensure that recovery can be performed even if the calibration is grossly incorrect. To ensure accurate operation with an incorrectly calibrated touchscreen, an extra level of confirmation is required to select an option. Specifically, when the screen is pressed, the selected button will turn red. If the device has detected the correct button, hold the button until it turned red, at which point releasing it will select the associated option. If the system has detected the wrong button, release it immediately to cancel the selection and try again.

# Chapter 4 Using Communications

The first stage of creating a MonicoView 3.1 database is to configure the communications ports of the target device to specify which protocols you want to use and which remote devices you want to access. These operations are performed from the Communications category.




As can be seen, the Communications category lists the unit's available ports in the form of a tree structure. The example shown above has two Ethernet ports configured via the Network section and initial support for four TCP/IP protocols. It also has three primary serial ports, with the option to add further ports in the form of expansion modules.

## Network Configuration

The target device's IP network configuration is edited via the Network icon in the Navigation Pane. When the icon is selected, the Editing Pane will show several tabs, each of which allows a given set of properties to be configured.

### Zero Config

The first tab is used to configure MonicoView 3.1's new Zero Config networking support:



Zero Config allows a unit to obtain an IP address via DHCP and then be referenced by a simple name from anywhere on the local subnet. For example, if you name your unit `test` and leave the rest of MonicoView 3.1's settings at their default values, your unit will obtain an IP address and then respond to name resolution requests for the name `test.local` from anywhere on the local subnet. You may open a command prompt on your PC and type `ping test.local` to confirm the unit's IP address, or you may go to your web browser and type `test.local` into the address bar

to visit the unit's default website—although note that Chrome and perhaps some other browsers need the `http://` prefix to be used!.

Zero Config is controlled via the following properties:

- The *Local Name* property is used to define the name by which the unit will be referenced. The name should be unique on the local subnet. If you do not enter a name, the unit will respond to `red-xx-yy-zz.local`, where each letter pair is replaced with digits from the last half of the MAC address. A unit with a MAC address of 00-05-E4-05-39-62 will therefore respond to `red-05-39-62.local`.
- The *Responders* property is used to define the local name resolution protocols to which the unit will respond. You should ideally leave all available protocols enabled to ensure that clients have the best chance of finding your device.
- The *Install MonicoView 3.1 Local Root* link is used to install a root certificate that will validate the default SSL certificate that MonicoView 3.1 will automatically generate for its webserver when operating in secure mode. With this root certificate installed, your PC will trust any MonicoView 3.1-generated certificates, but only for names ending in `.local`. Refer to the chapter on the web server for more information.

Note again that Zero Config only works on a single subnet. If your unit has an IP address of 192.168.1.200 and a netmask of 255.255.255.0, it is on the 192.168.1.0 subnet and devices on other subnets will not be able to reach it via its local name. Note also that local name resolution is not recommended for production deployment.

## Ethernet Settings

The next one or two tabs configure the target device's Ethernet ports:

The screenshot shows the 'Communications - Network' configuration window. The 'Ethernet 1' tab is active. Under 'Port Settings', 'Port Mode' is a dropdown menu set to 'Configured via DHCP or APIPA'. Below it are input fields for 'IP Address' (192.168.1.20), 'Network Mask' (255.255.255.0), and 'Gateway' (0.0.0.0). The 'DNS Settings' section has a 'DNS Mode' dropdown set to 'Automatic', and two 'Name Server' fields with values 8.8.8.8 and 8.8.4.4. The 'Physical Layer' section has 'Full Duplex' and 'High Speed' dropdowns, both set to 'Enabled'. The 'Maximum Segment Size' section has 'For Send' and 'For Receive' input fields, both with the value 1280.

### Port Settings

The Port Mode field controls whether the port is enabled, and the method by which the port is to obtain its IP configuration. If DHCP mode is selected, the target device will attempt to obtain an IP address and associated parameters from a DHCP server on the network. If DHCP fails, an IP address will be allocated automatically using APIPA.

Note that if the unit offers any services to the network, DHCP will only make sense if Zero Config is being used to allow named access from the local subnet, or if the DHCP server is configured to allocate a well-known IP address to the unit's MAC address. For operator panels, you also have the option of using the `GetNetIP()` function to display the unit's IP address on the screen, allow reference directly by that address or the creation of a HOSTS file entry.

If Manual Configuration mode is selected, the IP Address, Network Mask and Gateway fields must be filled out with the appropriate information. The default values provided for these fields will almost never be suitable for your application! Be sure to consult your network administrator

when selecting appropriate values, and be sure to enter and download these values before connecting the target device to your network. If you do not do this, it is possible that you will cause problems on your network.

Selecting IEEE 802.3 Only mode will enable the port for low-level communications, but will not allocate an IP address or allow TCP or UDP to operate. This mode only makes sense when using drivers that use raw Ethernet, such as certain building automation protocols.

## DNS Settings

The DNS Settings configure the device's ability to resolve host names. While most of MonicoView 3.1 works with IP addresses, some configuration options can be set to host names instead. To convert these host names to IP addresses, access to one or more DNS servers is required. The servers may be specified manually or obtained from the DHCP server. The default manual selections are Google's public DNS servers at 8.8.8.8 and 8.8.4.4.

## Physical Layer

The Physical Layer options control the type of connection that the device will attempt to negotiate with the hub or switch to which it is connected. Generally, these options can be left in their default states, but if you have trouble establishing a reliable connection, especially when connecting directly to a PC without an intervening hub or switch, consider turning off both Full Duplex and High Speed operation to see if this solves the problem.

## Maximum Segment Size


The Maximum Segment Size options control the MSS settings for TCP send and receive. You should not generally have to change these settings as the default values are suitable for virtually all applications and all networks.

## Multiple Ports

If you are using more than one Ethernet port, note that only a single port should have a default gateway defined and that each port should have a distinct network address. MonicoView 3.1 will only send a given IP packet to a single interface, so a configuration that, for example, defines the first Ethernet port as 192.168.100.1 and the second as 192.168.100.2 will result in all packets for the 192.168.100.0 network going to the first port, thereby preventing the second port from operating correctly.

## TLS-SSL Settings

The next tab configures support for the TLS and SSL protocols that are used to provide secure connections over TCP/IP links.



These protocols are required if you intend to use HTTPS with MonicoView 3.1's web server, or if you intend to access secure mail servers.

## Settings

The Protocol Support option is used to enable or disable SSL support. By default, the protocol is enabled and there is very little reason to consider turning it off.

## Trusted Roots

When MonicoView 3.1 connects to a remote server using TLS-SSL, it can optionally validate the server identity by checking the server's certificate against a collection of trusted root certificates. If you intend to use certificate validation, you must provide these root certificates. The Certificate Source setting is used to select how they are to be specified. You have the option of specifying a file that contains one or more certificates, or instructing MonicoView 3.1 to use the trusted roots currently installed on your PC. This last option is a quick way of providing a validated set of root certificates that will work in most situations.

## Routing Settings

The next tab configured TCP/IP routing options, as shown.




## Routing Mode

The IP Routing option is used to enable or disable packet routing between interfaces. If this option is enabled, IP packets received on an Ethernet or modem port that are destined for devices connected to another port will be forwarded as required. Disabling this option will prevent such forwarding. The required setting will be dependent on your network topology.

## Routing Table

The routing table defines additional static routes for MonicoView 3.1's TCP/IP stack.



In the example above, a single route has been specified, telling MonicoView 3.1 to forward any packets destined for IP addresses starting with 192.168.3 to the router located on the local network at address 192.9.200.8. Once again, the exact settings required will be dependent on the topology of the network to which the target device is connected.

## Download Settings

The next tab is used to configure downloads to the target device over TCP/IP.

Communications - Network

Ethernet 1 | Ethernet 2 | ZeroConfig | TLS - SSL | Routing | Download | Add Ports

Remote Update

IP Download: Enabled

Listen Port Number: 789

Unit Addressing

Selection Mode: Auto Local Name

Remote Address: 192.168.1.20

Send Port Number: 789

## Remote Update

The IP Download option is used to enable or disable TCP/IP downloads, while the Port Number option specifies which TCP port should be used for such downloads. The default value of 789 should be used unless you have a good reason to use something else. The Download to Different Port option is used to let MonicoView 3.1 know that while the target device will be listening on the port specified under Port Number, it should send to a different port as there is an intervening router that is performing port mapping.

## Unit Addressing

These settings are used to specify the IP address to be used by the MonicoView 3.1 configuration software when the TCP download method is selected in the Link-Options dialog box:

- Auto Local Name mode uses the local name defined on the Zero Config tab to reference the unit. This will only operate correctly if a name has been entered and if you are connected to the same subnet as the unit.
- Auto Ethernet mode will use the IP address configured for the selected Ethernet port. Obviously, the port must be manually configured for this to make sense, and otherwise the software will not know the IP address ahead of time!
- Manual mode will allow an IP address to be entered via the Remote Address field..

Note that this information is saved as part of the database, allowing you to easily switch between units on the same network as you navigate from database to database, or if you have multiple instances of MonicoView 3.1 open at the same time.

## Adding Ports

The final tab can be used to add additional network protocols.

Communications - Network

Ethernet 1 | Ethernet 2 | ZeroConfig | TLS - SSL | Routing | Download | Add Ports

Port Commands

Create New Network Port

Create New Virtual Port

Pressing the Create New Network Port button will add a further network protocol, up to the maximum number of ports supported by the target device. Pressing the Create New Virtual Port button performs a similar operation, but will add a port capable of emulating a serial connection over TCP/IP. Either type of port can be deleted by selecting it in the Navigation Pane and by pressing **ALT+DEL** or by selecting the delete toolbar option.

## Protocol Selection

Once the network has been configured, you can select the protocols that you wish to use for communications using the method describe below. Several protocols may be used at once, and many of these protocols will support multiple remote devices. This means that you have several options as to how to mix protocols and devices to achieve the results you want.

For example, suppose you want to connect to two remote slave devices using Modbus over TCP/IP. Your first option is to use two network protocols, configuring both as Modbus masters with a single device attached to each. For most protocols, this will produce higher performance, as it will allow simultaneous communications with the two devices. It will, however, consume two of the available protocols, limiting your ability to connect via additional protocols in complex applications.

Your second option is to use a single protocol configured as a Modbus TCP/IP Master, but to add a further device so that both slaves are accessed via the same driver. This will typically produce slightly reduced performance, as MonicoView 3.1 will poll each device in turn, rather than talking to both devices at the same time. It will, however, conserve network protocols, allowing more complex applications without running out of resources.

## Using Virtual Ports

As mentioned above, MonicoView 3.1 supports the addition of virtual ports to the network configuration. A virtual port looks to MonicoView 3.1's communications system just like a serial port, but sends and receives its data over a TCP/IP link. Virtual ports may be configured in either active mode or passive mode. In the former case, MonicoView 3.1 will attempt to open a TCP/IP connection to a specified remote device, while in the latter case, MonicoView 3.1 will listen on a specific TCP/IP port for incoming connections. Virtual ports are typically used to communicate with devices via remote serial servers: A standard serial protocol is employed, but that protocol's data is encapsulated within TCP/IP packets.

## Serial Port Selection


When deciding which of the target device's serial ports to use for communications, note that some devices and certain option cards multiplex a single serial controller between multiple ports. This implies that if either port is used for a slave protocol, the other port will be unavailable. Similarly, if a token-passing protocol such as DH-485 is employed, the other port will likewise be disabled. MonicoView 3.1 will warn you if you attempt to create a configuration that breaks these rules.

Note also that a target device's programming port may be used as an extra communications port, but that it will not be available for download in these circumstances. This is not an issue provided the unit also has a USB port available. The USB-based method is highly recommended in the event you want to connect devices via the programming port. If you want to use the programming port for both download and communications, you will have to provide a method to re-enable serial downloads by executing the `StopSystem()` command in response to some user action.



## Selecting a Protocol


To select a protocol for a port, click on that port's icon in the Navigation Pane, and press the Pick button next to the Driver field in the Editing Pane. The following dialog box will appear:



Select the appropriate manufacturer and driver, and press the OK button to close the dialog box. The port will then be configured to use the appropriate protocol and a single device icon will be created in the Navigation Pane. If you are configuring a serial port, the various Port Settings fields (Baud Rate, Data Bits, Stop Bits and Parity) will be set to default values appropriate to the protocol in question. You should check these settings to make sure that they correspond to the settings for the device to be addressed. Note, protocols developed specifically for Monico will appear near the top of this manufacturer list.


## Protocol Options

Some protocols require additional configuration of parameters specific to that protocol. These appear in the Editing Pane when the corresponding port icon is selected. The following example shows the additional parameters for the Allen-Bradley DF-1 driver, which appear under the Driver Settings section of the Editing Pane:



## Working with Devices

As mentioned above, when a communications protocol is selected, a single device is created under the corresponding port icon. In the case of a master protocol, this represents the initial remote device to be addressed via the protocol. If the protocol supports access to more than one device, you can use the Add Additional Device button included in the Editing Pane to add further target devices. You may also use the New Comms Device command, accessed via the Navigation Pane toolbar. Each device is represented via an icon in the Navigation Pane, and, depending on the protocol, may have a number of properties to be configured.



In the example above, the Modbus Universal Master protocol has been selected, and three additional devices have been created, indicating that a total of four remote devices are to be accessed. The Editing Pane shows the properties for each device. The Enable Device property is present for all devices, while the balance of the fields are specific to the protocol that has been selected. Note that the devices are given default names by MonicoView 3.1 when they are created. These names may be changed by selecting the appropriate icon in the Navigation Pane, pressing F2 and then typing the new device name.

## Advanced Settings

In addition to the device settings mentioned above, certain master devices will also offer a number of advanced settings that can be used to optimize communications behavior:

- The *Spanning Reads* option specifies whether MonicoView 3.1 will optimize read operations by read-ing blocks of data, even if those blocks span registers that are not currently on the communications scan or referenced in the database. For example, with spanning reads enabled for a database that ref-erences registers D1, D2 and D4, a single communications command will be issued to read four regis-ters from D1 onwards. Disabling spanning reads will results in two read operations, one for two registers from D1, and one for a single register from D4.
- The *Transactional Writes* options specifies whether a series of changes to a data value in MonicoView 3.1 should result in a corresponding series of write operations, or whether only the last written value will be transferred. Transactional writes make, for example, pushbutton replacement easier..
- The *Preempt Other Devices* option specifies whether reads from other devices should be interrupted for writes to this device to be processed. Enabling this option will decrease write performance at the cost of less predictable data updates from other devices.
- The *Favor UI Writes* option specifies whether to give priority to write operations that directly result from user actions. This is useful when working with a database that performs a lot of background communications as a result of protocol conversion or programmatic activity.
- The *Comms Delay* option specifies a delay that will be inserted between any two communications transactions for this device. It is useful when working with remote devices that are unable to keep up with MonicoView 3.1's performance, or when a lower communications priority is to be given to a device.

## Creating Tags

Some drivers provide an option to create tags within MonicoView 3.1 that correspond to the data items that exist in the remote device. This option is accessed via the Make Data Tags link on


the device configuration page. The exact operation is driver-dependent, but typically you will be asked to select a configuration file that has been exported by the device's programming software. The import process will delete any tags from a previous import of the same device, but will preserve tag settings such as formats, triggers, security and so on.

## Port and Device Usage


You can find all the items that refer to a given communication device or to any of the devices connected to a particular port by right-clicking that item in the Navigation Pane and selecting the Find Usage command. The resulting items will be placed on the Global Search Results List, and can be accessed by means of the F4 and **SHIFT+F4** key combinations. The list itself can be shown or hidden by pressing **F8**.

## Using Expansion Modules

Some devices support the installation of external communications modules to provide additional communications facilities. Several cards are available, including models to support bus protocols such as CANOpen, Profibus or DeviceNet. These modules may be mounted to the device itself or attached via an expansion rack. Devices that support these modules will have a section called Comms Modules within the Navigation List of their Communications section. For example, the device shown below supports six directly-connected modules and the option to add tethered expansion racks:



To select the module to be installed in a specific slot, select that slot and press the Pick button next to the Module property in the Module Selection section. A dialog like the one shown below will be displayed:



Selecting the appropriate module will add one or more icons to the Navigation Pane, representing the additional port or ports that are made available by the card. The additional ports can be configured in the usual way, following the instructions in the previous sections. Note that the drivers available for a port will depend on the connection type it supports. For example, the CAN Module shows a port that will only support drivers designed for the CAN communication standard.


If you have an expansion rack connected to your target device, you may configure this by clicking on the Tethered Rack option in the navigation tree and then selecting the Expansion Rack option under the New button in the top-left corner of the Navigation Pane. Icons will be added to represent the rack and the slots that it provides. These can be configured just as for the slots of the target device itself.

## Slave Protocols

For master protocols (i.e. those where MonicoView 3.1 initiates communication) there is no further configuration required under the Communications category. For slave protocols (i.e. those where MonicoView 3.1 receives and responds to remote requests), the process is slightly more complex, as you must also indicate what data you wish to expose.

## Selecting the Protocol


As with master protocols, the first stage is to select the protocol for the communications port that you wish to use. The example below shows the target device's RS-485 port configured for operation with the Modbus ASCII Slave protocol:



Note that a single device has been created for the protocol. In the case of master protocols, this represents the remote device that MonicoView 3.1 will access. In this case, though, the device represents the Modbus slave that the hardware will itself embody. This means that only a single device is required, and that things such as the station number to which the hardware will respond are normally configured via the port settings rather than those of the device.

## Adding Gateway Blocks


Having configured the protocol, you must now decide what range of addresses you want the slave protocol to expose. In this example, we want to use Modbus registers 40001 through 40008 to allow read and write access to certain data items in our database. We begin by selecting the device icon in the Navigation Pane, and clicking the Add Gateway Block button in the Editing Pane. An icon representing the block will appear under the device:



In the example above, we have configured the Start Address to 40001 to indicate that this is where we want the block to begin. We have also configured the Block Size to eight to allocate one Modbus register for each tag we want to expose, and we have configured the Direction as Device to Asset HMI 12", to indicate that we want remote devices to be able to read and write data items exposed via this block. Finally, we have left the Tag Data property at its default setting of Use Scaled Values, indicating that we want any scaling to be applied to tag data before that data is transferred to the gateway block.


## Adding Items to a Block

Once the block has been created and its size defined, entries appear in the Navigation Pane to represent each of the registers that the block exposes to remote access. When one of these entries is selected, an expanded Resource Pane appears and provides access to available data items. These items comprise both tags from within your database, and data registers from any master communications devices that you have configured.



To indicate that you want a register within your gateway block to correspond to a specified data item, simply drag that item from the Resource Pane to the Navigation Pane, dropping it on the appropriate gateway block entry. The example above shows how the first four registers in the block have been mapped to tags called Tag1 through Tag4, indicating that accesses to 40001 through 40004 should be mapped to the respective variables.

## Accessing Individual Bits




If your application requires it, you can expand individual elements within a Gateway Block to their constituent bits, and map a different data item to each bit. To do this, right-click on the element in question, and select **Expand Bits** from the resulting menu. The Navigation Pane will be updated to show the individual bits that make up the register, and these can be mapped using the drag-and-drop process described above.

## Protocol Conversion

In addition to exposing internal data tags via slave protocols, Gateway Blocks can also be used to expose data that is obtained from other devices, or to move data between two master devices. This unique protocol conversion feature allows much tighter integration between elements of your control system, even when using simple, low-cost devices.

## Master and Slave



Exposing data from other devices over a slave protocol is simply an extension of the mapping process described above, except this time, instead of dragging a tag from the Resource Pane, you should select the **Comms Devices** category, expand the appropriate master device, and drag across the icon that represents the registers that you want to expose. You will then be asked for a start address in the master device, and the number of registers to map, and the mappings will be created as shown.

In this example, registers **N7:0** through **N7:3** in an Allen-Bradley PLC have been exposed for access via Modbus as registers **40001** through **40004**. MonacoView 3.1 will automatically ensure that these data items are read from the Allen-Bradley PLC to fulfill Modbus requests, and will

automatically convert writes to the Modbus registers into writes to the PLC. If you select a TCP/IP slave protocol, this mechanism allows even the simplest legacy device to be connected to an Ethernet network.

## Master and Master


To move data between two master devices, simply select one of the devices, and create a Gateway Block for that device. You can then add references to the other device's registers just as you would when exposing data on a slave protocol. Again, MonicoView 3.1 will automatically read or write the data as required, transparently moving data between the devices. The example above shows how to move data from a Modbus device into an SLC-500.

## Which Way Around?

One question that may occur to you is whether you should create the Gateway Block within the Allen-Bradley device, as in this example, or within the Modbus device. The first thing to note is that there is no need to create more than a single block to perform transfers in a single direction. If you create a block in AB to read from MOD, and a block in MOD to write to AB, you'll simply perform the transfer twice and slow everything down! The second observation is that the decision as to which device should own the Gateway Block is essentially arbitrary. In general, you should create your blocks to minimize the number of blocks in the database. This means that if the registers in the Allen-Bradley lay within a single range, but the registers in the Modbus device are scattered all over the PLC, the Gateway Block should be created within the Allen-Bradley device to remove the need to create multiple blocks to access the different ranges of the Modbus address space.

## Controlling Master Blocks

Gateway blocks within master devices have several additional properties.



- As with slave blocks, the *Tag Data* property selects how data tags are mapped to and from the block. As you will discover in the next chapter, a tag data can be subject to various stages of transformation. This property selects where in the transformation process the gateway block will obtain and inject its data.
- The *Update Policy* property is used to define how the block updates. The default setting of Automatic will cause read blocks to update continuously, and write blocks to transfer only those values that have changed. A setting of Continuous will cause all blocks to update continuously. A setting of Timed will cause all blocks to update at the rate defined by the *Update Period* property, with the entire contents of a write block being written each time.


- The *Request and Acknowledge* properties are used to control the timing of block updates via tags or other data items. If the Acknowledge property is left empty, Request will act as an enable field, with a zero value disabling the block and a non-zero value allowing it to operate. If the Acknowledge is defined, the Request and Acknowledge will operate as a standard two-wire handshake, with the block updating once on each rising edge of the Request, and the Acknowledge being set after the transaction completes.

## Data Transformation

You may also use Gateway Blocks to perform math operations that your PLC might not otherwise be able to handle. For example, you may want to read a register from the PLC, scale it, take the square root, and write it back to another PLC register. To accomplish this, refer to the section on Data Tags, and create a mapped tag to represent the input value that will be read from the device. Then, create a tag to represent the output value, setting the expression to perform the required math. You can then create a Gateway Block targeted at the required output register, and drag the formula across to instruct MonicoView 3.1 to write the derived value back to the PLC.

## Disabling Communications

MonicoView 3.1 provides the option to disable all driver-based communications by means of a property contained in the top-level item of the Communication category.



Disabling communications can be useful during development when you do not have the necessary target devices available. When operating in disabled mode, MonicoView 3.1 initially sets all tags equal to their simulated values, and then allows them to be changed just as if they were being written to the associated devices. If you find your communications has stopped for no reason, make sure you do not have this setting set to disabled!



# Chapter 5 Working with Tags

Once you have configured the communications options for your database, the next step is to define the data items that you want to display or otherwise manipulate. This is done by selecting the Data Tags category in the Navigation Pane. Tags can be created, deleted and otherwise manipulated using the standard operations referred to earlier in this manual.

## All About Tags

Data Tags are named entities that represent data items.

### Data Sources

Tags may get their data from three possible sources:

- A tag may be *mapped* to one or more registers in a remote device, in which case MonicoView 3.1 will automatically read the corresponding register when the tag is referenced or displayed. Similarly, if you change a mapped tag, MonicoView 3.1 will automatically write the new value to the device.
- A tag may be *internal*, in which case it represents one or more data elements within the MonicoView 3.1-based device. Internal tags can be marked as retentive, in which case they will keep their values through a power-cycle, or non-retentive, in which case they will be reset to zero on power-up.
- A tag may be an *expression*, in which case it represents a calculation based upon other data items, optionally using mathematical operators and one or more of MonicoView 3.1's internal or user-defined functions. Expression tags can calculate derived values for internal use or for transfer to remote devices.

### Types of Tags

MonicoView 3.1 supports three main types of tags:



















- *Numeric Tags* represent integer or floating point values.
- *Flag Tags* represent an on-or-off value.
- *String Tags* represent strings of Unicode characters.

Each of the three main tag types can represent a single value or an array of values. An array is a collection of items with similar properties that are grouped together and accessed via an index value. Mapped arrays correspond to multiple registers in the target device.

A fourth type of tag is the *Basic Tag*. This is a simplified version of a tag that can only represent string or numeric expressions. It lacks many of the powerful features of the standard tags. It is typically used to encode simple data items like constants.

## Tag Key

The following graphic shows the tag keys available in MonicoView 3.1 and describes their usage:

	Integer; Internal		When seen in gateway blocks; Read Block (Device to G3)
	Integer; Read Only		When seen in slave device gateway blocks; Read and Write Block
	Integer; Writeable (Read and Write or Write Only)		Binary Value; Internal
	Integer; Array		Binary Value; Read Only
	Integer; Basic Tag		Binary Value; Writeable (Read and Write or Write Only)
	String; Internal		Binary Value; Array
	String; Read Only		Binary Value; Standard Flag
	String; Writeable (Read and Write or Write Only)		
	String; Array		
	String; Basic Tag		
	Floating Point; Internal		
	Floating Point; Read Only		
	Floating Point; Writeable (Read and Write or Write Only)		
	Floating Point; Array		
	Floating Point; Basic Tag		
	When seen in gateway blocks; Write Block (G3 to Device)		

## Tag Attributes

Tags within MonicoView 3.1 are rich objects that define various common properties:

- A tag's *label* is a translatable, human-readable string used to automatically label data fields referring to this data item. It is also used by the Web Server and the Data Logger to label associated data items.
- A tag's *description* is a non-translatable string used to provide an annotation as to the tag's purpose. It is not normally viewed by the user of the target device, but can be displayed for diagnostic purposes.
- A tag's *format* is a collection of settings that define the method by which the tag data is to be presented for display. The format may be left as General, in which case MonicoView 3.1 will use default format-ting rules, or may be set to one of many formatting types. For example, a numeric value may be displayed in scientific format, or may be used to select a number of different text strings.
- A tag's *coloring* is a collection of settings that define how the tag's text is to be displayed or what colors are to be used to represent the state of the tag. Again, a number of different colorings exist, allowing a tag to change its appearance based upon a variety of conditions. Foreground and background colors are defined in pairs, and can be accessed individually by display primitives.
- A tag's *security* descriptor defines the access rules to be used when changing the tag, and whether or not those changes are to be logged.

Basic tags lack format, coloring and security information. In addition, numeric and flag tags define alarms and triggers, respectively allowing alarms to be activated or actions to be taken based on certain conditions.

## Advantages of Tags

Since MonicoView 3.1 allows you to place a PLC register directly on a display page without going to the trouble of defining data tags, it is worth spending a moment pointing out the benefits of the minimal extra work that is involved with using tags:

- Tags allow you to name data items, so you know which data item within the PLC you are referring to. Further, if the data in the PLC moves or if you decide to switch to an entirely different family of PLC, you can simply re-map the tags, and avoid having to make any other changes to your database.
- Tags allow you to avoid re-entering the same information again and again. When you create a tag, you specify how the tag is to be displayed. In the case of a numeric tag, this means you tell MonicoView 3.1 how many decimal places are to be used, and what units, if any, are to be appended to the value. When you place a tag on a display page, MonicoView 3.1 knows how to format it without you having to do anything further. Similarly, if you decide to change the formatting, and perhaps switch from one set of units to another, you can do this in one place, without having to edit each display page in turn.
- Tags are used as one basic method for color animation. The various colors that are defined for a tag can be used to specify the way in which other animation primitives will be displayed. While there are other methods, tags provide a simple way of changing the color of display primitives.
- Tags are the key to implementing slave protocols. MonicoView 3.1 treats these protocols as mechanisms for exposing data items within the target device. This allows the same data to be accessed via multiple ports, so that, for example, a machine setting could be changed by both a local SCADA package and a similar package working over Ethernet from a remote site. Without tags, there would be nothing to expose, and this mechanism could not be implemented!
- Tags are used within MonicoView 3.1 to implement many advanced features. If you want to use functionality such as alarms, triggers, data logging or the web server, you will have to use tags, period. The formatting data from the tag definition is typically required by all these features, so tags are mandatory for their operation.

In other words, tags will automate many tasks during programming, saving you time. Even if you decide not to use tags, many of the subsequent chapters of this manual refer to concepts discussed in this chapter. You should read them thoroughly before proceeding.

## Editing Properties

Most properties are edited in ways that are self-evident to users familiar with the Windows operating system. For example, you may be required to enter a numeric value, or to select an item from a drop-down list. Certain types of property, though, provide more complex editing options and these are described below.


### Expression Properties

Expression properties are capable of being set to:

- A constant value.
- The contents of a data tag.
- The contents of a register in a remote communications device.
- A combination of such items linked together using various math operators.
- The return value of a local program.

In its default state, the arrowed button immediately after the label of the property shows that the field is in General mode. The edit box to the right of the button may show a grayed-out string

that indicates the default behavior of the property. An example of an empty expression property without a default value is shown below:




If you are familiar with MonicoView 3.1's expression syntax you can edit the property by typing an expression directly into the edit box. A complete description of this syntax can be found in the Writing Expressions chapter. Expression properties may also be set to a variety of other items, each of which is typically accessed via the list displayed under the arrowed button. You can access this list in the usual way by pressing the button, or with the button selected, you can press the spacebar to show the menu. You may also press the initial character of the item that you wish to select, avoiding the need to show the list at all. For example, pressing T with the button selected is equivalent to showing the menu and selecting the Tag option.

### Selecting a Tag

To set an expression property to an existing tag, you have four options. First, you can ensure that the target field is selected and then double-click the required tag in the Resource Pane. Second, you can drag the tag from the Resource Pane and drop it on the target field. Third, you can select Tag from the drop-down menu activated by the arrowed button and be reminded that you could just have dragged the target to the field in the first place! Finally, you can just do it the old fashioned way and type the tag name into the expression property.

### Creating a Tag

To set an expression property to a new tag, you have three options. First, for expressions that define the source of a data item, you can select the New Tag option in the drop-down menu activated by the arrowed button. Second, if you already have a tag selected, you can press the Pick button and select New Tag from the resulting dialog box. Finally, you can enter the name of the new tag as part of an expression, and have MonicoView 3.1 prompt you via a dialog similar to that shown below:




In this example, an expression referencing Tag1 has been entered, but no such tag exists within the database. MonicoView 3.1 spots the error, and asks if you would like to create this tag automatically. The dropdown list can be used to select the type of the new tag, and will contain options appropriate for the context in which the tag was used. The Yes to All button can be used to tell MonicoView 3.1 to use the default data type to create any other missing tags contained within this expression without any further prompting.

## Comms References

To select a register from a communications device, select a device from the drop-down menu. A dialog box will be displayed, allowing you to choose a register within that remote communications device. The various communications devices are listed at the end of the menu in the order in which they were created. You may also select the Next option from the drop-down menu, thereby setting the current tag equal to the last-used PLC register plus the number of registers mapped to that address. For example, mapping a 32-bit tag to Modbus register 40001 and then selecting Next will map the subsequent tag to 40003.

## Editing an Expression


As mentioned above, general expressions are typically edited directly in the edit box of the property. However, they can also be edited by pressing the Edit button next to the field, thereby activating a dedicated dialog box that allows more of the expression to be seen, as follows:



The editor used in this dialog box is the same as is used for creating global programs. It therefore provides syntax coloring. You can also access help information on system functions by placing your cursor in or at the end of the function name and pressing F1.

## Complex Expressions

If your expression is too complex to fit into a single line—or if you would simply rather write it as a program—you may select the Complex option from the drop-down menu, thereby allowing a local program to be created, as follows:



The `return` statement is used provide the value of the expression, just as if you had called a global program. Note once again that the program editor is used, providing syntax coloring and auto-indent facilities, and that the F1 mechanism described above can be used to consult help information on system functions. The Description text allows you to make a quick note of the program's function. This will be displayed next to the property for reference. For information on writing and editing programs, refer to later chapters.

## Translatable Strings

MonicoView 3.1 databases are designed to support multilingual operation, whereby any string that will be presented to the user of the target device is capable of being displayed in one of many different languages. To allow you to define these translations, properties that contain such strings have a button labeled Translate to their right-hand side.


Label:

To enter the translations, click the button and the following dialog box will appear:



The languages listed in the dialog are defined at the database level. Refer to the chapter on Localization for information on how they are selected, on the operation of the Auto-Translate function, and on how to switch the language at runtime. Note that if you do not enter text for a language and that language is subsequently selected by the operator, MonicoView 3.1 will use the text from the default language instead.

Translatable strings are also capable of being defined as expressions, thereby allowing them to change at runtime. For example, while an alarm name would typically be set during configuration, a database designer might want the alarm to contain the value of the tag that triggered the alarm. Expressions can be entered by prefixing them with an equals sign, just as one would do when editing a spreadsheet, as follows:




Note the use of the `AsText` property of the tag to allow its value to be accessed as a string according to its format setting. Refer to the Writing Expressions chapter for more details.

## Two-Way Properties

Properties such as translatable strings that are capable of being set to a constant value or an expression are called two-way properties. As well as accepting expressions prefixed with an equals sign, they can be set to tag values by simply dragging the appropriate tag from the Resource Pane and dropping it on the field.

## Action Properties


Action properties are used within tags to define the action to be performed when triggered conditions are met, or when a tag value is changed. They are edited by a drop-down and edit box similar to those used for editing expressions, as follows:



As with expressions, the Edit button can be used to invoke a larger editing window, and complex actions can be created by means of local programs.

## Color Properties

Color properties within tags represent a pair of colors, these being the foreground and the background color to be used when displaying the tag's state in textual form. The following example shows a color pair being edited:



The drop-down menu contains the following colors:

- The sixteen standard VGA colors.
- Thirty-two shades of gray between black and white.
- Any other colors used in the database, up to a limit of twenty-four.

The More option at the bottom of the list can be used to invoke the color selection dialog, as follows:




This dialog offers several ways of defining a color. You can pick from the palette, pick from the “rainbow” window, or enter the explicit HSL or RGB parameters. If the color selected has not previously been used in the database and is not one of the standard colors or grays, it will be added to the custom colors shown in the drop-down menu.

## Log Properties

When you first enter the Data Tags category of the Navigation Pane, you will notice a number of properties relating to event logging. These properties control if and how events generated by tags or by their alarms will be saved to the memory card. They are analogous to the properties defined by data logs, and you are referred to the Using the Data Logger chapter later in this manual for more information on how they can be used.

## Creating Tags

Data tags are created and otherwise manipulated via the usual methods in the Navigation Pane. You will notice that you can create folders to organize your tags, and that the New button in the toolbar contains a drop-down arrow to allow you to select the type of tag to be inserted. The left-hand side of the New button will create a tag of the same type as the last one you created, making it easier to create multiple tags without using the drop-down.



## Duplicating Tags

The Smart Duplicate command on the Edit menu can be used to create a new copy of an existing tag, automatically incrementing its data source to refer to the next data element.

The definition of “next” depends on the exact type of the data element, with MonicoView 3.1 being able to select the next register in a communications device, the next member of an array, or the next tag in a sequence. For example, using Smart Duplicate on a 16-bit tag mapped to Modbus register 40001 will produce a tag mapped to 40002, while using it on a tag mapped to `Array[2]` will produce a tag mapped to `Array[3]`.

This facility makes it much easier to create sets of tags referring to sequential data items.

## Editing Multiple Tags

You may want to edit the properties of several tags at once. MonicoView 3.1 supports this operation by having you edit one tag, and then allowing you to set the properties of the other tags equal to those of the one that you first edited. MonicoView 3.1 provides two methods to do this, both of which rely on the same underlying mechanism.

## Using Copy From

The Copy From command can be used to copy the selected properties of a given tag to one or more tags in the Navigation List. To use the command, select the target tags, and then rightclick to access the context menu. (Note that the Navigation List for tags supports multiple selection via the usual **SHIFT** and **CTRL** key combinations.) Select one of the Copy From commands, and the cursor will change to allow you to select the tag from which the copy operation should be performed. Depending on the command that was selected, one or more properties from the source tag will then be applied to the target tags.



## Using Paste Special

The Paste Special command can be used to achieve the same result, but via a different method that also allows properties to be copied between databases or between multiple instances of MonicoView 3.1. First, select the source tag and use the Copy command to put it and its properties on the Clipboard. Next, select the target tags in the Navigation List, again noting that multiple selections can be made. Finally, right-click the selection to access the context menu, and select the Paste Special command. The following dialog box will appear:




The selected properties from the source tag will be applied to the target tags.

## Property Selections

Both methods detailed above allow you to define which properties are to be copied:

- *Mapping* copies the Source property. It also copies all the properties that control that tag's communications options, such as the Extent, Access, and all the other properties that are contained in the Data Source section.
- *Scaling* copies the Scale To property and the associated scaling limits.
- *Format* copies the Format Type, and the associated Format object.
- *Coloring* copies the Coloring Type, and the associated Coloring object.
- *Alarms* copies all the properties of Alarm 1 and Alarm 2.
- *Triggers* copies all the properties of Trigger 1 and Trigger 2.
- *Security* copies all the properties from the tag's Security page.

In addition, the *Selective* option can be used to select the properties to copy, as follows:



The list contains a hierarchical presentation of all the properties defined by the source tag, organizing them according to the layout used when editing the tag, and showing the value

assigned to each. The properties or groups of properties can be selected or deselected using the associated checkboxes. Only the checked properties will be applied, providing you with low-level control of what gets copied from one tag to another.

## Importing and Exporting

Selecting the Data Tags item in the Navigation List provides access to buttons that can be used to export and import the data tags in your database. Tags may be exported to either Unicode text files or ANSI comma separate variable files, with either capable of being edited via applications such as Microsoft Excel. The export file is divided into sections based upon tag type, format type and coloring type. Each section contains several columns, the meanings of which can be determined by consulting the sections below.

Note that certain communications drivers can import, for example, a PLC configuration file and create data tags that correspond to the PLC registers. This facility is accessed via the device configuration page using the Make Data Tags command.

## Finding Tag Usage


You can find all the items that refer to a given tag by right-clicking that item in the Navigation Pane and selecting the Find Usage command. The resulting items will be placed on the Global Search Results List, and can be accessed by means of the **F4** and **SHIFT+F4** key combinations. The list itself can be shown or hidden by pressing **F8**.

## Numeric Tags

A numeric tag represents one or more integer or floating point values. MonicoView 3.1 performs all internal calculations using either 32-bit signed integers or single-precision floating point, so all data will be converted to one of these forms before processing. (Certain functions exist to allow 64-bit math to be performed via pairs of 32-bit array elements. Refer to the Reference Manual for more information.) Mapped numeric tags support several transformations that occur between the raw data and the data that will be used by MonicoView 3.1. The exact process is defined in detail later in this chapter.

## Data Properties

A numeric tag has the following properties on its Data tab:



## Data Source

- The *Source* property defines where the tag gets its data. The default setting results in an internal tag, but the drop-down list may be used to select a general expression, another data tag or an item from a remote device.
- The *Extent* property is used to choose between a single element tag or an array. If you select an array, you must enter the required number of elements. Arrays are not permitted for tags whose source is an expression. For mapped items, the number of registers to be read from the remote device depends upon the data type defined for the address. For example, an array of two elements that was mapped to a register of type Word as Long will result in four registers being accessed, with two words being needed for each long value. A similar array mapped to a data type of Word as Word will only need two registers.
- The *Manipulation* property defines the first-stage transformation that is applied as communications data is being transferred into a mapped tag. The following options may be available, depending on the exact data type being used:

MANIPULATION	DESCRIPTION
None	The data will not be changed.
Invert Bits	Each bit in the data will have its state inverted.
Reverse Bits	The most significant bit in the data will be swapped with the least significant bit, with intermediate bits being treated in a similar fashion.
Reverse Bytes	The most significant byte in the data will be swapped with the least significant byte and so on. Only available for data items of 16 bits or more in size.
Reverse Words	The most significant word in the data will be swapped with the least significant word. Only available for data items of exactly 32 bits in size.
BCD to Binary	Each four bit group in the data will be interpreted as a single decimal digit. Selecting this option will force the data to an unsigned integer.

- The *Treat As* property for internal tags defines the tag's data type. For mapped tags, it defines how the manipulated data is to be interpreted by MonicoView 3.1. The property will be set to default based on the underlying data type when the tag is mapped, but can be changed. Note that for most tags, the Treat As property does not have the final say on the actual data type of the tag as the scaling proper-ties may be used to convert the data further. The following options may be available, depending on the exact data type of the communications data:

TREAT AS	DESCRIPTION
Signed Integer	The data will be treated as a 32-bit signed value, with smaller data values being sign-extended. For example, a 16-bit value of 0x8000 will be converted to 0xFFFF8000.
Unsigned Integer	The data will be treated as a 32-bit signed value, with smaller data items being zero-extended. For example, a 16-bit value of 0x8000 will be converted to 0x00008000. Only available for data items of less than 32 bits in size.
Default Integer	The data will be either zero-extended or sign-extended according to the preference of the communications driver from which the data is obtained. Only available for data items of less than 32 bits in size.
Floating Point	The data will be treated as a 32-bit single-precision floating point value. Only available for data items of exactly 32 bits in size.

- The *Access* property is used for mapped tags to define what kind of communications operations are to be permitted. Internal tags are always set to read and write access, and expression tags are always read-only.

- The *Read Mode* property is used only for array tags. It defines the elements to be read when the array is referenced. The following settings can be used:

READ MODE	DESCRIPTION
Entire Array	All the elements in the array will be read whenever the array is referenced, and access will be blocked until the read operation has completed. This will ensure that data is available, but will produce the slowest performance.
Manual Mode	The array will not be read until a call is made to the <code>ReadData</code> function to force a one-time manual update.
On Demand	Array elements will be read as they are referenced. This produces the quickest performance, but stale data may be returned when an element is first accessed.
N Either Side	On Demand operation will be used, but N registers either side of the referenced register will be read as well, thereby making adjacent data available more quickly.

- The *Storage* property is used to indicate whether the tag will be retained through a power-cycle of the target device. This is typically used for internal tags, but mapped write-only tags may also have their values retained.

### Data Scaling

- The *Scaling* property is used for mapped tags to define a final scaling step to be performed on the data. Data may be scaled to integer or to floating point, irrespective how MonicoView 3.1 is treating the manipulated communications data. For example, an integer value may be scaled to a floating point value, in which case MonicoView 3.1 will consider the tag to be floating point. Likewise, a floating point value might be converted back to an integer, perhaps without even changing its magnitude.
- The *Data From* and *Data To* properties define the domain of the transformation that occurs on read and the range of the transformation that occurs on write. The values must match the data type specified in *Treat As*, such that only data that is being treated as floating point can have non-integral values entered in these fields. On read, values beyond these limits are still accepted, and will be scaled to corresponding values beyond the Display limits. In other words, no clipping of the value is performed.
- The *Display From* and *Display To* properties define the range of the transformation that occurs on read and the domain of the transformation that occurs on write. The values must match the data type specified in *Scale To*, such that only data that is being scaled to floating point can have non-integral values entered in these fields. On write, values beyond these limits are still accepted, and will be scaled to corresponding values beyond the Data limits. In other words, no clipping of the value is performed.

### Data Simulation

- The *Simulate As* property defines the assumed value to be used for the tag when working in the display page editor. Entering a sensible value allows a better representation of the page's likely appearance. This value is also used as the tag's default value if communication is globally disabled.

### Data Actions

- The *On Write* property defines an action that is to be invoked when the tag is changed. The system variable `Data` will hold the new data value when the write occurs and when the action is executed. The use of *On Write* properties is covered later in this chapter.


### Data Setpoint

- The *Use Setpoint* property is used to enable or disable a setpoint for this tag.

- The *SP Value* property defines an expression or another tag that this tag is nominally meant to follow. This setpoint can then be used in alarms or in primitives to implement various functions.

## Format Properties

A numeric tag has the following properties on its Format tab:



### Data Labels

- The *Label* property was discussed above under Tag Attributes.
- The *Description* property was discussed above under Tag Attributes.
- The *Class* property is reserved for future expansion.

### Format Type


- The *Format Type* property selects the format for this tag. The various types of formats are discussed in detail in a following chapter, as are the other properties that might appear according to the format type that you have selected.

### Data Limits

- The *Minimum Value* and *Maximum Value* properties are used to manually define data entry limits. If no values are provided, the default values will be based on the *Default Limits* property described below.
- The *Default Limits* property defines how the tag's data entry limits are to be determined if they are not provided. A setting of Automatic results in the Display Range specified on the Data tab being used as a primary source, with the format object being used as a fallback if scaling is not enabled. If neither source can define a range, the maximum supported range for the tag's data type is used. A setting of From Format forces the format object to be used.
- The *Deadband* property is used to define how much the tag's value must change before updates will be sent to OPC UA clients. Regular communications drivers do not use this setting and will therefore process writes as soon as the value changes. The property will not be shown on devices which do not support the OPC UA Server.

## Color Properties

A numeric tag has the following properties on its Colors tab:




### Color Type

- The *Color Type* property defines the coloring for this tag. The various types of coloring are discussed in detail in a following chapter, as are the other properties that might appear according to the option you have selected.

## Alarm Properties

A numeric tag has the following properties on its Alarms tab:



### For Each Alarm

- The *Event Mode* property is used to indicate the logic that will be used to decide whether the alarm should activate. The tables below list the available modes.

MODE	ALARM WILL ACTIVATE WHEN:
Data Match	The value of the tag is equal to the alarm's <i>Value</i> .
Data Mismatch	The value of tag is not equal to the alarm's <i>Value</i> .
Absolute High	The value of the tag exceeds the alarm's <i>Value</i> .
Absolute Low	The value of the tag falls below the alarm's <i>Value</i> .
Rise in Value	The value of the tag rises by the alarm's <i>Value</i> .

MODE	ALARM WILL ACTIVATE WHEN:
Fall in Value	The value of the tag falls by the alarm's <i>Value</i> .
Change in Value	The value of the tag changes by the alarm's <i>Value</i> .

The following modes are only available when a setpoint is defined:


MODE	ALARM WILL ACTIVATE WHEN:
Deviation High	The value of the tag exceeds the tag's <i>Setpoint</i> by an amount equal to or greater than the alarm's <i>Value</i> .
Deviation Low	The value of the tag falls below the tag's <i>Setpoint</i> by an amount equal to or greater than the alarm's <i>Value</i> .
Out of Band	The tag moves outside a band, which is equal in width to twice the alarm's <i>Value</i> and is centered on the tag's <i>Setpoint</i> .
In Band	The tag moves inside a band, which is equal in width to twice the alarm's <i>Value</i> and is centered on the tag's <i>Setpoint</i> .

- The *Event Name* property defines the name that will be displayed in the alarm viewer or in the event log when referring to this event.
- The *Value* property defines either the absolute value at which the alarm will be activated, the deviation from the setpoint value or the change in value that must occur since the alarm last triggered. The exact interpretation depends on the event mode as described above.
- The *Hysteresis* property is used to prevent an alarm from oscillating between the on and off states when the process is near the alarm condition. For example, for an absolute high alarm, the alarm will become active when the tag exceeds the alarm's value, but will only deactivate when the tag falls below the value by an amount greater than or equal to the alarm's hysteresis. Remember that the property always acts to maintain an alarm once the alarm is activated, and not to modify the point at which the activation occurs.
- The *Enable* property defines an expression that enables or disables the alarm. A non-zero or empty value results in the alarm being enabled, while a zero values results in the alarm being disabled.
- The *Trigger* property is used to indicate whether the alarm should be edge or level triggered. In the former case, the alarm will trigger when the condition specified by the event mode first becomes true. In the latter case, the alarm will remain in the active state while the condition persists. This property can also be used to indicate that this alarm should be used as an event only. In this case, the alarm will be edge triggered, but will not result in an alarm condition. Rather, an event will be logged to internal memory and optionally to the memory card.
- The *Delay* property is used to indicate how long the alarm condition must exist before the alarm will become active. In the case of an edge triggered alarm or event, this property also specifies the amount of time for which the alarm condition must no longer exist before subsequent reactivations will result in a further alarm being signaled. As an example, if an alarm is set to activate when a speed switch indicates that a motor is not running even when the motor has been requested to start, this property can be used to provide the motor with time to run-up before the alarm is activated.
- The *Accept* property is used to indicate whether the user will be required to explicitly accept an alarm before it will no longer be displayed. Edge triggered alarms must always be manually accepted.

- The *Priority* property is used to control the order in which alarms are displayed by MonicoView 3.1's alarm viewer. The lower the numerical value of the priority field, the nearer to the top the alarm will be displayed.
- The *Siren* property is used to indicate whether or not the activation of this alarm should also activate the target device's sounder. While the sounder is active, the panel's display will also flash to better draw attention to the alarm condition.
- The *Mail To* property specifies the email address book entry to which a message should be sent when this alarm is activated. Refer to the Using Services chapter for information on configuring email.
- The *On Accept*, *On Active*, *On Clear* and *On Event* properties are used to specify actions to be executed when the change of state occurs. Not all actions will be available, depending on the alarm's trigger mode and accept type.

## Trigger Properties

A numeric tag has the following properties on its Trigger tab:



### For Each Trigger


- The *Trigger Mode* property is as described for the Alarms tab.
- The *Value* and *Hysteresis* properties are as described for the Alarms tab.
- The *Delay* property is as described for the Alarms tab.
- The *Action* property is used to indicate what action should be performed when the trigger is activated. Refer to the Writing Actions chapter for a description of the syntax used to define the various actions that are available.

## Plot Properties

Quick Plot is a feature added to numeric tags which allows for an easy method of graphically tracking tag values. Once enabled and configured, the tag plot can be added to a display page from the Core Primitives category on the Resource Pane. Click and drag the Quick Plot primitive onto the desired display page and resize as needed.

The following properties are on the Plot tab:





- The *Mode* property is used to set how data is recorded. *Continuous* mode records in a circular buffer, discarding old values. *Continuous* is the most commonly used mode. *One-Shot Relative* will start recording when the enable becomes true, and stop when the buffer fills or when enable goes false. The time value attributed to each sample will be relative to the time when the plot started. *OneShot Absolute* is similar, except that all time values are zero-based.
- *On Rewind* specifies what to do if time goes backwards. While this sounds rather odd, it can occur since the time base can be a variable and may not be linked to the actual time of day. It may, for example, be a position value such that the plot shows the profile traced by part of a machine. The options are to either clear the data after the time to which we have stepped back, or shift all the data in the buffer so that the old data is retained but is shifted back in time.
- *Enable* starts and stops the trend.
- *Data Valid* indicates whether the recorded data is valid. Having this expression go to zero allows gaps to be recorded in the data without stopping the trend and thereby dropping all the data when it restarts.
- By default, *Time Base* is the system time. It is used to define the time base. For some applications (e.g. recording ramp-soak performance from an external controller) it can be an external time base. And for other applications (e.g. tracking a machining profile) it may not be a time value at all.
- *Time Span* is the number of time base ticks to record in the buffer. Note that this is typically larger than the point count and, together with that variable, defines how many ticks each slot will take up.
- *Point Count* is the number of points to store in the buffer. As the quick plot is designed for a basic display of a tag's changes over time, this is typically a smaller value than the number of pixels across the display.

## Security Properties


Refer to the Using Security chapter for details of security descriptors.

## Flag Tags

A flag tag represents one or more on-or-off values and is considered to have an internal data type of integer, no matter what the type of underlying data. Mapped flag tags allow simple transformations between raw data and the data that will be used by MonicoView 3.1.

## Data Properties

A flag tag has the following properties on its Data tab:



## Data Source

- The *Source* property defines where the tag gets its data. The default setting results in an internal tag, but the drop-down list may be used to select a general expression, another data tag or an item from a remote device.
- The *Extent* property is used to choose between a single element tag or an array. If you select an array, you must enter the required number of elements. Arrays are not permitted for tags whose source is an expression. For mapped tags, the exact number of registers to be read from the remote devices depends upon the type of the registers to which the tag is mapped and the *Treat As* property.
- The *Treat As* property is used for mapped tags to define how the on-or-off value is to be derived from the raw communications data and vice versa. The following settings may be available, depending on the underlying data type:

TREAT AS	RESULT
Unsigned Integer	The tag will be true if the data is non-zero, or false if it is zero. A true value will be written as an integer value of 1, while a false value will be written as zero. For a mapped array, each array element corresponds to a single communications data element. This setting is available for any communications data of 8 bits or more in size.
Floating Point	The tag will be true if the value is non-zero, or false if it is zero. A true value will be written as a 32-bit floating point value of 1, while a false value will be written as zero. For a mapped array, each array element corresponds to a single communications data element. This setting is available for communications data of exactly 32 bits in size.
Bit Array Little Endian	A single bit is extracted from the data. For a single element, the Bit Number field selects the bit, with the least significant being bit 0. For an array, each element is a single bit, such that the bits are in effect packed within the data items. The first element of the array is the least significant bit, the second is the next-most significant and so on. An 8 element array mapped to a byte data type in a PLC will thus read all 8 bits from a single register.
Bit-Array Big-Endian	As above, except that the bits are reversed, with a Bit Number field of Bit 0 accessing the most significant bit, and with the first element of an array being sourced from the most significant bit downwards.

- If you are using either of the Bit Array modes, see the section below on Write Mode regarding the danger of writing to individual bits within larger data types when other bits in the same value can be changed by the remote device.
- The *Bit Number* property extracts a single bit from multi-bit data items for mapped non-array tags. The property is not used for other configurations.
- The *Manipulation* property defines the transformation that is applied to the tag state after the *Treat As* logic has been performed when reading data, or before the *Treat As* logic when writing data. The only option available is to invert the state of the tag. Not a lot else you can do with a single bit value!

- The *Access* property is used for mapped tags to define what kind of communications operations are to be permitted. Internal tags are always set to read and write access, and expression tags are always read-only.
- The *Write Mode* property is used when a flag tag is mapped to a bit within a larger data type and where write access is enabled. If you instruct MonicoView 3.1 to write from cached data, the most recently known value (either from a read or the last write) will be used for the remaining bits in the larger data type. If you instruct MonicoView 3.1 to perform a read-modify-write operation, the larger data type will be read, the selected bit will be updated, and the new value will be written back. This operation may occur in a single communications transaction if the underlying driver supports it, but will more normally occur as three individual operations. There is still the chance that the data in the other bits of the underlying type will change during the operation, causing invalid values to be written back. You should therefore avoid writing to individual bits in larger data type when the remote device can change other bits in the same location.
- The *Read Mode* property is used only for array tags. It defines the elements to be read when the array is referenced. The following settings can be used:

READ MODE	DESCRIPTION
Entire Array	All the elements in the array will be read whenever the array is referenced, and access will be blocked until the read operation has completed. This will ensure that data is available, but will produce the slowest performance.
Manual Mode	The array will not be read until a call is made to the <code>ReadData</code> function to force a one-time manual update.
On Demand	Array elements will be read as they are referenced. This produces the quickest performance, but stale data may be returned when an element is first accessed.
N Either Side	On Demand operation will be used, but N registers either side of the referenced register will be read as well, thereby making adjacent data available more quickly.

- The *Storage* property is used to indicate whether the tag will be retained through a power-cycle of the target device. This is typically used for internal tags, but mapped write-only tags may also have their values retained.

## Data Simulation

- The *Simulate As* property defines the assumed value to be used for the tag when working in the page editor. Entering a sensible value allows a better representation of the page's likely appearance. This value is also used as the tag's default value by the target device if communication is globally disabled.

## Data Actions


- The *On Write* property defines an action that is to be invoked when the tag is changed. The system variable *Data* will hold the new data value when the write occurs and when the action is executed. The use of On Write properties is covered later in this chapter.

## Data Setpoint

- The *Use Setpoint* property is used to enable or disable a setpoint for this tag.
- The *SP Value* property defines an expression or another tag that this tag is nominally meant to follow. This setpoint can then be used in alarms or in primitives to implement various functions.

## Format Properties

A flag tag has the following properties on its Format tab:



## Data Labels


- The *Label* property was discussed above under Tag Attributes.
- The *Description* property was discussed above under Tag Attributes.
- The *Class* property is reserved for future expansion.

## Format Type

- The *Format Type* property selects the format for this tag. A Two-State format is used by default, but a Linked format may be substituted instead. The various types of formats are discussed in detail in a following chapter, as are the other properties that might appear per the selected format type.

## Color Properties

A numeric tag has the following properties on its Colors tab:



## Color Type

- The *Color Type* property defines the coloring for this tag. A TwoState coloring is selected by default, but a General, Linked or Fixed coloring may be substituted. The various colorings are discussed in detail in a later chapter, as are the other properties that might appear according to the option you have selected.

## Alarm Properties

A flag tag has the following properties on its Alarms tab:

The screenshot shows the 'Data Tags - Tag2' configuration window. It has tabs for Data, Format, Colors, Alarms, Triggers, and Security. The 'Alarms' tab is active, showing two alarm configurations: Alarm 1 and Alarm 2.

**Alarm 1:**

- Event Mode: Active On
- Event Name: (empty field)
- Enable: General (dropdown), True (checkbox)
- Trigger: Level Triggered Alarm (dropdown)
- Accept: Manual (dropdown)
- Siren: No (dropdown)
- On Active: General (dropdown), None (text)
- On Clear: General (dropdown), None (text)
- On Accept: General (dropdown), None (text)
- On Event: General (dropdown), (empty text)
- Delay: 0 ms
- Priority: 1
- Mail To: No Recipient

**Alarm 2:**

- Event Mode: Disabled
- Event Name: (empty field)
- Enable: General (dropdown), (empty text)
- Trigger: Level Triggered Alarm (dropdown)
- Accept: Manual (dropdown)
- Siren: No (dropdown)
- On Active: General (dropdown), (empty text)
- On Clear: General (dropdown), (empty text)
- On Accept: General (dropdown), (empty text)
- On Event: General (dropdown), (empty text)
- Delay: 0 ms
- Priority: 1
- Mail To: No Recipient

### For Each Alarm

- The *Event Mode* property is used to indicate the logic that will be used to activate the alarm. The tables below list the available modes.

MODE	ALARM WILL ACTIVATE WHEN:
Active On	The tag is true.
Active Off	The tag is false.
Change of State	The tag changed.

The following modes are only available when a setpoint is defined:

MODE	ALARM WILL ACTIVATE WHEN:
Not Equal to SP	The tag does not equal its setpoint.
Off When SP On	The tag does not respond to an ON setpoint.
On When SP Off	The tag does not respond to an OFF setpoint.
Equal to SP	The tag equals its setpoint.


- The *Event Name* property defines the name that will be displayed in the alarm viewer or in the event log, as appropriate. MonicoView 3.1 will suggest a default name based upon the tag's label, and the event mode that has been selected.
- The *Enable* property defines an expression that enables or disables the alarm. A non-zero or empty value results in the alarm being enabled, while a zero values results in the alarm being disabled.
- The *Trigger* property is used to indicate whether the alarm should be edge or level triggered. In the for-mer case, the alarm will trigger when the condition specified by the event mode first becomes true. In the latter case, the alarm will remain in the active state while the condition persists. This property can also be used to indicate that this alarm should be used as an event only. In this case, the alarm will be edge triggered, but will not result in an alarm condition. Rather, an event will be logged to internal memory and optionally to the memory card.
- The *Delay* property is used to indicate how long the alarm condition must exist before the alarm will become active. In the case of an edge triggered alarm or event, this property also specifies the amount of time for which the alarm condition must no longer exist before subsequent reactivations will result in a further alarm being signaled. As an example, if an alarm is set to activate when a speed switch indicates that a motor is not running even when the motor has been requested to start, this

property can be used to provide the motor with time to run-up before the alarm is activated.

- The *Accept* property is used to indicate whether the user will be required to explicitly accept an alarm before it will no longer be displayed. Edge triggered alarms must always be manually accepted.
- The *Priority* property is used to control the order in which alarms are displayed by MonicoView 3.1's alarm viewer. The lower the numerical value of the priority field, the nearer to the top the alarm will be displayed.
- The *Siren* property is used to indicate whether or not the activation of this alarm should also activate the target device's sounder. While the sounder is active, the panel's display will also flash to better draw attention to the alarm condition.
- The *Mail To* property specifies the email address book entry to which a message should be sent when this alarm is activated. Refer to the Using Services chapter for information on configuring email.
- The *On Accept*, *On Active*, *On Clear* and *On Event* properties are used to specify actions to be executed when the change of state occurs. Not all actions will be available, depending on the alarm's trigger mode and accept type.

## Trigger Properties

A flag tag has the following properties on its Trigger tab:



### For Each Trigger

- The *Trigger Mode* property is as described for the Alarms tab.
- The *Delay* property is as described for the Alarms tab.
- The *Action* property is used to indicate what action should be performed when the trigger is activated. Refer to the Writing Actions chapter for a description of the syntax used to define the various actions that are available.

## Security Properties


Refer to the Using Security chapter for details on security descriptors.

## String Tags

A string tag represents one or more strings of Unicode characters. While MonicoView 3.1 works in Unicode, it can also read and write strings from 8-bit sources. Mapped string tags support various encodings, allowing one or more characters to be extracted from one register.

## Data Properties

A string tag has the following properties on its Data tab:



## Data Source

- The *Source* property defines where the tag gets its data. The default setting results in an internal tag, but the drop-down list may be used to select a general expression, another data tag or an item from a remote device.
- The *Extent* property is used to choose between a single element tag or an array. If you select an array, you must enter the required number of elements. Arrays are not permitted for tags whose source is an expression. For mapped tags, the exact number of registers to be read depends upon the type of the registers to which the tag is mapped, the length and the Packing setting.
- The *Length* property defines the length of the string. Non-retentive internal strings do not have to have a length defined, as they can store a string of any reasonable length.
- The *Packing* property is used for mapped tags to define how the Unicode string value is to be derived from the raw communications data and vice versa. The following settings may be available, depending on the underlying data type:

PACKING	RESULT
None	Each comms data item is used to source a single character for the string. 8-bit values will be treated as ASCII, while values containing 16-bit or more bits will be treated as Unicode.
ASCII Big Endian	Each 8-bit unit in the data item is used to source a single ASCII character, with the most significant 8 bits being used for the first character. Only available for data items of 16 bits or greater in size.
ASCII Little Endian	Each 8-bit unit in the data item is used to source a single ASCII character, with the least significant 8 bits being used for the first character. Only available for data items of 16 bits or greater in size.
Unicode Big Endian	Each 16-bit unit in the data item is used to source a single Unicode character, with the most significant 16 bits being used for the first character. Only available for data items of 32 bits in size.
Unicode Little Endian	Each 16-bit unit in the data item is used to source a single Unicode character, with the least significant 16 bits being used for the first character. Only available for data items of 32 bits in size.
Hex String Little Endian	Each 4-bit unit in the data item is used to source a single hex character in the range '0'-'9' and 'A'-'F', with the least significant 4 bits being used first. Writes to strings with this packing method are not supported.
Hex String Big Endian	Each 4-bit unit in the data item is used to source a single hex character in the range '0'-'9' and 'A'-'F', with the most significant 4 bits being used first. Writes to strings with this packing method are not supported.

- The *Access* property is used for mapped tags to define what kind of communications operations are to be permitted. Internal tags are always set to read and write access, and expression tags are always read-only.
- The *Read Mode* property is used only for array tags. It defines the elements to be read when the array is referenced. The following settings can be used:

READ MODE	DESCRIPTION
Entire Array	All the elements in the array will be read whenever the array is referenced, and access will be blocked until the read operation has completed. This will ensure that data is available, but will produce the slowest performance.
Manual Mode	The array will not be read until a call is made to the <code>ReadData</code> function to force a one-time manual update.
On Demand	Array elements will be read as they are referenced. This produces the quickest performance, but stale data may be returned when an element is first accessed.
N Either Side	On Demand operation will be used, but N registers either side of the referenced register will be read as well, thereby making adjacent data available more quickly.

- The *Storage* property is used to indicate whether the tag will be retained through a power-cycle of the target device. This is typically used for internal tags, but mapped write-only tags may also have their values retained.

## Data Simulation


- The *Simulate As* property defines the assumed value to be used for the tag when working in the page editor. Entering a sensible value allows a better representation of the page's likely appearance. This value is also used as the tag's default value by the target device if communication is globally disabled.

## Data Actions

- The *On Write* property defines an action that is to be invoked when the tag is changed. The system variable *Data* will hold the new data value when the write occurs and when the action is executed. The use of On Write properties is covered later in this chapter.

## Format Properties

A string tag has the following properties on its Format tab:



## Data Labels

- The *Label* property was discussed above under Tag Attributes.
- The *Description* property was discussed above under Tag Attributes.
- The *Class* property is reserved for future expansion.




## Format Type

- The *Format Type* property selects the format for this tag. A String format is used by default, but a General or Linked format may be substituted. The various types of formats are discussed in detail in a following chapter, as are the other properties that might appear per the selected format type.

## Color Properties

A string tag has the following properties on its Colors tab:



## Color Type


- The *Color Type* property defines the coloring for this tag. A Fixed coloring is selected by default, but a General or Linked coloring may be substituted. The various colorings are discussed in detail in a later chapter, as are the other properties that might appear according to the option you have selected.

## Security Properties

Refer to the Using Security chapter for details on security descriptors.

## Basic Tags

Basic tags are used to represent constants or expressions:



## Data Value

The *Data Value* property defines the value of the tag. It must be an expression. The tag itself will adopt the data type of the expression that is used.

### Data Simulation

- The *Simulate As* property defines a value to be used as the default for the tag when editing display pages. Entering a sensible value allows a better representation of the page's likely appearance. This value is also used as the tag's default value by the target device if communication is globally disabled.

### Data Labels

- The *Label* property was discussed above under Tag Attributes.
- The *Description* property was discussed above under Tag Attributes.
- The *Class* property is reserved for future expansion.

## Advanced Topics

### Array Properties

Many of the properties of array tags can be made variable based upon the exact element of the array being referenced. To achieve this, a system property called *i* is set to the element index during the evaluation of those properties. For example, the *Label* property could be set to `= "Element " + AsText(i+1)` to label the array elements Element 1, Element 2, etc.

This feature can be used with the following properties:

- The tag's label.
- The tag's scaling values.
- The tag's setpoint.
- The tag's limits.
- The tag's On Write property.
- The tag's event labels.
- The tag's event and trigger values and hysteresis settings.
- The tag's trigger actions.

Note that triggers and events are evaluated separately for each element of the array for which they are configured, allowing several events or triggers to be created at once. The only limitation to this feature is that alarms and events only operate for the first 256 elements of the array. Triggers operate for all elements, regardless of the size of the array.

### Tag Data Flow

As you will have noticed, numeric tags in particular have a number of data transformations that occur between the comms data and the value actually used by MonicoView 3.1. These can be configured to handle just about any sort of data in any way you like, but the exact way in which they operate for numeric tags deserves further attention.

### Numeric Tag Read Process

When data is read from a device, the following steps occur:

- The comms driver reads a value based on the address setting that has been defined for the source of the tag. Based on the type of the address, the driver may combine more than one register to create the data value. For example, reading a single Word as Long value will result in two registers being read and combined by the driver using its knowledge of the device's word ordering.

- The comms data is then modified according to the Manipulation property for the tag in question. These processes perform bit or byte level changes to the data, typically to account for driver incompatibilities or other situations where the data is not in the form that the comms driver normally expects.
- The manipulated data is then interpreted in conjunction with the tag's Treat As property, being viewed as a 32-bit integer or a 32-bit single-precision floating-point value as appropriate. Data items smaller than 32 bits will be either zero- or sign-extended based, per their configuration. If no scaling is defined, the result of this step defines the final value and data type of the tag.
- If scaling is defined, the interpreted data is then scaled according to the domain and range defined for the tag. The result of the scaling may be of a different type from the interpreted data, such that a floating point value may be scaled to an integer or vice versa. Assuming scaling is defined, the result of this step then defines the final value and data type of the tag.

### Numeric Tag Write Process

When data is written to a device, the following steps occur:

- If scaling is defined, the domain and range are reversed, converting the data back to an unscaled value whose data type is defined by the Treat As property.
- If the unscaled data is larger than the comms data, the high-order bits are removed, producing a stripped version of the data suitable for the next step.
- The stripped data is then modified according to the Manipulation property, reversing the transformation applied above, producing comms data.
- The comms driver then takes the communications data, and writes it to one or more registers in the target device according to the type of the address.

### Using On Write

A tag's On Write property contains an action which is executed when a change is made to the tag. While the action is being executed, a system property called `Data` is set to the new value, allowing the new data to be examined.

There are three typical uses for this feature:

- Regular read-and-write tags can have an On Write property defined to allow some action to be taken on demand. For example, a database may need to store the value of a tag in two formats, one being the original tag format and the other being a transformed version. While there are other ways of doing this, one method is to use the On Write property to catch the write, and then run a program to calculate and store the transformed version.
- Read-only tags can be made writable by defining an On Write property. While this seems odd, imagine, for example, that a PID loop has a read-only property to indicate its current output power, and a read-write property to define the manual output power. You could define display fields to allow data entry to the output power when in manual mode, and catch them using the On Write property, thereby writing the values to the manual output power.
- Complex transformations can be implemented by defining an expression tag to perform the forward transformation and an On Write action to perform the inverse. For example, a tag could be set to `Sqrt([40001])` to take the square root of a value in a Modbus PLC. Since this is an expression tag, it is by definition read-only, but writes can be allowed by defining an On Write equal to `[40001] = Data*Data`, thereby reversing the square root calculation.




# Chapter 6 Using Formats

Numeric tags can have one of various data formats selected, while flag and string tags have their formats fixed to Two-State and General respectively. Each format type will take a data value and convert it to or from a text string.

## Format Types

The following formats are supported:



- *General* format provides simple formatting of values, converting numeric values to signed decimal values, and passing on strings without further processing. The general format has no configuration properties and is the default format for string tags. It is also implicitly used by basic tags.
- *Linked* format uses the data format of another tag to format the tag that you are configuring. It is useful for creating format templates and then applying them to many tags in the same database. This can avoid repetition, and make it easier to adjust settings such as units or decimal point counts.
- *Numeric* format takes a floating point or integer value and converts it to a string, using a specific number base and selecting the required number of digits before and after the decimal point. It can also add a prefix string and a units string to the value, and handle signed or unsigned values.
- *Scientific* format takes a floating point or integer value and converts it to exponential format, selecting the required number of digits after the decimal point. It can also add a prefix string and a units string to the value.
- *Time and Date* format takes an integer value and treats it as a number of seconds elapsed since 1<sup>st</sup> January 1997. It can display the result as a date value, a time value or both, or treat the value as elapsed time that can contain more than 24 in its hours value. Date and time formatting options are provided to allow support for various international standards.
- *IP Address* format takes an integer value and displays it as four decimal bytes separated by periods. This allows a 32-bit number to be displayed as an IP address without further configuration.
- *Two-State* format takes a numeric value and displays one of two strings based on whether the value is zero or non-zero. This is the default format type for flag tags.
- *Multi-State* format takes a numeric value and compares it against a table containing values and strings. Either the string associated with a matching data value is displayed, or the format can be configured to display the last string with a value not higher than that string's associated data.
- *String* format takes a string value and either restricts its length during input or applies a template that indicates what type of character can be entered at which point in the string. This allows, for example, a string to be formatted as a United State telephone


number, with the parentheses and dash being inserted upon display without the need to store them in the string data.

## General Format

General format has no properties.

## Linked Format


Linked format has the following properties:

The image shows a 'Format Data' dialog box. It has a 'Format Like:' label followed by a dropdown menu showing 'Tag' and a text field containing 'Tag1'. There is a 'Pick...' button to the right.

- The *Format Like* property is used to select a tag from which the formatting information for this tag is to be obtained. For correct operation, a tag of the correct data type should be used, such that, for example, a string tag's format should be based upon another string tag. Failure to observe this requirement will result in a fallback to the default formatting rules.

## Numeric Format

Numeric format has the following properties:

The image shows a 'Fixed Data Format' dialog box. It has several sections: 'Number Base' (dropdown: Decimal), 'Sign Mode' (dropdown: Soft Sign), 'Digits Before DP' (spin box: 5), 'Digits After DP' (spin box: 0), 'Lead Character' (dropdown: Spaces), and 'Group Digits' (dropdown: No). Below these is a 'Dynamic Data Format' section with 'Dynamic DP' (dropdown: General) and a text field 'none' with an 'Edit...' button. At the bottom is a 'Format Units' section with 'Prefix' and 'Units' text fields, each with a 'Translate...' button.

## Fixed Data Format

- The *Number Base* property defines the radix of the displayed value. The Passcode setting works in decimal but masks the digits using asterisks. Many of the other options will be disabled when a non-decimal mode is used.
- The *Sign Mode* property defines how the data is treated, and how the sign is displayed. A value of Unsigned will display the value as a 32-bit unsigned number, thereby allowing such values to be displayed and entered, even though MonicoView 3.1 cannot perform any math on values that will not fit within a 32-bit signed representation. A value of Soft Sign will display a leading minus sign for negative numbers and a space for positive numbers, while a value of Hard Sign will display a leading plus sign rather than the space.
- The *Digits Before DP* property defines the number of digits to be shown before the decimal point. For values without decimals, this is the total number of digits to be shown and therefore controls the size of the data field.
- The *Digits After DP* property defines the number of digits to be shown after the decimal point. For integer values, the decimal point is inserted into the integer representation, such that 1234 would be displayed and entered as 12.34 if this property were set to two. A value of zero suppresses the decimal point.
- The *Lead Character* property defines how values with leading zeros are formatted. Leading zeros may either be retained, replaced with spaces or removed completely.

Removing them can sometimes cause values on a display to show unpleasant jitter as they change their number of digits, particularly if the value is centered within a field.

- The *Group Digits* property enables the insertion of comma separators every three digits for decimal numbers, with similar behavior for other number bases.

## Dynamic Data Format

- The *Dynamic DP* property provides a means whereby an expression may be used to define the number of digits shown after the decimal point, with the limit set by the value defined by the *Digits after DP*, described in the Fixed Data Format.

## Format Units

- The *Prefix* property defines a string to be displayed before the numeric value.
- The *Units* property defines a string to be displayed after the numeric value.

## Scientific Format

Scientific format has the following properties:

Fixed Data Format

Mantissa Sign Mode:

Exponent Sign Mode:

Digits After DP:

Dynamic Data Format

Dynamic DP:

Format Units

Prefix:

Units:

## Fixed Data Format

- The *Mantissa Sign Mode* property defines how the sign is displayed on the mantissa. A value of Soft Sign will display a leading minus sign for negative numbers and a space for positive numbers, while a value of Hard Sign will display a leading plus sign rather than the space.
- The *Exponent Sign Mode* property defines how the sign is displayed on the exponent. A value of Soft Sign will display a leading minus sign for negative values and nothing for positive values, while a value of Hard Sign will display a leading plus sign for positive values instead.
- The *Digits After DP* property defines the number of digits to be shown after the decimal point. By definition, there is always one digit before the decimal in scientific format. A value of zero suppresses the decimal point.

## Dynamic Data Format

- The *Dynamic DP* property provides a means whereby an expression may be used to define the number of digits shown after the decimal point, with the limit set by the value defined by the *Digits after DP*, described in the Fixed Data Format.

## Format Units

- The *Prefix* property defines a string to be displayed before the numeric value.
- The *Units* property defines a string to be displayed after the numeric value.

## Time and Date Format

Time and Date format has the following properties:

The screenshot shows a configuration panel for 'Time and Date Format'. It is divided into three main sections: 'Format Mode', 'Time Format', and 'Date Format'.  
- **Format Mode:** A dropdown menu labeled 'Field Contents:' with 'Time Then Date' selected.  
- **Time Format:** Contains four settings: 'Time Format:' (dropdown with '12 Hour (Civil)' selected), 'Show Seconds:' (dropdown with 'No' selected), 'AM Suffix:' (text input with 'AM' and a 'Translate...' button), and 'PM Suffix:' (text input with 'PM' and a 'Translate...' button).  
- **Date Format:** Contains three settings: 'Date Format:' (dropdown with 'Locale Default' selected), 'Show Year:' (dropdown with 'As 2 Digits' selected), and 'Show Month:' (dropdown with 'As Digits' selected).

### Format Mode

- The *Format Mode* property is used to indicate whether the field should display the time, the date or both. In the last case, this property also indicates in which order the two elements should be shown. Options are also provided to allow a time value to be treated as an elapsed period of time, rather than a time that is paired with a date. For example, a value of 25.5 hours will display as 25:30 in an elapsed mode. In a conventional time mode, it will display 00:30, as the system will assume a time early in the morning on 2<sup>nd</sup> January 1997.

### Time Format

- The *Time Format* property is used to indicate whether 12hour (civil) or 24hour (military) time format should be used. As with other properties, leaving this set to Locale Default will allow MonicoView 3.1 to pick a suitable format according to the language selected within the operator panel.
- The *Time Separator* property is used to select the character that will be placed between the elements of the time display. The default value will be based upon the current language selection, but can be overridden as required.
- The *AM Suffix* and *PM Suffix* properties are used with 12-hour mode to indicate the text to be appended to the time field in the morning and afternoon, as appropriate. If you leave the property undefined, MonicoView 3.1 will use a default.
- The *Show Seconds* property is used to indicate whether the time field should include the seconds, or whether it should just comprise hours and minutes.

### Date Format

- The *Date Format* property is used to indicate the order in which the various date elements (i.e. date, month and year) should be displayed.
- The *Date Separator* property is used to select the character that will be placed between the elements of the date display. The default value will be based upon the current language selection, but can be overridden as required.




- The *Show Year* property is used to indicate whether the date field should include the year, and if so, how many digits should be shown for that element.
- The *Show Month* property is used to indicate whether the month should be displayed as digits (i.e. 01 through 12) or as its short name (i.e. Jan though Dec).

## IP Address Format

IP Address format has no properties.

## Two-State Format

Two-State format has the following properties:



**Data Format**


ON State:  [Translate...](#)

OFF State:  [Translate...](#)

- The *ON State* property defines the text to be shown if the value is non-zero. The *OFF State* property defines the text to be shown if the value is zero.

## The Multi-State Format

The Multi-State format has the following properties:



**Format Control**

States:  [Edit...](#)

Limit: [General](#)

Default:  [Translate...](#)

Match Type: [Discrete](#)

**Format States**

	Data	Text	
1:	<input type="text" value="1"/>	<input type="text" value="ONE"/> <a href="#">Translate...</a>	
2:	<input type="text" value="2"/>	<input type="text" value="TWO"/> <a href="#">Translate...</a>	
3:	<input type="text" value="3"/>	<input type="text" value="THREE"/> <a href="#">Translate...</a>	
4:	<input type="text" value="4"/>	<input type="text" value="FOUR"/> <a href="#">Translate...</a>	

## Format Control

- The *States* property defines how many states the multi-state format will contain, up to a maximum of 500 entries. The window displaying the format will update to show the required number of Data and Text properties.
- The *Limit* property defines how many states will be used when matching data against this format. It can be dynamically adjusted, while the absolute number of states is statically defined. This property is useful when the state fields are populated at runtime, as it allows unused fields to be skipped during the data entry process.
- The *Default* property defines a string to be displayed if the data cannot be matched against the defined states. If no value is provided, the numeric representation of the unmatched state will be displayed in parentheses.
- The *Match Type* property defines how the data is compared against the various states. If *Discrete* is selected, the tag data must match a given state's data value in order for that state to be used. If *Ranged* is selected, MonicoView 3.1 assumes that the state data values are in increasing numerical order, and will use a state value if the tag data is less than or equal to that state's data value but greater than the prior state's data value. During data entry, ranged format objects assign values equal to the individual states' actual data values.

## Format States


- The *Data* and *Text* properties define the data value and display text for each state in this format. States with empty text fields are disabled and are ignored.

## Format Commands

Multi-state format objects also provide options to allow their various states and the associated properties to be exported to or imported from Unicode text files. These files can then be edited by an application such as Microsoft Excel.

## The String Format

The String Format has the following properties:



**Format Data**

Template:

Max Length:

- The *Template* property is used to enter an optional “picture” of what the string should look like. A template comprises a number of special formatting characters that indicate what type of character is acceptable at that position. The following formatting characters are supported:

CHARACTER IN TEMPLATE	PERMITTED CHARACTERS				
	A-Z	a-z	0-9	SPACE	OTHER
A	Yes	-	-	-	-
a	Yes	Yes	-	-	-
S	Yes	-	-	Yes	-
s	Yes	Yes	-	Yes	-
N	Yes	-	Yes	-	-
n	Yes	Yes	Yes	-	-
M	Yes	-	Yes	Yes	-
m	Yes	Yes	Yes	Yes	-
o	-	-	Yes	-	-
X	Yes	Yes	Yes	Yes	Yes

The additional characters referred to by the Other column are:

,.;+-=!/?%/\$

Any characters that are not formatting characters are interpreted as literals and displayed without their having to be present in the underlying data. For example, a template of “(000) 000-0000” will allow entry of US standard telephone numbers without the user having to enter the punctuation and without those characters being stored in each string.


- The *Max Length* property may be used as an alternative to the *Template* property to allow free-form entry to a maximum number of characters. Note that the format length and the underlying data length are independent values, but that the former should not typically be larger than the latter.

# Chapter 7 Using Colors

Numeric tags can have one of various so-called colorings selected, while flag and string tags have their colors fixed to Two-State and General, respectively. Each coloring will take a data value and convert to a foreground and background color pair.

## Types of Coloring

The following colorings are supported:




- The *General* coloring always returns white on black.
- The *Linked* coloring uses the coloring of another tag to format the tag that you are configuring. It is useful for creating templates and then applying them to many tags in the same database. This can avoid repetition, and make it easier to adjust your color settings from a single location. Note that a Linked coloring uses the data from the original tag and applies the rules defined by the linked tag. This means that the original tag will not necessarily be the same color as the linked tag, but rather that its color may depend upon its own data value.
- The *Fixed* coloring always returns a fixed pair of colors.
- The *Two-State* coloring takes a numeric value and picks one of two color pairs based on whether the value is zero or non-zero. This is the permanently defined coloring for flag tags.
- The *Multi-State* coloring takes a numeric value and compares it against a table containing data values and color pairs. Either a color pair associated with a matching data value is selected, or the selector can be configured to use the last color pair with an associated data value not higher than the data.

## General Coloring

The General coloring has no properties.

## Linked Coloring

Linked coloring has the following properties:



- The *Color Like* property is used to select a tag from which the coloring information for this tag is to be obtained. For correct operation, a tag of the correct data type should be used, such that, for example, a numeric tag's coloring should be based upon another numeric tag. Failure to observe this requirement will result in a fallback to the default formatting rules.

## Fixed Coloring

The Fixed coloring has the following properties:

- The *Colors* property defines the colors to be used all the time.

## Two-State Coloring

The Two-State coloring has the following properties:

- The *ON Colors* property defines the colors to be used when the tag is non-zero.
- The *OFF Colors* property defines the colors to be used when the tag is zero.

## Multi-State Coloring

The Multi-State coloring has the following properties:

## Format Control

- The *States* property defines how many states the multi-state selector will contain, up to a maximum of 500 entries. The window displaying the selector will update to show the required number of Data and Text properties.
- The *Default Colors* property defines the colors to be used if the data cannot be matched against the defined states.
- The *Match Type* property defines how the data is compared against the various states. If Discrete is selected, the tag data must match a given state's data value in order for that state to be used. If Ranged is selected, MonicoView 3.1 assumes that the state data values are in increasing numerical order and will use a state value if the tag data is less than or equal to that state's data value but greater than the prior state's data value.

## Format States

- The *Data* and *Colors* properties define the data and color values for each state.

## Color Commands


Multi-state coloring objects also provide options to allow their states and the associated properties to be exported to or imported from Unicode text files. These files can then be edited by an application such as Microsoft Excel. An additional button allows the Data fields of the coloring to be synchronized with the Data fields of a Multi-State format object configured for the same tag, avoiding your having to enter the same values twice.

# Chapter 8 Creating Display Pages

Selecting the Display Pages category in the Navigation Pane gives access to the new MonicoView 3.1 graphics editor. This editor is designed to allow the quick and efficient creation of attractive displays, while also providing the maximum flexibility.

## Editor Basics

The graphics editor is shown below in its initial state:



The Editing Pane shows a representation of the target device, including the display area itself plus any keys and LED icons. At the lowest zoom level, the entire panel will be shown, even if this means allocating less than one pixel on your PC's display for each pixel on the display of the target device. In this situation, pages can still be viewed and most editing can be performed, but accuracy will be somewhat reduced. A warning message is thus displayed.

## Working with Pages

Manipulation of display pages via the Navigation List is intuitive, and operates as for any other item in a MonicoView 3.1 database. That said, it is worth reiterating the fact that pages can be copied between databases by simply selecting them in one database's Navigation Pane and dragging them to the corresponding category in the target database. This makes it very easy to build new databases by combining previously used page designs.

## Changing the Zoom Level


Zooming in and out is most easily performed using the mouse wheel. If you do not have such a mouse, you can use the editor's zoom mode by selecting the magnifying glass from the toolbar. In this mode, left-clicks will zoom in, and either right-clicks or left-clicks with **CTRL** held down will zoom out. You may also use the zoom commands on the View menu.

The first zoom step will take you from the full-panel view to a 1:1 display, centering the target device's display in your editing window. Thereafter, zooming is performed to keep the data under your mouse pointer in view, thereby making it easier to choose which area of the display you wish to examine in more detail.

## The Resource Pane

Display pages are typically built from items dragged from the Resource Pane. You can either slide out the Resource Pane by clicking the arrowed bar to the right-hand side of the window, or you can choose to lock the Resource Pane in place, perhaps maximizing your window to increase your available workspace. The Resource Pane has three categories:

### Primitives



The Primitives category is used to access the key building blocks used to assemble display pages, and is shown to the left in its various states. You will notice that the top-level contains a number of sub-categories, each of which provides access to a number of primitives. Clicking on an icon displays a subcategory and its primitives. Clicking on a given primitive displays versions of that primitive in predefined colors. The icons in the toolbar can be used to move between sub-categories, to move up to a higher level or to change the number of primitives displayed per row. The primitives are described in the next chapter.


### Symbol Library



The Symbol Library category operates in a manner that is very similar to the Primitives category, providing access to a number of sub-categories, each of which contains a number of predefined

symbols. Clicking on a given symbol provides a number of pre-colored versions of that symbol, although this facility is used less often than it is with primitives. Take some time to explore the Symbol Library—it contains many thousands of possible images, and its correct use can produce more attractive and easy-to-use databases.


## Data Tags



The Data Tags category contains a tree view of all the data tags in the current database. It is used both to drag tags directly on to a display page, and to provide access to tags while configuring the primitive properties. Dragging a tag onto a page will create a data box that is bound to that tag, with all the formatting properties based on the properties defined by the tag itself. You may also select and drag multiple tags by using the **SHIFT** and **CTRL** keys in the usual way. These facilities make it very quick and easy to add data to a page.

## Adding Items to a Page


As mentioned above, the various items in the Resource Pane can be dragged onto the editor, thereby adding them to a display page. Suitable primitives will be created for tags and images. The example below shows how, after clicking on the Core Primitives selection in the Primitives category, a rectangle primitive can be dragged onto the page:




## Using the Scratchpad

MonicoView's graphics editor provides a scratchpad area than can be used to store commonly used primitives or to provide a location to park primitives while you are re-organizing a display page. The contents of the scratchpad are stored with the database and will thus be available from one editing session to another. The scratchpad can be enabled or displayed via the Show

Scratchpad option on the View menu, and when enabled, initially appears as a notepad icon in the bottom left-hand corner of the editing pane.



This minimized form of the scratchpad window can be moved to any location, including to a second monitor. This allows you to organize your workspace according to your preferences, and according to the monitor real-estate that you have available. To open the scratchpad, either click on the minimized form, or drag a primitive from your current display page and hover over the notepad icon. The scratchpad will appear in its open form as shown below...



Items placed on the scratchpad can be manipulated in the usual way and can be dragged into the main editor to add them to the current display page. By default, a drag-and-drop action will perform a copy operation, leaving the original primitive on the scratchpad. If you wish to change this, hold down the **SHIFT** key while dragging the primitive.

The scratchpad window will automatically hide itself if you try to access an area of the screen that it would otherwise obscure. In the layout shown above, for example, starting to drag an item from the scratchpad to the main editor will hide the scratchpad so that you have unencumbered access to the part of the page that is covered by the scratchpad window. To display the automatic hiding of the scratchpad, click on the pushpin icon.

## Working with Primitives

The following sections describe how to perform common operations on primitives.

### Selecting the Primitives

To select a display primitive, simply move your mouse pointer over the primitive in question, and perform a left-click. You will notice that while your pointer is hovering over a primitive, a bounding rectangle is drawn in blue to help show what will be selected. When the actual selection is



performed, the rectangle will change to red, and handles will appear, to allow you to resize the primitive as required.

To select several primitives, either drag out a selection rectangle around the primitives you want to select, or select each primitive in turn, holding down the **SHIFT** key to indicate that you want each primitive to be added to the selection. If multiple primitives are selected, the red rectangle will surround all of the primitives, and the handles can then be used to resize the primitives as a group. The relative size and position of the primitives will be maintained, as long as MonicoView 3.1 can do so without violating minimum size requirements.

## Buried Primitives

If you find that the primitive you want to select is hidden below another primitive, press the **CTRL** key to allow the selection to be made. Alternatively, right-click to access the context menu, and choose the Select submenu. This will list the all primitives that are beneath the mouse pointer, ordering them from back to front. Each command will select the corresponding primitive, making it easy to ensure that you have selected the correct element.

## Using the Quick Bar

The Quick Bar is a floating toolbar that appears to the top-right of the current selection:



The bar will at first appear in a faded form, and will become more solid as you move your mouse towards it. Moving away from it will hide the bar, after which it will not reappear until the selection process is repeated, or the scrollwheel button on your mouse is pressed. The Quick Bar allows easy access to a number of commonly-used features while minimizing mouse movement. The bar can be enabled or disabled using a command on the View menu.

## Moving Primitives Between Pages

Primitives can be dragged around a display page in the usual way, but can also be copied from one page to another. To do this, select the primitive you wish to copy and drag it towards the Navigation Pane. If the pane is hidden, hover over the arrowed bar and the pane will slide into view. Hover over the target page, and that page will be selected. Now drag the primitive back into the editor and drop it on the new page. Holding down **CTRL** will change the copy operation to a move.

## Moving Primitives Between Databases

Dragging primitives between databases is just as easy. Simply select the items you wish to copy, and drag them to another copy of MonicoView 3.1 that contains the new database. This will work with entire pages, groups of primitives or just a single item.

## Changing the Size of Primitives


Resizing primitives is performed in the intuitive manner of grabbing one of the sizing handles and moving it in the required direction. The **CTRL** key can be held down to restrict the sizing operation such that the primitive's width and height are equal. The **SHIFT** key can be held down to allow the sizing to operate from the "middle out" rather than from one edge.

## Rotating and Reflecting Primitives


Certain primitives can be rotated in increments of 90° and can be reflected about their horizontal or vertical axes. The settings that control the primitive's orientation can be accessed directly via the primitive's properties dialog box, or can be modified using the commands on the Transform menu. Shortcut keys are also available, with **CTRL+ALT+LEFT** and **CTRL+ALT+RIGHT** rotating the selected primitive in the positive (i.e. counterclockwise) and negative (i.e. clockwise) directions, and with **CTRL+ALT+UP** and **CTRL+ALT+DOWN** reflecting the selected primitive about its vertical and horizontal axes. When a suitable primitive is selected, icons to perform these operations will also appear on the Quick Bar.

## Using Layout Handles

Certain primitives have internal handles that can be moved to change their layout. For example, the rounded rectangle shown below has a single layout handle in its top left-hand corner. The handle is marked with a diamond whenever the primitive is selected:



In this case, moving the handle changes the radius of the rectangle's corners:




The function of each handle depends on the specific primitive, but is usually intuitive.

## Smart Alignment

If you have the Smart Align features of the View menu enabled, MonicoView 3.1 will provide you with guidelines during a move or size operation. These will help align a primitive with existing primitives, or with the center of the display. With a little practice, this feature can make it very easy to align primitives as they are created, without the need to go back and “tweak” your display pages to get the various figures into alignment.


In the example shown below, a circle is being aligned with two squares:



Guidelines are present at both the edges of the figures, showing that both are aligned. The red rectangle is highlighting the primitive that is being manipulated, while the blue rectangles are highlighting the primitives to which the guidelines have been drawn.

## Quick Alignment

MonicoView 3.1's Quick Alignment features allow primitives to be aligned to other primitives without the need to bring up a dialog box. To use this feature, simply select the primitive you want to move, and right-click to bring up the context menu. Select the Align submenu, and then select one of the various "With...Of" options, marked with the rectangle-and-cursor symbol. The mouse pointer will change to indicate that you now need to click on the primitive to which you wish to align.



As soon as you click, the alignment will be performed.


## Using the Grid

The Grid button on the toolbar can be used to control the behavior and the display of the alignment grid. Clicking on the left-hand side of the button will show or hide the grid. Clicking on the drop-down portion will allow the operations for which the grid is used to be configured. You may separately enable or disable the grid for creation, sizing and movement operations, or you may use the All or None options to enable or disable it globally. You may also control whether the grid is used when editing within groups.

## Aligning Primitives

While the Smart Alignment and Quick Alignment options discussed above allow many alignment operations to be performed, there are times that you will want to use a more traditional approach.

To do this, select a number of primitives, and use the Align Selection command on the Arrange menu to display the following dialog box:




The Horizontal and Vertical settings can be used to indicate what type of alignment is to be performed, while the Reference setting defines which primitive is used as the reference for the alignment operation. In the example above, Auto mode will use the left-most primitive as a reference as we are performing a left alignment. Other alignment modes work in a similar way. The alternative mode uses the first selected item as a reference. This item can be identified by the larger square at its center.

## Spacing Primitives

If you have a number of primitives that you wish to space equally on the page, you may use the Space Equally Vertical or Space Equally Horizontal commands on the Arrange menu. The commands work on the currently selected primitives, and attempt to reallocate the free space between the items to achieve equal spacing. The two outer primitives will be left in their current positions. Note that the command may fail if an inappropriate set of primitives are selected, and may not achieve perfect spacing if the available space is too limited.

## Reordering Primitives

Primitives on a display page are stored in what is known as a z-order. This defines the sequence in which the primitives are drawn, and therefore whether or not a given primitive appears to be in front of or behind another. In the first example below, the blue square is at the bottom of the z-order and is thus shown behind the red squares. In the second example, it has been moved to the top of the order and it now appears on top of the other figures.



To move items in the z-order, select the items, and then use the various commands on the Arrange menu. The Move Forward and Move Backward commands move the selection one step in the indicated direction, while the Move To Front and Move To Back commands move the selection to the indicated end of the z-order. Alternatively, if you have a mouse that is equipped with a wheel, the wheel can be used to move the selection by moving the wheel with the **CTRL** key

held down. Scrolling up moves the selection to the back of the z-order; scrolling down moves the selection to the front.

## Duplicating Primitives

The **CTRL+D** key combination or the Smart Duplicate command on the Edit menu can be used to make a copy of the current primitive, adjusting its properties such that the primitive gets its controlling data from the next data item. The definition of “next” depends on the exact type of the data, with MonicoView 3.1 being capable of selecting the next register in a comms device, the next member of an array, or the next tag in a sequence. As an example, repeatedly using Smart Duplicate with a button mapped to `Array[0]` will produce a sequence of buttons mapped to `Array[1]`, `Array[2]` and so on until the whole screen is filled.

## Editing Multiple Primitives


You may on occasion want to edit the properties of multiple primitives. MonicoView 3.1 supports this by having you edit one primitive, and then allowing you to set the properties of a number of other primitives equal to those of the one that you first edited. MonicoView 3.1 provides two methods to do this, both of which rely on the same underlying mechanism.

### Using Copy From

The Copy From command can be used to copy the selected properties of a given primitive to one or more primitives. To use the command, select the required targets, and then right-click to access the associated context menu. Select one of the Copy From commands, and the cursor will change to allow you to select the primitive from which the copy operation should be performed. Depending on the command that was selected, one or more properties from the source will then be applied to the target primitives.

### Using Paste Special

The Paste Special command can be used to achieve the same result, but via a different method that also allows properties to be copied between databases and between multiple instances of MonicoView 3.1. First, select the source primitive and use the Copy command to put it on the Clipboard. Then, select the required target primitives, right-click the selection, and select the Paste Special command. The following dialog box will appear:




The selected properties from the source primitive will be applied to the target primitives.

## Property Selections

Both methods detailed above allow you to define which properties are to be copied:

- *All Formatting* copies everything except any text, data item or action.
- *Text Formatting* copies the font, alignment and margins of text or data items.
- *Fills and Edges* copies the fill and edge attributes from the Figure tab.
- *Action* copies any action assigned to the primitive.


In addition, the *Selective* option can be used to select the properties to copy:



The list contains a hierarchical presentation of the properties defined by the source primitive, organizing them per the layout used when editing the primitive, and showing the value assigned to each. Each property or group of properties can be selected or deselected using the associated checkboxes. The checked properties will be applied, thereby providing you with low-level control of what gets copied from one primitive to another.

## Jumping to Other Items

If a primitive references tags, display pages or other items, a Jump submenu will appear on its context menu. Select this menu to view a list of referenced items. Select one of those items to jump directly to that section of the database. The example below shows a primitive that references two tags:




After you have made whatever changes you want to the tag, you can use the Back button on the toolbar or the **ALT+LEFT** key combination to return to the display page that you were just editing. Note how the selection is preserved during navigation, making it easy to view or edit a referenced object and to then resume the display creation process.

## Primitive Properties

The properties of a primitive can be edited by double-clicking on the primitive, or by using the Properties command on the primitive's context menu. You may also select the primitive and press the **ALT+ENTER** key combination. The property dialog for a primitive will contain various tabs, with some tabs only appearing when additional items—such as text, data or an action—have been added to the primitive. The properties dialog shows a live preview of the current primitive, allowing you to see the effect of changes before you commit them.

## Showing or Hiding Primitives


All primitives have a Show tab in their property dialog:



The *Visible* property can be set to an integer expression to show or hide the associated primitive at runtime. A value of zero will hide the primitive, while any non-zero value will allow it to be shown. All primitives are visible by default.

## Defining Primitive Colors

Colors within primitives are edited using a field similar to that shown below:



You will notice that the color property is presented by means of an arrowed button, a dropdown list and a Pick button. The arrowed button is used to show the list that contains the various color animation modes. It can be activated in the usual way by clicking with the mouse or by pressing the spacebar with the button selected. While the button is selected, you may also press the initial letter of one of the options contained in the list, avoiding the need to show the list at all. For example, pressing 2 will select 2-State mode.


The following color animation modes are available:

- In *Fixed* mode, the color does not change, and is selected from the drop-down list, or by invoking the color selection dialog by pressing the Pick button.
- In *Tag Text* mode, the color is animated to match the foreground color defined by a particular tag. The specific tag can be selected by pressing the Pick button.
- In *Tag Back* mode, the color is animated to match the background color defined by a particular tag. The specific tag can be selected by pressing the Pick button.
- In *Flashing* mode, the color is animated to alternate between two colors at a specific rate, with another color being displayed when flashing is disabled.
- In *2-State* mode, the color is animated to switch between two colors depending on the value of a tag or other data item.
- In *4-State* mode, the color is animated to switch between four colors depending on the value of two tags or other data items.
- In *Blended* mode, the color is animated to transition smoothly from one color to another based upon the value of a tag or other data item relative to specified minimum and maximum values.
- In *Expression* mode, a numeric expression can be entered that will be used to determine the color to be displayed. See below for more details.
- In *Complex* mode, a local program returning an integer value can be written to define the color to be displayed. See below for more details.

The drop-down menu contains the following colors:

- The sixteen standard VGA colors.
- Thirty-two shades of gray between black and white.
- Any other colors used in the database, up to a limit of twenty-four .


The More option at the bottom of the list can be used to invoke the color selection dialog:



This dialog offers several ways of defining a color. You can pick from the palette, pick from the “rainbow” window, or enter the explicit HSL or RGB parameters. If the color selected has not previously been used in the database and is not one of the standard colors or grays, it will be added to the custom colors shown in the drop-down menu.

## Defining Flashing Colors

Flashing colors are defined via the following dialog box:




- The *Rate* property defines the rate at which the flashing should occur. A value of 1 produces a flashing rate of 1Hz, with each color being displayed for 500ms. It is not recommended to use rates in excess of 4Hz, as the target device’s display update rate may produce unpleasant “beating” effects.
- The *Enable* property defines an optional expression that can be used to enable or disable flashing. The Steady Color will be displayed when flashing is disabled.
- The *Color* properties allow you to define the colors to be used.

## Defining 2-State Colors

2-State colors are defined via the following dialog box:






- The *Value* property is used to select the color to be displayed.
- The *Color* properties allow you to define the colors to be used.

## Defining 4-State Colors


4-State colors are defined via the following dialog box:



- The *Value* properties are used to select the color to be displayed.
- The *Color* properties allow you to define the colors to be used.

## Defining Blended Colors

Blended colors are defined via the following dialog box:



- The *Value*, *Minimum* and *Maximum* properties are used to define the color to be displayed. In the example shown, the color will blue when the tag is at or below its minimum value, red when it is at or above its maximum value, and will transition smoothly from blue to red as the tag changes between its limits.
- The *Color* properties allow you to define the colors to be used.

## Defining Tank Fills

Many geometric primitives support a so-called “tank fill” option whereby the figure is filled to a given level based upon the contents of a tag. This feature can be used to implement simple bar graphs or to fill more complex shapes.

The example below shows a six-pointed star with a bottom-up tank fill set to 60%.




Tank fills are defined using a primitive's Fill Behavior properties::

- The *Fill Mode* property defines whether a tank fill should be drawn, and from which direction the fill should occur. Fills can occur from any edge of the primitive, allowing complex animations to be created. Block mode results in the figure being filled with a single pattern, disabling tank fills.
- The *Value* property selects the value used to calculate the level of the fill. If a tag is entered, the Minimum and Maximum limits will automatically be set to the data entry limits of that tag using the tag property expression syntax. The Value property may be an integer or a floating-point value. The fill level calculations are always performed in floating point.
- The *Minimum* and *Maximum* values define the limits to be used when scaling the Value property to calculate the fill level.

## Defining Fill Formats

A primitive's Fill Format properties define how the inside of the primitive will be filled:

- The *Pattern* property selects between various fill patterns. The default option is Solid Color, but a variety of dithered, hatched patterns may also be selected. In addition, a texture may be selected to create a realistic looking representation of a real-world object. The picture below shows some of the available textures:




- Several graduated fills are also available:

PATTERN	DESCRIPTION
Graduated Fill 1	Color 1 at the top and bottom of the primitive, changing vertically to Color 2 at the center.
Graduated Fill 2	Color 1 at the top of the primitive, changing vertically to Color 2 at the bottom.
Graduated Fill 3	Color 1 at the left and right of the primitive, changing horizontally to Color 2 at the middle.
Graduated Fill 4	Color 1 at the left of the primitive, changing horizontally to Color 2 at the right.
Shiny and Chrome	A metallic effect using the two specified colors, allowing you to ride eternal.
Horz Cylinder	An effect that models a horizontally oriented cylinder of Color 1 with a highlight of Color 2.
Vert Cylinder	An effect that models a vertically oriented cylinder of Color 1 with a highlight of Color 2.

- The *Color 1* property defines the first color to be used for the fill.
- The *Color 2* property defines an optional second color to be used for the fill.
- The *Color 3* property defines the background color for a tank fill. It is not required if a block fill is being used. The property may not be present if the current primitive does not support tank fills.

## Defining Edge Formats

A primitive's Edge Format properties define how the edge of the primitive will be drawn:




- The *Width* property defines how wide the edge will be, with a value of zero disabling the edge completely. While legacy primitives have a limited number of edge sizes available, newer primitives support arbitrary widths up to 80 pixels.
- The *Pattern* property defines how the edge will be filled. While legacy primitives required the edge to be of a solid color, newer primitives allow edges to be drawn using graduated fills, patterns or textures. The settings are analogous to those defined above for a primitive's Fill Format.
- The *Color 1* property defines the first color to be used for the edge.
- The *Color 2* property defines an optional second color to be used for the edge.
- The *Edge Mode* property defines where the edge is placed relative to the boundary of the filled portion of the figure. Edges may be placed inside or outside a figure, or may be drawn such they are centered on the figure's boundary. This setting has a subtle impact on how tank fills are processed, and on the position of the edge relative to the primitive's bounding box. It is only available for edge widths of three pixels or greater. Thinner edges are automatically positioned.
- The *Join Mode* property defines how the edge will be drawn on the outside of each corner of a figure. Bevel mode will flatten off the corners, while miter mode will extend each edge to create a point— although miters that extend too far will be clipped to avoid unattractive results. Rounded mode will round-off the corners with a radius equal to the edge width. The illustration below shows a triangle with a 10-pixel edge drawn in each of the three modes.



## Defining Edge Trim


A primitive's Edge Trim properties allow an option line to be drawn on each side of the edge:



- The *Trim Width* property specifies the width of the trim. The default value of zero disables the trim. Trim is often used when a richly styled edge is applied, such as one that uses a texture. A trim line on the outside of the edge better delineates the edge, allowing it to stand out against the background.
- The *Trim Edges* property specifies which side of the edge the trim should be applied to. It may either be applied to the inner or outer edge, or to both.
- The *Trim Color* property specifies the color of the trim.

## Legacy Edge Formats


For legacy primitives, a simpler Edge Format is supported:



- The *Width* property specifies the thickness of the edge. The edge may be displayed by selecting a value of None. For legacy primitives, MonicoView 3.1 supports only odd edge sizes, up to nine pixels in width.
- The *Color* property defines the color of the edge.
- The *Corners* property is only present for rectangles, and defines whether rounded or square corners should be used when drawing the edge. All other primitives use rounded corners by default.

## Recoloring Symbols

When a symbol is added to a page by dragging it from the Symbols section of the Resource Pane, a special primitive is created to hold the resulting image. This Simple image primitive supports all the image adjustment features described in the next chapter. It also supports image recoloring, allowing the existing colors within the symbol to be replaced with a solid color or a graduated fill. Recoloring is configured via the Shade Format properties on the Shading tab of the Simple Image primitive.




- The *Shading*, *Color 1*, *Color 2* and *Color 3* properties are as described above.
- The *Include* property defines how MonicoView 3.1 should apply the new color. If Alpha Channel is selected, the new color is applied to any pixels that are not fully transparent, removing any internal detail within the symbol. This is most often used with symbols from the Basic Shapes category. The other settings select one or more of the red, green and blue channels that encode the colors of each pixel that makes up the symbol. The



## Nested Group Editing

MonicoView 3.1 also allows editing within groups that are themselves within groups:



To activate this feature, begin editing within the outer group, select the inner group and then click on a member of that inner group. Note in the example above how a series of fading rectangles are used to show the group hierarchy. Note also how items outside the current groups are shown in faded colors to make highlight where the group ends. When using the **ESC** key to exit nested group editing, each press of the key will move up one level.

## Expanding Groups


As mentioned above, movement of primitives during group editing is limited such that you cannot move a primitive outside the group to which it belongs. In situations where you want to make adjustments to primitives at the edge of a group, you may select the Expand and Edit command from the group's context menu. This will move the group boundaries out from the primitives, allowing such adjustments to be made. When group editing mode is canceled, the group boundary will be moved inwards to tightly surround its contents.

## Adding Movement to Primitives

Any primitive can be animated such that it moves dynamically within a bounding rectangle that you define. Primitives can be moved horizontally, vertically or in both dimensions, or they can be moved according to polar coordinates such that they orbit a point at a variable distance. In each case, each dimension is defined by a control value and a pair of limits.

To apply movement, select the required primitive or primitives, and choose one of the Add Movement commands from the Behavior menu. A red rectangle will appear around the primitives, representing the movement group in which the animation will take place. The group can be resized to change the extent of animation, but unlike a regular group, resizing a movement group does not change the size of the primitives themselves. The group contents can be edited just as with standard groups, using the techniques detailed above. When polar movement is being edited, an ellipse will show the path that the primitives will follow when the radius is set to 100%. Note that this will always be smaller than the group itself, as it represents the position of the center of the items that are being animated, and space must be left to ensure that they do not extend beyond the group boundary.


To define how the movement is controlled, open the properties of the movement group:



The example above shows the configuration of 2D movement. Polar movement is configured in a similar way. For each dimension of movement, the *Position* value defines where the contents of the group will be placed relative to its outline. The *Minimum* and *Maximum* values represent the limits of the control values. For 2D movement, the minimum settings result in the group contents being displayed in the top left corner.


## Adding Text to Primitives

Most primitives within MonicoView 3.1 can support the addition of text. To add text to a primitive, simply select the primitive, press F2 and begin typing. Alternatively, you can right-click the primitive and select the Add Text command from the resulting menu. The example below shows text being entered into a rounded rectangle:



Note first how the bounding rectangle for the primitive is shown in yellow, and how all the other primitives on the page are faded out. Note also how the text editor automatically splits the text across lines. Try resizing a primitive containing text, and you will see how MonicoView 3.1 automatically adjusts the text to fit into the new shape.

During text editing, the toolbar changes to provide commands to modify the text alignment, and to grow or shrink the spacing between lines. The more advanced text properties can be editing by either selecting Text Properties from a primitive's context menu, or by pressing **ALT+ENTER** while in text editing mode:




## Text Properties

- The *Text* property contains the text to be displayed. Vertical bar characters are used to encode hard line breaks. Since this field is a translatable string, multilingual versions can be edited. This also implies that the property can be set to an expression, allowing its contents to change dynamically. MonicoView 3.1 supports full dynamic re-flow, allowing complex and attractive presentation options.
- The *Text Font* property allows the required font to be selected. MonicoView 3.1's new default font is Hei, a Unicode font that provides support for simplified Chinese and most other languages. The Pick button can be used to invoke the font selection dialog, allowing any font that is installed on your system to be rendered in a form that can be used by the target device. Note that it is your responsibility to ensure that you are licensed for this kind of font usage.
- The *Horizontal* property defines the horizontal alignment of the text.
- The *Vertical* property defines the vertical alignment of the text.
- The *Line Spacing* property defines additional line spacing in pixels.
- The *Text Color* property selects the color of the text.
- The *Drop Shadow* property is used enable an optional shadow to the right and to the bottom of the text itself. This effect is useful when trying to make text stand out from its background, especially if the background is an image that contains a combination of many colors.



## More Properties




- The *Text Margin* properties are used to control the margin around the text relative to the text-bounding box provided by the primitive. This can be useful if you want to reposition the text within the primitive, or in achieving better visual centering when working with fonts that have lots of space above or below their characters, either for diacritical marks or descenders.
- The *Direction* property defines the direction in which the text will be moved when the associated primitive is pressed. It is only enabled when an action is assigned to the primitive, or when the primitive is something like a button that has an inherent action associated with it. This option is useful when creating custom buttons that should provide feedback when touched.
- The *Step* property indicates how far the text should move when the primitive is pressed. One to three pixels can be chosen, according to the effect desired.

## Adding Data to Primitives

Primitives which support the addition of text also support the display of live data, and can optionally be configured for data entry. To add data to a primitive, right-click the primitive and select the Add Data command from the resulting menu. Alternatively, select the primitive and press the **CTRL+F2** key combination. The primitive's properties dialog will be displayed, with a number of additional tabs being available to define the data item and its behavior.


## Data Properties



- The *Value* property defines the data value to be displayed.

- The *Contents* property defines whether the field should display the data value, the data value and its associated label, or just the label alone.
- The *Layout* property defines how the selected data should be formatted. A setting of Single Line places everything on a single line, overflowing the available space if the text is too large. A setting of Multiple Lines breaks the text into several lines if this is necessary to accommodate in the primitive. In this mode, the label is always placed on a separate line from the associated data.
- The *Operation* property defines whether the field should just display the value or also provide data entry functionality. Data entry is obviously only available if the selected data value is writable.
- The *Get from Tag* properties define whether certain properties of the data field are defined locally or are linked to the properties of the tag being displayed. The options are only available when a tag is specified in Value.
- The *Text Font* property allows the required font to be selected. MonicoView 3.1's new default font is Hei. This is a Unicode font that provides support for simplified Chinese and most other languages. The Pick button can be used to invoke the font selection dialog, allowing any font that is installed on your system to be rendered in a form that can be used by the target device. Note that it is your responsibility to ensure that you are licensed for this kind of font usage.
- The *Horizontal* property defines the horizontal alignment of the text.
- The *Vertical* property defines the vertical alignment of the text.
- The *Line Spacing* property defines how many extra pixels should be inserted between lines when working in the Multiple Lines layout mode.


## More Properties



- The *Text Margin* properties are used to control the margin around the text relative to the text-bounding box provided by the primitive. This can be useful if you want to reposition the text within the primitive, or in achieving better visual centering when working with fonts that have lots of space above or below their characters, either for diacritical marks or descenders.
- The *Direction* property defines the direction in which the text will be moved when the associated primitive is pressed. It is only enabled when an action is assigned to the primitive, or when the primitive is something like a button that has an inherent action associated with it. This option is useful when creating custom buttons that should provide feedback when touched.
- The *Step* property indicates how far the text should move when the primitive is pressed. One to three pixels can be chosen, according to the effect desired.


## Entry Properties

These properties are only available when data entry is enabled:




- The *Enable* property is used to provide an expression to enable or disable data entry. Disabled data entry fields will act just like display-only fields.
- The *Validate* property is used to define an expression that will be used to validate any entered values. The expression should evaluate to non-zero to allow entry, or zero to block it. For example, entering `Data%25==0` will only allow multiples of 25 to be entered, as these are the only values for which reducing to modulus 25 will result in a zero value. During the execution of this expression, the special system variable `Data` will hold the newly-entered value.
- The *Remote* property enables or disables the ability to control data input remotely via the web server.
- The *On Selected* property specifies an action to be executed when the user presses on the data entry field, just before data entry begins.
- The *On Deselected* property specifies an action to be executed when data entry ends, either as a result of a value being written, a page change or the user pressing a button to cancel the entry process.
- The *On Entry Complete* property specifies an action to be executed when data entry is successfully completed.
- The *On Entry Error* property specifies an action to be executed when the user enters an invalid value.
- The *Title* property field can be used to enter a title that will appear the top of the entry keypad when activated.
- The *Status Bar* property field can be used to enter a comment or information that will appear the bottom of the entry keypad when activated.

## Format Properties



- The *Label* property defines the label to be applied to this field. It may not be available if the label is not to be displayed, or if the field is configured to get its label from the controlling tag.
- The *Format Type* field specifies the format type to be used when displaying and optionally editing the data value. Again, the selection may not be available if the format is being obtained from the controlling tag.
- Other properties are specific to the data format that has been selected. Refer to the chapter on Using Formats for details of each format's properties.

## Color Properties




- The *Color Type* field specifies the coloring to be used when displaying the data value. The selection may not be available if the coloring is being obtained from the controlling tag.
- The *Text Color* property is used to override the color of the text if the General coloring is being used.
- The *Drop Shadow* property is used to enable an optional shadow to the right and to the bottom of the text itself. This effect is useful when trying to make text stand out from its background, especially if the background is an image that contains many colors. It is only available with the General coloring.

- Other properties are specific to the coloring that has been selected. Refer to the chapter on Using Colorings for details of each coloring's properties.

## Adding Actions to Primitives

Primitives that do not perform their own implicit action support the addition of customized actions to be performed when the operator presses or releases the touchscreen. An action can be added by selecting the Add Action command from the primitive's context menu, or by selecting the primitive and pressing the **CTRL+I** key combination.

An Action tab will be added to the primitive's properties dialog:



## Protecting Actions

An action's Protection property can be used to prevent an action from being invoked accidentally. This facility operates in addition to any protection provided by the Security System and is invoked before the associated actions are begun. The following protection modes are available:


- *Confirmed* mode displays a popup to confirm the action, and then performs the action immediately if the user indicates that the action should proceed.
- *Locked* mode displays a popup stating that the action is locked. If the user indicates that the action should proceed, it becomes unlocked, and they must activate the action again for it to actually take place. Selecting another action will lock the previous action, as will waiting beyond the global timeout.
- *Hard Locked* mode operates as for Locked mode, except that the action will relock once it has been performed and must be unlocked each time.

## Enabling Actions

If you want to make a particular action dependent on some condition being true, enter an expression for that condition in the *Enable* field. This expression may reference a flag tag directly, or may use any of the comparison or logical operators defined in the Writing Expressions section. If you need more complex logic such that one of several actions is performed based on more complex decision-making, configure the key for User Defined mode, and use it to invoke a program that implements the required logic. You can also use the *Remote* property to block access to this action from the web server.

## The Goto Page Action


This action is used to instruct the target device to show a new page:



- The *Target Page* property is used to indicate which page should be displayed. In addition to the pages contained in the database, you have the option of selecting either Previous Page or Next Page to navigate within the page history list. The New button may be used to create a new page without leaving the dialog.
- The *Show As* property is used to indicate how the page should be displayed. A selection of Normal Page will cause the page to be selected in the usual manner, while the Simple Popup option will cause the primitives on the new page to be displayed in a rectangular popup on top of the current page, replacing any existing popups. A setting of Nested Popup will also display the page as popup, but will display the new page on top of any existing popup. Popup Menu is a legacy setting for devices with soft-keys down the left-hand side of the display. MonicoView 3.1 does not support any such devices at the time of writing. A popup can be closed by executing the `HidePopup()` function or by selecting the Hide Popup or Hide All Popups for an action's Operation property.

## The User Defined Action

This action is used to perform one or more user-defined actions:




- The *On Pressed* property defines the action to be performed when the primitive is pressed. This action may invoke any of the functions in the Function Reference or the data modification operators described in the Writing Actions chapter. It may also run a program to perform a more complex action.
- The *On Auto-Repeat* property defines the action to be performed when the primitive is pressed and then held down. The action occurs both on the initial depression and on subsequent auto-repeats, so there is no need to define both this property and On Pressed. This action may invoke any of the functions from the Function Reference or the data modification operators described in the Writing Actions section, or it may run a program.

- The *On Released* property defines the action to be performed when the primitive is released. This action may invoke any of the functions from the Function Reference or the data modification operators described in the Writing Actions section, or it may run a program.

In the example above, a user-defined action is used to implement a momentary pushbutton.

## The Push Button Action

This action is used to emulate a pushbutton:



- The *Button Type* property selects the desired behavior:


BUTTON TYPE	PRIMITIVE BEHAVIOR
Toggle	Change the data state when the primitive is pressed.
NO Momentary	Set the data to 1 when the primitive is pressed. Set the data to 0 when the primitive is released.
NC Momentary	Set the data to 0 when the primitive is pressed. Set the data to 1 when the primitive is released.
Turn On	Set the data to 1 when the primitive is pressed.
Turn Off	Set the data to 0 when the primitive is pressed.

- The *Button Data* property defines the data to be changed by the key.
- The *Hold Time* property is used for momentary buttons to ensure that the data associated with the pressed state is written for at least a specified amount of time, even if the button is pushed and immediately released. It can be used to ensure that the remote device sees the button activation in circumstances where MonicoView 3.1's transactional writes are insufficient or have been disabled. It is generally bad practice to rely on this property as it must be tuned to allow for the comms delays present in the system.

In the example above, touching the primitive will toggle the value of the `Output` tag.

## The Change Value Action

This action is used to write a numeric value to a data item:




- The *Write To* property defines the data item to be changed.
- The *Data* property defines the data to be written.

In the example above, touching the primitive will set the *Data* tag to 250. Note that this action supports either floating point or integer values. The *Data* property must be of a type appropriate for the data item defined by the *Write To* property.

## The Ramp Value Action

This action is used to increase or decrease a data item. The options are shown below:




- The *Write To* property defines the data item to be changed.
- The *Data* property defines the step by which to raise or lower the item.
- The *Limit* property defines the minimum or maximum data value.
- The *Ramp Mode* property defines whether to raise or lower the item.

In the example above, pressing and holding down the primitive will repeatedly increase the *Data* tag by 5 until it reaches 500. Note that this action supports either floating point or integer values. The *Data* and *Limit* properties must be of a type appropriate for the data item defined by *Write To* property.



## The Play Tune Action

This action plays a selected tune using the target device's internal sounder.



- *Tune Name* selects the tune to be played.

Customized tunes may be played using the `PlayRTTTL()` function.

## The Log On User Action

This action activates the log-on screen on the target device. It has no options.

## The Log Off User Action

This action logs off the current user of the target device. It has no options.

## The Hide Popup Action


This action hides a page that has been displayed as a popup, allowing the underlying page or, in the case of a nested popup, the previously displayed popup, to be seen once more. If no popup is displayed, the action has no effect.

## The Hide All Popups Action

This action hides any pages that have been displayed as popups or nested popups, allowing the underlying page to be seen once more. If only a single popup is present, it is equivalent to the Hide Popup action. If no popup is displayed, the action has no effect.

## Adding Actions to Icons

Certain devices support added actions to the LED icons present above or below the device's display. Zoom out until you can see the icons, and then double-click to bring up its properties:




You will notice that this dialog contains two tabs, both of which define an action. The first tab defines the action that will be performed by this icon when the current page is displayed, while the second tab defines an action to be performed on every page. These are known as the local and global actions, respectively. Once you have defined an action, you can right-click on the icon and use the resulting menu to select either Make Global or Make Local to change the action type. These options will not be available if both actions have already been defined.

Refer to the section later in this chapter for information on controlling the associated LEDs.

## Editing Page Properties


Right-clicking in the Editing Pane away from any primitives activates the context menu and allows selection of the Properties commands to edit a display page's properties:

### General Properties



- The *Label* and *Description* properties define general purpose translatable strings that can be accessed elsewhere using MonicoView 3.1's property extraction syntax. See the chapter on Writing Expressions for more details.
- The *Master Slide* property allows the selection of another page that will be used as a background for the current page. This allows common user interface elements such as clocks, alarm status indicators and so on to be drawn on a single page and then included on several other pages.
- The *Fill Color* property defines the background color of the page, assuming that a master slide has not been used. You should avoid animating the background color, as changes will require the hardware to redraw of all items on the page, with a potential impact on performance.
- The *Update Rate* property defines the page's update rate. The overdrive setting should not be used in normal circumstances. The default setting is currently equivalent to the standard setting.
- The *Timeout* properties define timeout behavior. If a period of time equal to Period passes without user activity, the On Timeout action will be executed. Refer to the Writing Actions chapter for details of the possible actions.
- The *Clear GotoPrevious Buffer* property indicates that the history buffer maintained by `GotoPrevious()` and `GotoNext()` should be cleared when this page is selected. You would typically set this property on the main menu page of your database, removing the ability to go back beyond that point.


## More Properties



- The Links property group specifies the pages to be selected by various standard actions on a display page. The *Parent Page* property defines a page to be selected if the timeout occurs and no action is defined. The *Next Page* property defines a page to be selected if input navigation is enabled and the focus is moved beyond the last field on the page. The *Previous Page* property defines a page to be selected if the focus is similarly moved beyond the first field.
- The *Auto Initiate* property is used to indicate whether the data entry keypad should automatically be displayed as soon as the page is selected, provided enabled entry fields exist. If this mode is disabled, an active data entry field must be touched to display the keypad.

- The *Entry Order* property is used to select how the next and previous buttons on the keypad should navigate between fields. Fields may be selected in rows and then in columns, or in columns and then in rows.
- The *Position* property allows the globally defined position of popup windows to be overridden for this page. If local settings are enabled, the *Horizontal* and *Vertical* properties are used to specify the position.
- The *Master Slide* property is used to indicate whether the master slide should be kept active while a popup is displayed. The default setting of enabled allows buttons on the master slide to function, even though buttons on the actual page will be disabled while a popup is present. This can be useful if you want global navigation options on the master slide to always be available.

## Action Properties



- The *On Select* property defines an action to be run when the page is displayed.
- The *On Remove* property defines an action to be run when the page is deselected.
- The *On Tick* property defines an action to be run once per second.
- The *On Update* property defines an action to be run on each display update.

## Security Properties


Refer to the Using Security chapter for details on security descriptors.

## User Interface Settings

Selecting the root item in the Navigation List will access the user interface settings.

## Global Properties

The Global tab contains various general settings that apply across the database:



## Global Actions

- The *On Power Up* property defines an action to be run when the system starts.
- The *On Startup* property defines an action to be run slightly later.<sup>1</sup>
- The *On Tick* property defines an action to be run once per second.
- The *On Update* property defines an action to be run on each display update.

Note that these actions are run in the context of the user interface task. This means that user responsiveness will be prejudiced if the actions take too long to run, and that conversely, certain user interface activities, especially those associated with the security system, may cause the actions to be deferred. You should not use these actions to perform time-sensitive control activities. Refer to the section on IEC-61131 control for alternatives that might be more suitable.

## Global Timeouts

- The *Keypad Timeout* property defines the period of time without user action after which any data entry operations will be canceled and the associated popup keypad removed from the display.
- The *Backlight Timeout* property defines the period of time without user action after which the display backlight will be turned off to conserve power and display life. The default value of zero disables this feature.
- The *Relock Timeout* property defines the period of time after which any actions protected via the Locked or Hard Locked methods will relock automatically, such that the user will once again have to unlock them before they can be used.

## Popup Position

- The *Horizontal* and *Vertical* properties define the default position for popup display pages and popup keypads. They can be overridden at the page level if desired by using the page's own properties to specify new values.

## Diagnostics

- The *Show GMCs* property is used to enable or disable the display of certain diagnostic information after a runtime system fault. The information is useful in correcting software problems, but may be distracting to users.

## Languages


- The *Configure Translation* button is used to configure the languages to be used within the system. Refer to the chapter on Localization for more information.

---

<sup>1</sup> The difference between these two properties is subtle and not of concern to most users.

## Entry Properties

The Entry tab contains global settings that apply to data entry:



### Keypad Options

- The *Keypad Size* property is used to select the size of the data entry keypad. The various settings progressively increase the size of the keypad, with a setting of Maximum causing the keypad to take up most of the screen for use in situations where, for example, operators are wearing unwieldy gloves.
- The *Keypad Layout* property is used to select between the default keyboard layout and specialist layouts for different languages. This release of MonicoView 3.1 supports specialized keyboards for French and Hebrew.
- The *Input Navigation* property is used to show or hide the **NEXT** and **PREVIOUS** keys in the various popup keypads. These keys can be used to move between entry fields without first deactivating the keypad.
- The *Auto Initiate* property is used to indicate whether the data entry keypad should automatically be displayed as soon as the page is selected, provided enabled entry fields exist. If this mode is disabled, an active data entry field must be touched to display the keypad.
- The *Entry Order* property is used to select how the next and previous buttons on the keypad should navigate between fields. Fields may be selected in rows and then in columns, or in columns and then in rows.
- The *Numeric Keypad* option is used to control the appearance of the keypad used for numeric entry, and specifically whether ramping is enabled in addition to or instead of traditional entry.

### Data Entry Mode


- The *Multi Data Entry* property is used to control the data entry mode used for multi-state format objects. Two-stage editing results in the ENTER key having to be pressed to commit any changes, while single-stage editing results in the new data being written to the associated data item as soon as **RAISE** or **LOWER** is used to make a change. Single-stage entry is faster, but may result in the writing of intermediate values when changing a multi-state setting.
- The *Flag Data Entry* property is used to control the data entry mode used for two-state format objects. It operates in the same way as the property above.

### Miscellaneous

- The *Activate Beeper* property is used to turn the target device's beeper on or off, as desired. The beeper provides feedback as to keyboard and touchscreen activation, but can become annoying during the development process.

## Images Properties

The Images tab is used to manage images within the database:



### Images


- The *Include Data* property indicates whether external images dragged into a display page should be stored as pointers to the source location, or whether the actual image data should be included in the database file. Including image data will typically make the database very large, and may make it impossible to use the Support Upload feature without filling the memory of the target device.
- The *Stored Paths* property defines how image links are stored. Absolute mode stores the full path, including the drive letter. The two relative modes store and interpret image paths relative to either the database or the MonicoView 3.1 image directory, allowing database and image files to be moved between machines without too much worry about absolute path locations.
- The *Image Directory* property defines the image path referenced above.
- The *CF Directory* property is used to specify where MonicoView 3.1 can find copies of the images that will be stored on a target device's memory card. The memory card image primitive uses this path when previewing images.

### Maintenance

- The *Manage Image Database* button is used to invoke the Image Manager in order to view and manipulate the images used in the database. See the section below for more information on this facility.

## Fonts Properties

The Fonts tab is used to manage fonts within the database:




## Maintenance

- The *Manage Font Database* button is used to invoke the Font Manager in order to view and manipulate the fonts used in the database. See the section below for more information on this facility.

## Icons Properties

The Icons tab is used to set properties of the icon LEDs on those HMIs that provide them:




- The *Alarm LED* property is used to set whether the left-hand or alarm LED will be controlled by the system or whether it will be free for user control. The default behavior is that flashing red indicates the presence of an active and unaccepted alarm, and solid red indicates the presence of accepted alarms.
- The *Orb LED* property is used to set whether the central or orb LED will be controlled by the system or whether it will be free for user control. The default behavior is that the LED will show flashing blue to indicate boot code loading into a unit, and will flicker during memory card access.
- The *Home LED* property is used to set whether the right-hand or home LED will be controlled by the system controlled by the system or whether it will be free for user control. The default behavior is that solid green indicates power on.

Refer to the “Adding Actions to Icons” section earlier in this chapter for information on adding actions to the LEDs on those devices which support touch-sensitive annunciators.

## Managing Images

The Image Manager is invoked from the Images tab of the user interface settings. It contains a list of the images referenced in the database, together with their properties. It allows you to view the images, and to perform certain changes to how the images are stored and used.

The sample below shows the Images Manager from a complex database:





The main list view shows the properties of the various images:

- The *Source* column indicates whether the image is being obtained from a file via either a fixed or a relative path, from the Symbol Library, or from internal data stored when an image was pasted or dragged from another source.
- The *Name* column shows the filename for images stored in files, and the relevant symbol information for images sourced from the Symbol Library.
- The *Type* column shows the file type of the image data.
- The *Used* column indicates whether the image is used in the database.
- The *Valid* column indicates whether valid image data is available. This column may be set to No if an image was being sourced from a disk file that is no longer available, and if the database is not config-ured to hold its own image data via the Include Data property described above.
- The *Disk* column indicates whether the image exists on disk. Images that were pasted or dragged directly into the editor may never have existed on disk, and images sourced from files but also stored within the database itself may now be missing if the file is no longer available.


The toolbar at the top of the window allows various commands to be performed:

- The *Export* command saves an image that is available but not stored on disk to a file. If a filename has already been defined for the selected image, that name will be used. In other cases, you will be prompted to select a filename.
- The *Replace* command allows you to replace a given image with another. All references to the image in the database will be updated to reflect the change.
- The *Export All* command saves all images that are available but not stored on disk and that have file-names defined. It can be used to ensure that all images are stored in external files prior to turning off Include Data.
- The *Purge Unused* command is used to remove all images that are not used in the database, thereby saving disk space when saving the database to disk. Use of this command may also reduce memory usage in the target device.

## Managing Fonts

The Font Manager is invoked from the Fonts tab of the user interface settings. It contains a list of all the fonts referenced in the database, together with their properties. It allows you to view the fonts, and to perform certain changes to how the fonts are stored and used.

The sample below shows the Font Manager from a complex database:




The main list view shows the properties of the various fonts:

- The *Face* property shows the name of the font.
- The *Size* property shows the height in pixels of the font.
- The *Weight* property indicates whether the font is bold or not.
- The *Type* property indicates whether the font is a system or custom font.
- The *Used* property indicates whether the font is used in the database.
- The *Options* property lists the options selected for the font.

The toolbar at the top of the window allows various commands to be performed:

- The *Edit* button allows the properties of custom fonts to be edited.
- The *Delete* button allows an unused font to be deleted. Once a font is deleted, it will no longer be presented in the drop-down used for font selection, but may be recreated by using the associated Pick button.
- The *Replace* button allows a font to be replaced with another. All references to the font in the database will be updated to reflect the change.
- The *Show System* button controls whether system fonts are shown in the list.
- The *Purge Unused* button removes all unused fonts from the database, thereby reducing the amount of memory used in the target device. As with a deleted font, purged fonts will no longer be presented in the drop-down list used for font selection, but may be recreated by using the associated Pick button.

Editing the properties of a custom font produces the following dialog box:



The various options allow specific sets of characters to be included in the font image that is created and downloaded to the target device. Restricting the characters to the ones that are needed for your application will save memory, especially with larger fonts. Note that the Numeric Output option can be used alone to restrict the font to digits, decimal points and those other characters used to render conventional, scientific or hexadecimal numbers.

## Advanced Topics

This section describes advanced techniques that are typically not required by most users.

### Defining Color Expressions

As mentioned above, color properties can be defined via integer expressions or via local programs returning integer values. These mechanisms are used in those circumstances where the standard color animation methods are not sufficient.

MonicoView 3.1 works with 15-bit color constants, with the lowest five bits representing the red, the next five bits representing the green and the upper five bits representing the blue. (Note that this is true even with device's that support richer sets of colors. Those additional colors are used for graduated fills, symbols and pictures, but cannot be selected for color settings and constants.) You can manipulate color values just as you would any other integer value.

### Building Colors

The `ColGetRGB(r,g,b)` function can be used to create a color value from its red, green and blue components. Although MonicoView 3.1 uses 15-bit color values containing three 5bit values, the arguments passed to this function are internally scaled down by a factor of 8 and should thus be in the range 0 to 255. `ColGetRGB(128, 0, 64)` will therefore return a purple-like color with a red value of 16, no green component and a blue value of 8.

### Splitting Colors

The `ColGetRed(rgb)`, `ColGetGreen(rgb)` and `ColGetBlue(rgb)` functions can be used to access the individual color components of a color value. In keeping with the convention used by `ColGetRGB()`, the values returned by these functions are scaled to be between 0 and 255.

### Choosing Colors

The `ColPick2()` function can be used to select between two colors based on the value of an expression. For example, the expression `ColPick2(Flag1, Col1, Col2)` will return `Col1` if `Flag1` is non-zero, or `Col2` if `Flag1` is zero. The first and second color arguments can be replaced by calls to the `ColGetRGB()` function if required.

### Blending Colors

The `ColBlend()` function can be used to produce a color that is a user-defined blend of two other colors. For example, the expression `ColBlend(Data, 0, 100, Col1, Col2)` will return `Col1` if `Data` is 0 and `Col2` if `Data` is 100. Intermediate values will be appropriate mixtures of the two colors, allowing a smooth transition from one color to another. Once again, the color arguments can be replaced by calls to the `ColGetRGB()` function.

### Responding to Touch

The `IsPressed` system variable is equal to true if the current primitive has been touched and is otherwise false. It can be used with the color selection functions to animate a primitive per its touch status. Note that primitives will not be enabled for touch unless they have an action defined or they support an inherent action.




# Chapter 9 Primitive Types

This chapter describes each of the primitives provided by MonicoView 3.1.

## Core Primitives

### Geometric Primitives



The geometric primitives represent simple shapes. They include rectangles, full and partial ellipses, rectangles with rounded or trimmed corners, polygons, stars, arrows, parallelograms and trapeziums. All these primitives support tank fills, and can therefore be used to implement effects such as bar graphs. They also support the addition of text or data, and can therefore be used to create text or data displays, or to provide data entry. Finally, they support the addition of actions, and can therefore be used to implement interactive display elements.

### Basic Properties

All geometric primitives have properties that control their basic appearance in terms of fills, edges and edge trim. These properties can be used to create a broad range of effects, and you should experiment with the various settings to get a feel for what can be achieved. Refer to the previous chapter for these standard settings. While the geometric primitives are very simple, their support for tank fills, data, text and actions means that a large portion of most databases can in fact be created by using just the rectangle or the rounded rectangle.

### Other Properties

Certain geometric primitives offer additional configuration options:


- Rectangles with rounded or trimmed corners have a *Skip Corners* property that allows the corner effect to be omitted for specific corners.
- Polygons have a *Rotation* property that allows the orientation of the polygon to be adjusted within the bounding rectangle. Note that the polygon is always scaled to fill the rectangle and the rotation applied accordingly.
- Stars likewise have a *Rotation* property, but also have an *Inner Radius* property that allows the pointedness of the star to be adjusted. The behavior is difficult to explain but easy to see in practice!
- Arrows, triangles, parallelograms and trapeziums have *Direction* and *Reflection* properties that allow the figures to be rotated and reflected via either these properties or the Transform menu in the graphics editor.
- Partial ellipse primitives likewise have the transformation properties, but also have a *Show Edges* property which defines whether the edge will be drawn around just the arc, or around the arc and the straight edges.

### The Line Primitive



The line primitive is used to place a line on the page. The MonicoView 3.1 line primitive supports a rich variety of settings, including textured and graduated fills, line edging and edge trim, and selectable end styles to allow the creation of arrows and other figures.

## Line Properties



- The *Width* property specifies the width of the line from 1 to 80 pixels.
- The *Pattern* property specifies the pattern to be used to fill the line. The available options are identical to those offered for fills and edges, so refer to the previous chapter for information on the various settings.
- The *Color 1* and *Color 2* properties select the colors for the selected pattern.
- The *End 1 Style* and *End 2 Style* properties define the effects to be applied to each end of the line. A flat endcap ends exactly at the end of the line, while a square endcap extends beyond the end of the line by an amount equal to the width of the line. The rounded and pointed endcaps should be self-explanatory, as should the various arrowheads and other shapes that are available.

## Edge Properties

Refer to the previous chapter for information on edges and edge trim.

## Text and Data Primitives



The text box and data box primitives are rectangles with predefined data and text items, and with no fill or edge colors defined. They exist to make it easier to add data and text elements, and to provide comfort to those users who are not used to being able to construct an entire database from simple geometric primitives! They can also be used to add a second data or text element to a primitive or when constructing a group. Refer to the previous chapter for details of the standard settings.


## The Image Primitive



The image primitive is used to display an image, possibly chosen from several images based upon a numeric value. The primitive supports the display of bitmaps, JPEGs, metafiles, bitmaps and many other image types. It can operate with a transparent or filled background, and can optionally

define an edge to go around the image. It also supports the addition of data, text or actions, thereby allowing more complex elements to be constructed.

The Image tab for an animated image primitive is shown below:




- The *Image Count* property defines the number of image slots that are defined for this primitive. One of the images will be chosen for display at any given time, based upon the value of the *Image Select* property.
- The *Image Select* property selects the desired image. It is taken as a zero-based value and is reduced modulo the *Image Count*. In other words, if four images are defined, values of 0, 4, 8 etc. will display the first image, values of 1, 5, 9 etc. will display the second image and so on.
- The *Use Color* property is used to either reduce an image to black-and-white or to preserve its color. An expression that evaluates to a non-zero value or an empty expression will result in a color image. A zero value will reduce the image to grayscale using standard r-g-b brightness weightings. This option is useful when showing the disabled state of an image on a button.
- The *Show Image* property is used to show or hide the image. If the primitive has no edge or fill defined, it is functionally equivalent to the *Show Item* property, but will otherwise still display the edge or background as per the configuration.
- The *Show Item* property is used to show or hide the entire primitive.

## Defining Images

The *Images* section of the dialog box defines the images for each slot. The *Pick* button next to each image will display a dialog box reminding you that you can simply drag an image onto the field. This image can be dragged from the Symbol Library category in the Resource Pane, from a folder in Windows Explorer or from any other drag-and-drop capable application. The *Browse* button can be used to open a file containing a suitable image format and to load that file into this image slot. As mentioned above, JPEGs, metafiles, bitmaps and many other graphical file formats are supported.

## Adjusting Images

The Adjust button next to the image can be used to modify the image:




The various sliders can be used to pan, zoom and spin the image, while the checkboxes can be used to mirror it horizontally or vertically. The Show Center checkbox shows or hides the blue lines that mark the center of the image, while the Reset button can be used to restore the image to its original state. The manipulation options are sometimes used to modify an image to create various states for use in animation.

## The Bevel Primitive

The bevel primitive displays a rectangle with a raised or sunken border. The face color may be changed, as may the colors used for the highlighted and shadowed portions. You may also change the color and width of the lines within the primitive, or remove them entirely. Finally, a layout handle may be used to adjust the width of the beveled portions.


## Figure Properties



- The *Pattern*, *Color 1* and *Color 2* properties define the color of the face of the primitive in the usual way. Refer to the previous chapter for more details.
- The *Style* properties controls whether the bevel will be raised or sunken. This effect is achieved simply by switching the highlight and shadow colors.
- The *Highlight* and *Shadow* properties define the two colors to be used to create the 3D effect applies to the outside of the primitive.



## Line Properties




- The line properties are conventional, except to note that setting the *Width* to zero will remove all dividing lines. Refer to the previous chapter for details.

## The Button Primitives




The button primitives implement beveled or graduated buttons. Text is preconfigured to allow the button to be labeled, but can be removed to allow the addition of live data. An action tab is also provided by default, but will be disabled if data entry is configured, as button with data entry fields use the button press to activate editing.

The primitive-specific property tab for a beveled button is shown below:



Refer to the previous chapter for details of the standard settings.

The primitive-specific property tab for a graduated button is shown below:



Refer to the previous chapter for details of the standard settings.

## Gauge Primitives

MonicoView 3.1 supports a wide range of linear and radial gauges that can be used to display process variables in an intuitive and easy-to-read format. All the gauges have similar behavior and similar configuration properties. Gauges do not themselves display data in textual form, but text and data boxes can be added to augment the display.

### Gauge Concepts


The following sections describe various concepts that apply to all gauges.

#### Types

Radial gauges display a value by means of a rotating pointer or a radially-swept band:



Linear gauges display a value by means of a moving line or a colored bar:



#### Bugs

Bugs are triangular markers shown on the outside of the gauge's scale. They are used to indicate set-points or other important values. Each gauge can support up to two bugs, with the color and position being dynamically adjustable via tags. The picture below shows a single green bug on a radial and linear gauge:



#### Bands

Bands are radial or linear regions drawn outside the gauge's scale. Bands indicate important operating ranges. For example, a green band might indicate the target range for a process variable, while a red band might indicate an area where operation should be avoided. Each gauge can support up to two bands, with the color and position being dynamically adjustable via tags. The picture below shows a green band on a radial and linear gauge:



## Styles

Gauges can be created in various styles, with each style applying pre-defined colors to the gauge's elements. A custom style can be used to manually specify each color, allowing a broad range of visual themes to be created. The picture below shows a radial gauge in each of the five pre-defined styles:



## Naked Gauges


A naked gauge is a gauge that displays only the pointer, scale, bugs and bands. It does not display the bezel or even the background against which the pointer moves. Naked gauges are created by selecting the Naked style on the Style page. They can be used to create gauges with custom bezels or to combine several gauges within a single figure. The picture below shows three naked linear gauges on top of a rounded rectangle:



## Gauge Properties

All gauges have similar properties.


## Format Properties



- The *Value* property specifies the value that is to be displayed by the gauge, while the *Minimum* and *Maximum* properties specify the range that the gauge's scale is to cover. The range is used both to scale the *Value* property, and to determine the position of any bugs and bands.


- The *Major Color* and *Minor Color* properties specify the colors to be used for the major and minor divisions of the scale. These properties can be animated, allowing the scale to show important changes in process state.
- The *Major Divisions* and *Minor Divisions* properties control how the scale is to be divided. Note that the divisions are applied without reference to the minimum and maximum values. Setting *Minor Divisions* to one will result in only major division being shown. MonicoView 3.1's sub-pixel graphics engine ensures that even large numbers of divisions can be shown clearly.
- The *Display Mode* property selects between pointer and swept operation. See the examples at the start of this section for an illustration of each mode for both linear and radial gauges.
- The *Display Color* property controls the color of the pointer or the band. Note again that this property can be animated, drawing attention to important changes in process state.
- The *Pointer Style* property defines the how the outer end of a radial pointer or both ends of a linear pointer will be drawn. The property is not used when operating in swept mode.

## Layout Properties for Radial Gauges




- The Scaling properties allow the radial size of each element of the gauges to be adjusted to achieve a different visual result, or to make room for additional text or data boxes. The impact of each value is best experienced by making changes and viewing the results in the primitive's properties dialog box.

## Layout Properties for Linear Gauges




- The Margin properties allow the margin around the active area of the gauge to be adjusted to make room for additional text or data boxes. For example, increasing the bottom margin will allow a label to be placed below the scale.

## Style Properties




- The *Rotation* and *Reflection* properties allow the gauge to be transformed to achieve different orientations and directions of pointer movement. The properties may also be accessed via the Transform menu or via the icons that will appear in the primitive's Quick Bar. The Arbitrary rotation setting enables the second Rotation property to allow a value other than a multiple of 90° to be selected. Gauges rotated by an arbitrary angle will still be constrained to fit in their bounding rectangle. This may produce counter-intuitive results which should become clearer as you experiment.
- The *Gauge Style* property selects from one of the predefined styles, or allows custom colors to be selected. The property also allows naked mode to be selected, as described previously in this section.
- The Custom properties allow the colors assigned to various elements of the gauge's bezel to be modified. Many weird and wonderful results can be achieved by adjusting the various settings.

## Band Properties



- The *Band Enabled* property enables or disables the associated band.
- The *Band Color* property selects the required color for the band. Note that this color can be animated, drawing attention to changes in process state.
- The *Band Start* and *Band End* properties select the region to be spanned by the band. The values are relative to the *Minimum* and *Maximum* properties defined on the gauge's Format page.

## Bug Properties



- The *Bug Enabled* property enables or disables the associated bug.
- The *Bug Color* property selects the required color for the bug. Note that this color can be animated, drawing attention to changes in process state.
- The *Bug Position* property defines the location of the bug. The value is relative to the *Minimum* and *Maximum* properties defined on the gauge's *Format* page.

## Bar and Line Graphs




Bar graphs display one or more values from an array as a series of horizontal bars. Scatter graphics allow up to four associated sets of x and y values to be plotted, with optional data markers and a connecting line. They also provide the ability to add a regression line that shows the best-fit linear relationship associated with each data set.

### The Bar Graph Primitives

Bar graphs are available in both horizontal and vertical forms.

### Option Properties




- The *Value* property defines an array element as the source of the data to be displayed. The element will be used for the first bar. A total of *Count* elements will be displayed, with subsequent array elements being used for each.
- The *Minimum* and *Maximum* properties define the lower and upper limits of the display range. Bars beyond these ranges will be clipped.
- The *Fill Format* property group defines the color to be used for the bars.

## Figure Properties

The figure properties control the background of the graph and are conventional.


## Scatter Graph Properties

### Line Properties



- The *X Values* and *Y Values* properties define array elements as the source of the first data point to be plotted. A total of *Count* elements will be displayed, with subsequent array elements being used for each. If *Count* is set to zero, the data set will not be displayed.
- The *Graph Style* property defines whether data markers will be drawn, and whether lines will be used to connect the data point.
- The *Marker Color* and *Line Color* properties define the colors to be used to plot the respective elements.
- The *Regression Line* property defines whether MonicoView 3.1 should calculate the linear relationship that best fits the set of points, and draws a line to show this relationship. The *Line Color* property allows the line color to be selected.

### Option Properties



- The *Style* property controls which set or sets of grid lines will be enabled.
- The *Y Axis Grid Lines* property group controls how the horizontal grid lines will be drawn and laid out. The system uses an automatic algorithm to determine the best way to place the lines based upon the minimum and maximum values of Line 1. The *Layout Font* and *Limit Values* properties correspond to those of the legacy scale primitive, such

that matching those settings will allow a scale placed next to the scatter graph to align with the associated grid lines.

- The X Axis Grid Lines property group controls how the vertical grid lines will be drawn and laid out. The system uses an automatic algorithm to determine the best way to place the lines based on the number of points shown for Line 1 and the minimum spacing specified by the *Layout Width* property.


## Figure Properties

The figure properties control the background of the graph and are conventional.


## Action Buttons



Actions buttons use preselected images from the Symbol Library to create a button that will perform a given action when it is pushed. Many versions are provided beyond those shown above. Clicking on a given button in the Resource Pane will show the different color variants that are available. For example, the square button is available in red, green or black:



When using an action button, you will primarily use the Action tab of the properties dialog to define an action as per the description in the previous chapter. The Button tab can also be used to adjust the button images, or to define your own versions:



## Illuminated Buttons




Illuminated buttons use preselected images from the Symbol Library to create a button that will control a tag, and light up based either upon the state of that tag or the state of another expression. Many versions are provided beyond those shown above. Clicking on a given button in the Resource Pane will show the different color variants that are available. For example, the candy button shown below is available in red, green, yellow, blue or grey:





The primitive-specific property tab for these primitives is shown below:



- The *Operation* property selects the required behavior:

OPERATION	BUTTON BEHAVIOR
Toggle	Change the data state when the primitive is pressed.
Latching	If the data is 0, set it to 1 when the button is pressed. If the data is 1, set it to 0 when the button is released.
NO Momentary	Set the data to 1 when the primitive is pressed. Set the data to 0 when the primitive is released.
NC Momentary	Set the data to 0 when the primitive is pressed. Set the data to 1 when the primitive is released.
Turn On	Set the data to 1 when the primitive is pressed.
Turn Off	Set the data to 0 when the primitive is pressed.

- Note that Latching is slightly different from Toggle in respect of the point at which a non-zero control value is set back to zero. Toggle makes all changes when the button is pressed, while Latching turns a value off when it is released. This produces a result more in keeping with the behavior of a real-world pushbutton.
- The *Control* property defines the value to be written when the button is pressed or released. This value must be writable, and will be set to one or zero depending on the exact operation defined for the button.
- The *Status* property is used to control the illumination of the button. If it is left blank, it will default to the Control value. A different value can be used if more complex logic is required.
- The *Hold Time* property is used for momentary pushbuttons to ensure that the data associated with the pressed state is written for at least a specified amount of time, even if the button is pushed and immediately released. It can be used to ensure that

the remote device sees the button activation in circumstances where MonicoView 3.1's transactional writes are insufficient or have been disabled. It is generally bad practice to rely on this property as it must be tuned to allow for the comms delays present in the system.

Refer to the previous chapter for details of the *Protection*, *Enable* and *Remote* properties.

Refer to earlier in this chapter for details of how to change or adjust the button images.


## Indicators



Indicators use preselected images from the Symbol Library to show the on/off status of a data value. Many versions are provided beyond those shown above. Clicking on a given button in the Resource Pane will show the different color variants that are available. For example, the pilot indicator shown above is available in red, green, yellow, blue or white:



Indicators have a very simple set of properties:



The *Status* property controls the images to be drawn. All other properties are standard.


## 2-State Toggles



2-State Toggles use preselected images from the Symbol Library to implement toggle switches with up and down positions. Many versions are provided beyond those shown above. Clicking on a given toggle in the Resource Pane will show the different color variants that are available. For example, the paddle switch is available in red, green or black:




## Switch Properties



- The *Actions* property controls the behavior of the switch. The three automatic modes model conventional or biased toggle switches, while User-Defined mode allows you to specify more complex actions that will occur when either half of the toggle switch is pressed or released.
- The *Value* property is used in the automatic modes and will be written to the data values associated with States A and B as the switch is changed. By default, State A is represented by a zero and State B by a one, but these values can be changed using the advanced settings for this primitive.
- The *Divisions* property defines whether the switch is thrown vertically or horizontally, and therefore how MonicoView 3.1 should divide the primitive when interpreting touches by the user.
- The *Hold Time* property is used for biased switches to ensure that the data associated with the pressed state is written for at least a specified amount of time, even if the switch is thrown and immediately released. It can be used to ensure that the remote device sees the switch activation in circumstances where MonicoView 3.1's transactional writes are insufficient or have been disabled. It is generally bad practice to rely on this property as it must be tuned to allow for the comms delays present in the system.

Refer to the previous chapter for details of the *Protection*, *Enable* and *Remote* properties. Refer to earlier in this chapter for details of how change or adjust the switch images.

## Advanced Properties



- The *Value A* and *Value B* properties define the data values used in the automatic modes to represent the states of the switch. The value read from the Value property will be compared to these two values to decide which state to display, and changing the switch will similarly write the appropriate value.
- The *Default* property selects the state to be displayed if the data read from the Value property does not match either Value A or Value B.
- The *On Pressed* and *On Released* properties define custom behaviors to be carried out when the A and B portions of the switch are pressed or released by the user. For a vertical switch, A is the bottom half and B is the top half. For a horizontal switch, A is the left half and B is the right half.


## 3-State Toggles



3-State Toggles use preselected images from the Symbol Library to implement toggle switches with up, center and down positions. Other versions are provided beyond those shown above. Clicking on a given toggle in the Resource Pane will show the different color variants that are available. For example, the paddle switch is available in three colors:



## Switch Properties




- The **Actions** property controls the behavior of the switch. The four automatic modes model conventional or biased toggle switches, while User-Defined mode allows you to specify more complex actions that will occur when either half of the toggle switch is pressed or released. Note that the switch can only be moved one position at a time, so moving from State A to State C will necessarily mean moving through State B, as would occur with a physical toggle switch.
- The **Value** property is used in the automatic modes and will be written to the data values associated with States A, B or C as the switch is changed. By default, State A is represented by a zero, State B by a one and State C by a two, but these values can be changed using the advanced settings for this primitive.
- The **Divisions** property is used to define whether the switch is thrown vertically or horizontally, and therefore how MonicoView 3.1 should divide the primitive when interpreting touches by the user..
- The **Hold Time** property is used for biased switches to ensure that the data associated with the pressed state is written for at least a specified amount of time, even if the switch is thrown and immediately released. It can be used to ensure that the remote device sees the switch activation in circumstances where MonicoView 3.1's transactional writes are insufficient or have been disabled. It is generally bad practice to rely on this property as it must be tuned to allow for the comms delays present in the system.

Refer to the previous chapter for details of the *Protection*, *Enable*, *Remote* properties.

Refer to earlier in this chapter for details on how to change or adjust the switch images.

## Advanced Properties



- The **Value A**, **Value B** and **Value C** properties define the data values used in the automatic modes to represent the three states of the switch. The value read from the

Value property will be compared to these values to decide which state to display, and changing the switch will write the appropriate value.

- The *Default* property selects the state to be displayed if the data read from the Value property does not match Value A, Value B or Value C.
- The *On Pressed* and *On Released* properties define custom behaviors to be carried out when the A and C portions of the switch are pressed or released by the user. For a vertical switch, A is the bottom half and C is the top half. For a horizontal switch, A is the left half and C is the right half.

## 2-State Selectors



2-State Selectors use preselected images from the Symbol Library to implement rotary selector switches with two states. Their behavior is identical to Two-State Toggles, and they are implemented using the same primitive.

## 3-State Selectors




3-State Selectors use preselected images from the Symbol Library to implement rotary selector switches with three states. Their behavior is identical to Three-State Toggles, and they are implemented using the same primitive.

## System Primitives

### Viewer Format

Most system primitives display or manipulate data created or accessed by MonicoView 3.1. Each viewer consists of a viewing area with a number of buttons beneath. The appearance of the list-based viewers is controlled via the Format tab of the properties dialog:




Colors and fonts are specified in the conventional way. The Buttons section allows some of buttons at the bottom of the viewer to be disabled, and allows their labels to be edited or translated for international applications. Remember that translatable strings can be set to expressions, implying that the label on a button can be customized at runtime.

## The Alarm Viewer

The Alarm Viewer is used to display and optionally accept alarms within the system.

### Option Properties



- The *Show Alarm Time* property is used to indicate whether each alarm should be prefixed with the time and date at which it occurred. The exact time format to be used is specified on the Time tab.
- The *Show End Markers* property is used to indicate whether markers should be included in the list to flag the first and last items, thereby making it easier for the user to know when they are at either end of the list.
- The *Show Numbers* property is used to indicate whether the alarm numbers should be included, and if so, how many digits should be displayed.
- The *Sort Alarms By* property is used to indicate how the alarms should be ordered in the viewer. Alarms can be shown oldest first or newest first. Note that the system's ability to detect the time at which an alarm becomes active is a function of the communication scan time and the alarm task scan time.
- The *Auto Scroll Timeout* is used to define the period after which the cursor will return to the top of the list, allowing the list to once more scroll automatically to show new alarms. Set the property to zero to disable the timeout.
- The *Colors* property group specifies the text colors to be used when showing alarms in different states. The Active state can either be represented by a single color or by various colors that represent the alarm priorities. The *Use Priority Colors* property selects between the two modes. The "No Active Alarms" message supports a dedicated background color, while the other states always use the background of the primitive itself.
- The *When Inactive* property defines the string that is displayed by the primitive when no alarms are active. This option is typically used to provide localized text when creating multi-lingual applications.

### Actions Properties

If the Help button at the bottom of the viewer is enabled via the Format tab, the *On Help* property on the Actions tab can be used to define an action to be executed when the button is pressed. While the action is being executed, the following system variables contain information about the currently selected alarm:

VARIABLE	CONTENTS
Data	A packed representation of the tag number and alarm number, with the tag number in the low word and the alarm number in the high word. This variable exists solely for compatibility with earlier software released.
t	The index of the tag associated with the alarm. The tag number for a tag is displayed at the top right-hand side of the Editing Pane when a tag is selected, right next to the Up and Down buttons used to move between tags.
i	The array element associated with the alarm if the alarm is sourced from a tag array, or zero otherwise. As you will recall, arrays can have alarms that are applied to the first 256 elements of the array, numbered from 0 to 255.
a	The alarm number of the alarm, this being 0 for Alarm 1 and 1 for Alarm 2.

## Time Properties

The Time tab defines the format to be used when indicating the time and date at which an alarm occurred. Refer to the chapter on Using Formats for detailed information.


## Color Properties

The Priority Colors tab defines the colors to be applied to each alarm priority. This feature will only be enabled if the Use *Priority Colors* property has been selected on the Options tab.

## The Alarm Ticker

The Alarm Ticker is used to display a scrolling summary of the active alarms in the system. It is typically placed along the bottom edge of the display page, perhaps on a master slide so that it will always be visible.

## Options Properties



- The *Show Alarm Count* property controls whether the number of active alarms should be displayed as part of the ticker.
- The *Show Alarm Time* property controls whether the activation time of each alarm should be displayed as the ticker scrolls through the alarms.
- The *Colors* property group specifies the text colors to be used when showing alarms in different states. The Active state can either be represented by a single color or by various colors that represent the alarm priorities. The *Use Priority Colors* property selects between the two modes.
- The *Show No Active Alarms Text* property is used to configure whether the primitive will display a message when there are no active alarms present in the system, or whether an empty bar will be displayed instead.



- The *No Active Alarms Text* property is used to configure the text to be displayed when no active alarms are present in the database. It can be translated to ensure that appropriate versions are available in each language.
- The *Enable Blinking* and *Blink Accepted Alarms* properties control whether active alarms will blink when they are displayed, and whether this blinking will also be extended to active alarms that have been accepted. The *Blink Rate* property controls how quickly this blinking will occur.
- The *Alarm Transition* property controls how long MonicoView 3.1 will display each alarm before moving on to the next alarm in the active list. The default value of two seconds is reasonable for most applications.

Note that it is common to add an action to the alarm ticker to allow the user to switch to a page that shows the full alarm viewer. Alternatively, a popup page may be used to achieve the same result. Refer to the previous chapter for information on adding actions.

## The Event Viewer

The Event Viewer is used to view and optionally clear the events logged by the system in response to alarms or events generated by data tags.

### Options Properties



- The *Show Event Time* property is used to indicate whether each event should be prefixed with the time and date at which it occurred. The exact time format to be used is specified on the Time tab.
- The *Show End Markers* property is used to indicate whether markers should be included in the list to flag the first and last items, thereby making it easier for the user to know when they are at either end of the list.
- The *Show Numbers* property is used to indicate whether the event numbers should be included, and if so, how many digits should be displayed.
- The *Show Event Type* property is used to indicate whether each entry should be marked to indicate whether it is an alarm occurrence, acceptance or clearance, or whether it represents a simple event. If alarms are in use, failing to enable this setting can produce rather confusing displays.
- The *Auto Scroll Timeout* is used to define the period after which the cursor will return to the top of the list, allowing the list to once more scroll automatically to show new events. Set the property to zero to disable the timeout.
- The *When Empty* property defines the string that is displayed by the primitive when no events are present in the log. This option is typically used to provide localized text when creating multi-lingual applications.

## Enables Properties

If the Clear button at the bottom of the viewer is enabled via the Format tab, the Enable Clear property is used to enable or disable the clearing of the event log.


## Time Properties

The Time tab specifies the format to be used when indicating the time and date at which an event occurred. Refer to the chapter on Using Formats for more details.

## File Viewer

The File Viewer is used to allow the user to view text files on the memory card.


## Options Properties



- The *Root Directory* property specifies the directory to be displayed.
- The *Line Numbers* property is used to show or hide line numbers on the file.
- The *Sort Order* property is used to indicate how files should be accessed.
- The *File Types* property group is used indicate the types of file that should be made available for viewing. Note that only text files can be displayed.
- The *Messages* property group defines and perhaps translates various messages used by the file viewer.

## User Manager

The User Manager is used to allow the changing of passwords at runtime:




Its core properties are contained on a single tab, and all are conventional.

## Trend Viewer

The trend viewer allows the display of information from the Data Logger.

### Options Properties



- The **Data Log** property selects the data log to be displayed.
- The **Data Display** property is used to select the display mode. Trend Lines will display the log contents as lines plotted against time while Trend Lines with Fill will also fill the area below the lines. The fills are drawn before the trend lines, such that the lines will be visible on top of the filled areas.
- The **View Width** property is used to indicate the initial amount of data to be shown across the window. The user can subsequently zoom in and out using the buttons at the bottom of the viewer.
- The **Pen Weight** property is used to define the thickness of the lines to be drawn by the viewer. The weights are nominally in quarter pixel increments, with a weight of four representing a single pixel. Fraction widths are implemented using standard anti-aliasing techniques.
- The **Pen Mask** property is used to provide a 32-bit integer value to selectively enable or disable the trend line for specific channels. Bit 0 corresponds to the first channel of the data log, bit 1 to the second and so on. A bit value of one shows the channel while a value of zero hides it. A blank entry provides the default behavior, with all channels being displayed.
- The **Fill Mask** property is used to provide a 32-bit integer value to selectively enable or disable the below-the-line fill for specific channels. Bit 0 corresponds to the first channel of the data log, bit 1 to the second and so on. A bit value of one shows the channel while a value of zero hides it. A blank entry provides the default behavior, with all channels being displayed.
- The **Show Values** property enables or disables the display of the data values associated with each channel of the data log, either during live mode or when scrolling back and forth using the cursor.
- The **Show Cursor** property is used to enable or disable the display of a cursor on the viewer. The cursor can be activated by the user to allow a specific point in time to be precisely determined, and optionally to allow the associated historical data values to be displayed.

- The *Time Axis* property defines whether gridlines should be displayed for the time axis. The pitch of the gridlines is automatically determined by MonicoView 3.1 based on the amount of time covered by the viewer.
- The *Data Axis* property is used to control the display of gridlines for the data axis. Gridlines may be defined manually by specifying either just major divisions or both major and minor divisions, or may be defined automatically by specifying minimum and maximum values for the data axis and letting MonicoView 3.1 calculate the best gridline pattern.
- The *Major Divisions* and *Minor Divisions* properties define the number of divisions to be drawn when using manually-defined gridlines.
- The *Minimum* and *Maximum* properties are used to indicate the range of data to be displayed when using automatic gridlines. MonicoView 3.1 will use these values to determine the best gridline pattern to adopt. Data values will also be scaled to these values, as opposed to being scaled to their own data limits.
- The *Limit Values* property specifies how the top and bottom values of the scale are determined. If a setting of *Precise* is specified, the *Minimum* and *Maximum* values will be used exactly, even if this produces limits that do not exactly correspond to the automatically selected tick spacing. This can produce irregular gridline spacing. A setting of *Rounded* allows the scale primitive to adjust the limits to achieve regularly spaced tick marks.

## Format Properties

These properties are used to specify colors and fonts. Their operation is conventional.


## Buttons Properties

These properties are used to edit and optionally translate the various button labels.

## Time Properties


The Time tab is used to format the time used when providing time and date information relating to the data log. Refer to the chapter on Using Formats for detailed information.

## Pen Properties



These properties are used to specify sixteen colors that will be used for drawing the trend lines. The colors are used cyclically, such that the seventeenth channel will return to the color of the first. Note that drawing so many channels can produce a confusing display.


## Fill Properties



These properties are used to specify sixteen colors that will be used for filling below the trend lines. The colors are used cyclically, such that the seventeenth channel will return to the color of the first. Note that drawing so many channels can produce a confusing display.

## Touch Calibration

The Touch Calibration primitive is used to calibrate the touch-screen:



Its primitive-specific properties define the actions to be taken when calibration has either succeeded or failed. These properties are typically configured to return to a menu screen or to otherwise move away from the calibration page.


## Touch Tester

The Touch Tester primitive allows the user to check the touch-screen performance and calibration. Each touch produces a dot on the screen, with a trail being displayed of the last so-many touches. It has no configurable properties beyond visibility control.

## PDF Viewer

The PDF Viewer primitive is used to display a PDF file stored on the unit's memory card.

## Option Properties




- The *File Name* property is used to specify which PDF file to display. The PDF file must be stored on the unit's memory card in a directory named pdf.
- The *Cannot Load* property defines the text that is displayed when the named file cannot be loaded, either because it is not present or because it contains errors.
- The *Working* property defines the text that is displayed when a file is being loaded and processed for display.

## Camera

The camera primitive is used to allow video from a remote camera to be displayed page.

### Option Properties



- The *Comms Device* sets the source of the video to be displayed in the given primitive. A device must already be mapped to a communications port before this selection can be made.
- *Scale* is used to change the image size coming from the source. Scaling is drive dependent and might not be supported by all camera types.

## Figure Properties

The Figure properties are used to control the primitive appearance and are conventional.

## Legacy Primitives


Legacy primitives are analogous to the newer primitives described above. Except for the vertical scale primitive, they will not be described in detail here.

## Scale Primitive




The scale primitive is used to draw a vertical scale. The limits of the scale can be defined as constants, or can be varied per the value of specific expressions. The scale can be labeled or unlabeled, with any labels being based upon a specified format object which may optionally be obtained from a tag. The scale is designed to operate in the same way as the scatter graph referred to earlier in this chapter, and can therefore be used to label such a graph.

### Data Properties




- The *Value* property defines an optional tag that will be used to obtain limits and format information for the scale. The value itself is not actually used by the primitive, but the tag is used as a source for other pieces of information.
- The *Get From Tag* properties are used to indicate whether a tag selected in the Value property should be used as a source for the data in question.
- The *Show Labels* property is used to show or hide the numeric scale labels.
- The *Show Units* property is used to show or hide the units defined by a numeric data format. The units may be appended to each scale label, or may be drawn vertically by the edge of the scale.
- The *Limit Values* property specifies how the top and bottom values of the scale are determined. If a setting of *Precise* is specified, the limit values will be used exactly, even if this produces limits that do not exactly correspond to the automatically selected tick spacing. This can produce irregular scale labels but will ensure that a tank fill placed next to the scale and bound to the same tag will be drawn exactly as required. A setting of *Rounded* allows the scale primitive to automatically adjust the limits to achieve more regular tick marks.
- The *Limit Positions* property specifies how the limits of the scale relate to the unit labels. A setting of *Aligned* keeps the tick marks and the labels aligned precisely, at the cost of moving the outer tick marks inwards from the edge of the primitive. Choosing a setting of *Shifted* moves the outer two labels relative to the tick marks, but allows the minimum and maximum ticks to line up with the edge of the primitive, making it easier to align with, say, a tank fill.

## Figure Properties




The properties on this page define the colors and fonts used for the scale. Refer to the previous chapter for details of the standard properties. The *Label Shift* property can be used to move the labels up or down relative to the tick marks, producing more attractive results when working with fonts with spacing above or below the character glyphs.

## Limit Properties



The properties on this page are used to set the minimum and maximum values to be shown by the scale. Expressions may be specified, in which case MonicoView 3.1 will dynamically update the scale at runtime, choosing tick marks and label positions appropriate to the new values. These settings are not available if a tag has been chosen as the source of the limit values.

## Format Properties





The *Format Type* field specifies the format type to be used when drawing the labels. Only general or numeric formats are supported. The selection may not be available if the format is being obtained from a tag. Refer to the section on Using Formats for details of the various other properties that are displayed when a numeric data format is selected.




# Chapter 10 Localization

MonicoView 3.1 supports several features that allow you to adapt your database for deployment in multilingual environments. This chapter describes how these features are used, and how you can easily create databases that can be used across the world.

## Selecting Languages

The first stage in creating a multilingual database is to configure the languages to be used within your project. Pressing the Configure Translation button on the Global page of the user interface properties displays the following dialog box:



The top section defines global settings for the translation process:

- The *Method* property specifies how translation is to be performed, and is described in more detail in the following section.
- The *Service* property selects from several supported translation services that MonicoView 3.1 will access to perform auto-translation.
- The *Apply Languages Globally* property instructs MonicoView 3.1 to apply the currently selected language to all operations that use translatable text. As an illustration, consider a multi-state tag with translated state names that is subject to data logging. If this property is checked, the tag's state will be recorded in the log using the currently selected language. If the property is unchecked, the default system language will be used no matter which UI language is selected.
- The *Localize Separators* property instructs MonicoView 3.1 to replace the comma in comma separated variables (CSV) files with a localized version. This is typically a semicolon for languages that use the comma as a decimal separator.

The bottom section of the dialog box defines various properties for each language:

- The *Language* property is used to select the required language. A language may exist in several variations according to the different countries in which it is spoken. The Generic setting may be used for languages that are not directly supported within MonicoView 3.1.
- The *Code* property is used to display or enter the two-character code for the language that has been selected. This property will be passed to the web translation services during automatic translation, and will be used to define the header row in a lexicon file.

You must enter the code manually for Generic languages of which MonicoView 3.1 has no prior knowledge.

- The *Numeric Format* property is used to define whether MonicoView 3.1 will format numbers using US format or using a format specific to the current language selection. Numeric formatting options include the use of commas versus decimal points, and the placement of digit grouping characters.
- The *Diacritical Marks* property is used to override a language's default setting for the treatment of accents on upper case characters. For example, French as used in France (as opposed to Canada) applies accents to upper case characters, which can make these characters harder to render in some fonts. Selecting Lower Case Only for this setting will override this default behavior.
- The *Switch Keyboard* property is used to select the circumstances in which the MonicoView 3.1 configuration software will switch the keyboard layout to that used by the language. The switching can occur when using the translation dialog box, whenever text is being edited in this language, or not at all. Keyboard switching in the translation dialog is enabled by default for languages such as Simplified Chinese, thereby ensuring that the appropriate Input Method Editor is invoked.

## Configuring Auto-Translation

MonicoView 3.1 contains powerful auto-translation features to help you adapt your database for international deployment. The translation process uses two components, namely a system lexicon and a web-based translation service.

The system lexicon is a Unicode text file that contains many standard words and phrases that are used in industrial automation and process control, together with translations in each of a number of common languages. This lexicon can be consulted during the translation process, allowing some text to be translated very quickly and with a high degree of accuracy.

The web-based portion uses one of two services. Google WebAPIs typically provides faster translations, as it is not subject to bandwidth restrictions. In contrast, Microsoft Translator provides slightly more accurate translations, but is not as quick as there is a limit on the number of submissions that can be made per minute. You can select either service from the Configure Translation dialog pictured above.

Auto-translation can be configured to use either or both of these methods. If you have an Internet connection, it is generally better to use first the lexicon and then the web-based service. The lexicon can be used alone in some circumstances to avoid the questionable translations that the web-based services can sometimes provide.


Note that text boxes will not accept more than 1,000 characters. If an English string is close to this limit, its translations may be too long and will not be accepted by MonicoView 3.1. Long translations should be reviewed after auto-translation to assure they completed correctly.

## Translating Your Database

Database translation can be accomplished in a number of ways, as described in the remainder of this section.

## Entering Translations

Manual translation is performed by pressing the Translate button next to each translatable string in the database. A dialog will be displayed, allowing translated text to be entered, or allowing auto-translation to be invoked for this string alone:



This kind of per-string auto-translation allows you to review the translations for accuracy.

## Global Auto-Translation

The Utilities submenu on the File menu contains a command to apply auto-translation to every string in the database. This command may take some time to execute, especially if a bandwidth limited translation service is used. Some care should be taken when using global auto-translation, as strings that are not in the system lexicon may be subject to erroneous translation if they contain technical terms or industry-specific jargon.

## Exporting and Importing

The Utilities submenu also contains commands to export and import text files containing all the translatable text in the database. These files can be edited using an application such as Microsoft Excel, allowing translations to be entered manually. This facility is particularly useful when working with a third-party translation service. The file format includes several columns that indicate the source of each string, allowing distinct occurrences of a given string to be translated into different text according to context.

## Applying a Lexicon

In addition to the system lexicon described above, you may create your own lexicons, either from scratch or by using Export Lexicon command in the Utilities submenu. Lexicon files are Unicode text files that start with a header row containing tab-separated language codes, as used in the Code properties defined in the Configure Translation dialog box. After the header row, each row contains a word or phrase in each of the defined languages.

A sample lexicon file is shown below:

en	fr	de
one	un	eins
two	deux	zwei
three	trois	drei

Note that text should be entered in lower case unless a specific term is only ever used in upper case, such as might be the case with a German noun. The use of lower case allows MonicoView 3.1 to form its own upper case and title case variants.

## Previewing Translations

Translations can be previewed within the graphics editor by selecting the appropriate language from the drop-down menu that is accessed via the flag icon in the toolbar. Any direct editing of text will also apply to the currently selected language, with the other languages being left unchanged. Editing within dialog boxes continues to be restricted to the default language, with the other languages accessed via the Translate button.

## Switching Languages


The language used by the target device is controlled via calls to the `SetLanguage()` function, with the argument of the function being a number between 0 and 19 to select the required option. For example, a call to `SetLanguage(1)` in the example above will select French, while a custom action of `SetLanguage(2)` will select German. The `GetLanguage()` function can be used to determine the current language.

# Chapter 11 Using Widgets


MonicoView 3.1 supports a powerful feature, namely the ability to turn ordinary groups of primitives into powerful entities called widgets. In addition to its component primitives, a widget contains user-definable data items that can be edited at the group level but referenced by the widget's components. This chapter explains how to use widgets.

## Creating a Widget


The easiest way to understand widgets is to create one. Let's start by creating an empty database and adding four numeric tags. Leave the tag properties at their default settings, resulting in four internal integer values named Tag1 through Tag4.




Switch to the Display Pages section and add two data box primitives to the page:




Leave their properties at their default values for now, and select both items. Right-click on the selection, and select the wonderfully-named Widgetize command from the context menu. The items will be bound into a group, but the following dialog box will also appear:




Once the widget has been created, this dialog box will be used to edit the widget's data items, but for now we have nothing defined. Click on the Edit button in the Definitions section to allow us to define some data items:



Clicking on the Edit button next to Count field will let us create two properties:




Complete the data fields as shown above, paying attention to get the data type right, and to modify the Flags fields to indicate that each data item should be a tag. (The flags field can be edited using the Edit button next to the property.) Press OK to close the dialog box, and note how the widget itself now displays data items in its own properties dialog:




Ignore these for now, and press OK to close this dialog, too.

The widget should still be selected in the graphic editor, so click on one of the data boxes contained in the widget to enter group editing mode. Remember, the green rectangle marks the group that we're editing, and the red rectangle shows the selected item in that group:





Double-click on the data box to bring up its properties:




Enter `Data1` in the Value field, and note the results.


MonicoView 3.1 accepts this as a tag name, even though we don't actually have a tag called `Data1` in our database. This value is actually equal to one of the data items defined within the widget, and will represent whatever tag we assign when we go back and edit the widget data. (The value of 25 shown in the preview window is the default value used for widget data items that are not mapped to anything.) Since `Data1` is marked a tag, we can access its properties, use it as a source of formatting, or do anything else that we would do with a tag.

Repeat this step for the second data box, this time setting its Value property to `Data2`.


Press **ESC** until you have the widget alone selected. If you go too far and clear the selection, just click on the widget itself, ensuring that it has a red rectangle round it:




Now bring up the widget properties, and this time enter values for the data items:




Enter the values shown above, setting the data items to `Tag1` and `Tag2` respectively. Note how the preview now shows values of zero, as the data boxes within the widget are now getting their data from `Tag1` and `Tag2` respectively. To make things a bit more interesting, right-click on the widget and access the Jump menu.




Select Tag1 to jump to that tag, and enter a value of 1234 in the Simulate As property. Use the **ALT+LEFT** key combination or the Back button on the toolbar, and note how the widget is continuing to track the tag data:



Next, grab the right handle and make the widget a little wider:



Left-click on the upper of the two data boxes to enter group editing mode, and then right-click on the same box to access its context menu:



Select the Data submenu, and choose the Label and Data command to configure this data box to display the tag's label as well as its value. Note the new appearance of the widget:



As you can see, the data box is displaying the label from Tag1, indicating that the value of `Data1` that we entered into the data box's Value property is entirely equivalent to the tag to which the data item was subsequently configured. We refer to the process of setting a widget item to a tag as binding that data item to that tag. Binding can be performed in more complex ways, as we shall see later.

## Summary

Let us now recap what we did:

- We placed primitives on the display and grouped them into a special kind of group called a widget. The widget appeared to behave like a normal group in terms of editing and so on, but had additional properties.
- We edited the data definitions for the widget, creating two data items. Each was given a name, a description, a data type and a number of flags.
- We used group editing to edit the contents of the widget, setting their properties to the widget's own data items, and referring to them by the data item names.
- We modified the widget's data items, binding them to tags, thereby providing real tags and their associated information to the contents of our widget.

## Why This Matters

So why are widgets important? We could easily have created the data boxes and bound them directly to the tags, so why bother with these extra steps? The answers become obvious when you try to create more complex widgets:

- Widgets allow data items be used in several places, with multiple elements in the widget being dependent on the same tag without your having to select the tag name in multiple places.
- Widgets can encapsulate complex design and functionality, and allow you to replicate and reuse this across or within databases. In effect, they allow complex primitives to be created by the user.
- Widgets can be saved to disk and be added to the Resource Pane, or distributed via email, thereby allowing easier cooperation between MonicoView 3.1 users or between users and Tech Support.

## Down to Details

The next section revisits most of the topics above, but in more detail.

They also explore some of the magic that can be used to make widgets even more powerful.

## Widget Data Definitions

The features that give widgets their power is their data items. The data definition of a widget is edited by opening the widget's properties and by clicking on the Edit button in the Definitions section of the Data page:

Widget Data Definition			
<b>Extent</b>			
Count:	2	<input type="button" value="Edit..."/>	
<b>Definitions</b>			
Name	Description	Data Type	Flags
1: Data1	Data 1	Integer	Tag <input type="button" value="Edit..."/>
2: Data2	Data 2	Integer	Tag <input type="button" value="Edit..."/>
<b>Binding</b>			
Folder Binding:	Disabled		
Required Folder Class:	<input type="text"/>		
Binding Prefix:	<input type="text"/>		
<b>Details</b>			
Details Creation:	Disabled		
Details Widget:	<input type="text"/>		
<input type="button" value="OK"/> <input type="button" value="Cancel"/>			

- The *Extent* property defines how many data items are required for this widget. This value can be changed at any time, but making it smaller will result in data items and their values being lost. Up to eighty data items may be defined.


- The *Name* property of each data item is used to refer to that item from primitives contained within the widget. It must therefore meet all the requirements of a tag name. It must contain no spaces or punctuation, and it must start with a letter.
- The *Description* property for each data item is used to provide a more friendly version of the name, this time for display in the data item editing dialog. No restrictions are placed on the contents of this field.
- The *Data Type* property for each item defines the required data type. The way in which the data item is displayed in the widget's property dialog will depend on the setting that is selected. The real, integer and string data types correspond to expression values, while the color, page and action data types allow more complex items to be created. Page and action items can be treated as display page names and programs from within the widget's primitives.
- The *Flags* property for each data item is used to modify items that have data types of real, integer or string. It supports the following settings:

SETTING	DESCRIPTION
Tag	The value entered for the data item must be a tag. The primitives within the widget can treat the data item as a tag, and access its properties, data format and so on.
Writable	The value entered for the data item must be writable. The primitives within the widget are similarly allowed to write to the data item
Array	The value entered for the data item must be the name of an array. The primitives within the widget will see the data item as an array, and must use the index operator to access individual values.
Element	The value entered for the data item must be an array element. The primitives within the widget will see the data item as an element, and will be able to pass it to functions that require arguments of this type.
No Bind	MonicoView 3.1 will not apply folder binding to this property, allowing it to be used to store predefined values without errors being generated on binding. See later sections for details of folder binding.

- The *Binding* property group is used to control an advanced feature known as folder binding. It is discussed in detail below.
- The *Details* property group is used to control an advanced feature known as details page creation. It is discussed in detail below.


## Filing Widgets

Each widget has a Filing tab in its property dialog:



The *Description* and *Category* properties are used to control how a widget will be displayed on the Resource Pane after it is saved. All widgets of the same category will be grouped together in the same subcategory on the Primitives category, and the widget description will be displayed when the user hovers over an item.


To save a widget, simply select it, and choose Save Widget from the Edit menu or press the **CTRL+Q** key combination. A standard Save dialog will open, allowing you to save the widget as a `wid` file in the MonicoView 3.1 widget directory:



The Resource Pane will update automatically whenever a widget file is added to this directory. This will occur whether the change is made via MonicoView 3.1 or by simply dropping a `wid` file in the directory via Windows Explorer. Note that widget files are stand-alone, and can be transferred between MonicoView 3.1 installations on different machines. This provides a powerful mechanism for sharing user interface elements, or for exchanging items with other engineers when multiple individuals are working on a project.


## Folder Binding

MonicoView 3.1's ability to organize tags in folders allows a kind of object-oriented design whereby tags that represent the properties of an object can be grouped together in a folder that represents the object itself. Consider the example below:



Here, a folder has been created to represent a PID loop, and tags have been created to refer to the loop's process value and setpoint. The tags are referred to in code as `Loop.PV` and `Loop.SP`, using the standard MonicoView 3.1 rules for using nested items.

Folder binding allows you to create a widget that mirrors that object and property structure that you have created in your tags. Consider the following data definition:



Here we have created data items whose names match the names of the tags that make up a PID loop. We have provided human-readable names for them, and we have flagged both data items as being tags. We have also defined the setpoint to be writable. Note at this time that a new property called *Bind To* has appeared for each data item; we shall return to this during a discussion of advanced folder binding.


In the binding section, we have enabled folder binding. This indicates that we want MonicoView 3.1 to support the automatic binding of all the data items to tags from a single source folder. After we save these changes and select the widget's context menu, we will notice a new command called Bind Widget that allows the binding operation to be performed.

Selecting the command or pressing **CTRL+B** displays the following dialog box:



If we drag the Loop folder from the Resource Pane and drop it on the target, the widget's data items will be automatically bound to the corresponding tags in the folder.

Opening the widget's properties shows the results:



In other words, each data item has been bound to the tag within the selected folder that has a name equal to its own data item name. Think for a second about how powerful this is: You can define multiple properties and bind them in a single operation, reducing design time and allowing better reuse of previously designed items.

## Advanced Binding

Folder binding supports a number of advanced options.

### Class Matching

The first and simplest is the *Required Folder Class* setting in the widget's properties. This can be used to restrict the folders that will be accepted during binding, therefore avoiding mismatches between what amount to different object types. The specified class on the widget must match the class on the folder that is being bound, or an error will result.

## Binding Prefixes

The *Binding Prefix* property can be used when nesting widgets to allow the child widgets to be bound to sub-folders of the folder to which the parent widget is bound. For example, suppose you create a dual-loop widget that is to be bound to a folder that contains two PID folders named Loop1 and Loop2. By setting each of the child widget's binding prefix to one of the loop names, you can ensure that they are bound to different child folders of the folder that is dragged on to the parent widget. For example, if the first child widget has a binding prefix of Loop1 and its parent is bound to a folder called Dual, the child widget's properties will be bound to expressions of Dual.Loop1.PV and Dual.Loop1.SP.

## Using Bind To

The *Bind To* property of a data item can be used to modify the expression to which that data item is bound. The simplest option is to enter a name distinct from the name of the data item, in which case that name will be used for selecting the tag to which to bind.

## Using Periods

You may also enter a name that contains periods. These select tags in child folders of the source folder. For example, entering Remote.SP will result in the data item in question being bound to an expression of Loop.Remote.SP upon binding to the Loop folder.

## Using Carets

To ascend the folder tree, you may prefix the name with caret characters, each of which moves up one level. A data item with a Bind To setting of ^Name in a widget that is bound to a Dual.Loop will itself be bound to the expression of Dual.Name.

## Special Name

You may also use one of a number of special *Bind To* names:

NAME	RESULT
::Path	The full path of the tag to which this widget was bound, including any parent folders
::Name	The name of the tag to which this widget was bound, excluding any parent folders.
::TopPath	The full path of the tag to which the root widget was bound in a nested binding operation. Equivalent to ::Path for non-nested binding.
::TopName	The name of the tag to which the root widget was bound in a nested binding operation. Equivalent to ::Name for non-nested binding.

Note that each of these special names evaluates to a string constant equal to the required name and not to the actual tag itself. They are typically used to provide information to the user regarding the folder to which a widget or its root widget have been bound.

## Details Widgets

Suppose you have created a PID widget, but want to display more detailed status information when the user presses a button in that widget. The easy answer is to create a more and perhaps larger complex widget that you would then bind to the same loop. You would place this widget on another page, and then select that page from the original overview widget, perhaps using a data item to tell the widget which page to use.

Well, Details Widget creation performs all these steps automatically!

## Enabling Details Creation

This feature is controlled via the *Details Creation* property of the widget's data definition:

The screenshot shows a configuration panel for a widget. It has two fields: 'Details Creation' with a dropdown menu set to 'Enabled', and 'Details Widget' with a text box containing 'PIDDetails'.

The *Details Widget* property is used to provide a comma-separated list of the one or more details widgets that you would like to place on their own pages. Each widget is specified by giving the filename to which it was saved. In the example above, we have one details widget to be extracted from a file called `PIDDetails.wid` in the MonicoView 3.1 widgets directory.

## Defining Data Items

We must also provide data items in the overview widget so that we can access the names of the pages that are created for the details widgets. These properties must be named `Details1`, `Details2` and so on, with one data item for each element in the Details Widgets list. Each data item must be the Page data type. In the example below, we have created a single such property to hold the page name of our single details page:


The screenshot shows a 'Widget Data Definition' dialog box. It has several sections: 'Extent' with a 'Count' of 3; 'Definitions' with a table of three items; 'Binding' with 'Folder Binding' set to 'Enabled'; and 'Details' with 'Details Creation' set to 'Enabled' and 'Details Widget' set to 'PIDDetails'.

Name	Description	Bind To	Data Type	Flags
1: PV	PV	Per Name	Real	None
2: SP	SP	Per Name	Real	None
3: Details1	Details 1	Per Name	Page	None

## Results of Binding


When we bind the overview widget to our PID loop, a new page is created to hold the details widget. The name of the new page is based on the name of our page containing the overview widget, but with a "Zoom" suffix and a number chosen to make the name unique.

This page is placed in the Navigation List below the current page:




The details created on this page are bound to our loop:





And the properties of our overview widget are modified as follows:



We can easily define a button within our overview widget, and have this button invoke an action of `ShowPopup (Details1)` thereby displaying the associated details widget. The details widget itself can close the popup by calling `HidePopup ()`.

## Multiple Details Pages

If multiple details pages are created, you will recall that data items called `Details1`, `Detail2` and so on in the overview widget will hold the names of those pages. These data items can also be defined on the details widgets, and will also be set to the names of the pages that have been created. This is useful if you want to allow the first details page to navigate to the second and so on, thereby linking the pages together. Details widgets can also define a special data item called `DetailsP` which will be set equal to the page that holds the overview widget. This can be used to return to the overview—something that cannot be achieved via a simple `GotoPrevious ()` when multiple details pages are provided.





MonicoView 3.1 device before the information is deleted. The log shown above is configured to retain a week's worth of data.

- The *Allow Comments* property is used to enable or disable the addition of comments to the data log via the `LogComment()` function. Refer to the Reference Manual for details of how this function can be used.
- The *Merge Events* property is active when the *Allow Comments* property is set to Yes. The *Merge Events* property allows event associated with the logger tags and those in the Monitor List to be merged into the data log. Such events will still be logged in the events file.
- The *Apply Signatures* property is used to control the addition of cryptographic signatures to the log. See below for more information on these signatures and how they can be used to ensure the log integrity is maintained.
- The *Include in Batch* property is used to include or exclude this log from the batch logging system. See below for information on how batch logging operates.
- The *Log Enable* property is used to allow or inhibit logging. If the entered expression is true, logging will be enabled. If the expression is false, logging will be disabled. If no expression is entered, logging will be enabled by default.
- The *Log Trigger* property is active when the Update Type property is set to *Triggered Snapshot*. The *Log Trigger* property is used to set the event that initiates taking a snapshot of current data points.

## Contents Properties

- The *Contents* property is used to indicate which tags should be included in the data log. Tags can be dragged into the list from the Resource Pane, and moved up and down within the list using standard drag-and-drop techniques.


## Monitor Properties

- The *Monitor* property is active when both the *Allow Comments* and *Merge Events* properties are set to Yes. The *Monitor* property is used to select additional tags the associated events of which will be merged into the data log.

## Batch Logging

When you first access the Data Logger, you will notice a global setting to enable or disable batch logging. For normal data logging operation, the Data Logger will save the log files under the folder name specified for each log. Batch logging, on the other hand, also saves all logs that are so configured to a directory named after the current production batch. This allows all the logs related to a particular batch to be accessed and manipulated as a group.

To illustrate this, consider the following directory structure:



This example is taken from a target device that has batch logging enabled and has two data logs configured. The first data log is set to be included in the batch, while the second one is not. Note that the log files are stored by default in the directories named LOGS/LOG1 and LOGS/LOG2. Note also, however, that the first log is also being placed in subdirectories under the BATCH directory. Each subdirectory contains the data sampled between the time when that batch was started and the time when the batch was ended.

## Controlling a Batch

Batch logging is controlled via a number of functions. `NewBatch(name)` will create a folder called *name*, ending the current batch and starting a new one. Files recorded after this command will be saved under the new folder. The `EndBatch()` function will stop the current batch, while `GetBatch()` will return the name of the batch that is currently active. For more information, please refer to the Reference Manual.

## Digital Signatures

MonicoView 3.1 supports the addition of cryptographic signatures to data, event and security logs, thereby allowing you to check a log file's integrity. The signatures will show if the log has been tampered with, or if data has been removed from the middle of the file. They will also allow you to be sure that a given log file came from the given device.

Enabling signatures adds an extra field to the CSV file to allow the storage of the required data. If you examine such a file, you will see that every few lines of the file have a large amount of data stored in this additional field. This data is the digital signature—a value mathematically derived from the data in the proceeding lines in a manner that makes it impossible to figure out how to keep the signature valid if a change is made to the data.

Signatures can be verified using the SigCheck command-line utility provided with the MonicoView 3.1 software. The utility will either confirm that the file is valid, or indicate the line at which the validation error occurs. If you want to be 100% sure of a file's integrity, you should also validate the digital signature applied to the SigCheck utility to ensure that it is approved Monico software and not a modified version that will produce invalid results.

To provide further comfort as to the integrity of the signature process, a Technical Note describing the algorithm in detail can be obtained from Monico Technical Support. You may also obtain the source code for SigCheck so that you can independently verify that it correctly validates the signatures applied to the log files.

## Log File Storage

As described above, data logs store their data in a series of files on the target device's memory card. The files are placed in the subdirectory specified in the log's properties, with this directory being stored under a root directory entry called LOGS.

Log files are named after the time and date at which the log is scheduled to begin. If each file contains an hour or more of information, the files will be named `YYMMDDhh.CSV`, where *YY* represents the year of the file, *MM* represents the month, *DD* represents the date, and *hh* represents the hour. If each file contains less than one hour of information, the files will instead be named `MMDDhhmm.CSV`, with the initial six characters as described above, and the trailing *mm* representing the minute at which the log began. These rules ensure that each log file has a unique name, dependent on the time at which it was created.

The length of each file depends on the *Update Rate* and *Each File Holds* properties. For example, with an update rate of 5 seconds and a number of samples of 360, each file will hold  $(5 \times 360) / 60 = 30$  minutes of data, therefore use the `MMDDhhmm.CSV` filename format. A new file will be created every 30 minutes, either on the hour or at half-past the hour.

## The Logging Process

MonicoView 3.1's data logger operates using two separate processes. The first samples each data point at the rate specified by the properties of each log and places the data in a buffer within the RAM of the target device. The second process executes every two minutes and writes the data from memory to the memory card.

This structure has several advantages:

- Writes to the memory card are guaranteed to begin only on a two-minute boundary—that is, at exactly 2, 4 or 6 minutes past the hour, and so on. This means that if your target device supports hot-swapping, you can wait for the next burst of writes to start, and, when the memory card activity LED ceases to flicker, you are guaranteed to have at least until the start of the next two minute interval before further writes will be attempted. This implies that you can remove the memory card without fear of data corruption. As long as you insert a new card before four minutes have elapsed, no data will be lost.
- Writes to the card occur at much higher levels of performance, as the system avoids the need to continually update the card's file system data structures for every single sample. For logs configured to sample at very high data rates, the bandwidth of a typical memory card would not allow data to be written reliably in the absence of such a buffering process.

Note that because data is not committed to a memory card for up to two minutes, up to this amount of log data may be lost when the terminal is powered-down. Further, if the target device is powered down while a write is in progress, the memory card may be corrupted. To ensure that such corruption is not permanent, MonicoView 3.1 uses a journaling system that caches writes to additional non-volatile memory within the terminal. If the device detects that a write was interrupted during power-down, the write will be repeated when power is reapplied, thereby reversing any corruption and repairing the card.

If you want to remove a memory card from a panel performing data logging, you must observe the procedure described above with respect to the activity LED, and only remove power when the activity has ceased. If you are not sure if the terminal was powered-down correctly, reapply power, allow the write sequence to complete, and power down according to the correct procedure. The card can then be removed safely.

Since the gyrations required to remove a memory card are somewhat complex, MonicoView 3.1 provides a variety of other mechanisms for accessing log files, thereby eliminating the need for such removals. These methods are described below.

## Accessing Log Files

There are five methods of accessing log files:

- You can mount the memory card as a drive on a PC via the process described at the start of this manual. This will allow the logs to be copied via Windows Explorer. This method has some drawbacks in terms of the amount of load that Windows can put on the memory card when it is first mounted.
- You can use the Web Server that is described in the next chapter. With the web server enabled, log files can be accessed over a TCP/IP connection, using either a web browser such as Microsoft Internet Explorer, or by using the automated process implemented by the WebSync utility provided with MonicoView 3.1.
- You can use the FTP Server to allow remote clients to connect to the MonicoView 3.1 device and download the logs. Refer to the Using Services chapter for details.
- You can use the Sync Manager to push the files to an FTP server on a periodic basis. Again, refer to the Using Services chapter for more details.

- You can enable automatic copying of the log files to a USB memory device by configuring the Memory Stick option in the Communication category. Refer to the Using Communications chapter of this manual for more details.





# Chapter 13 Using the Web Server

MonicoView 3.1's web server can be used to expose various data via TCP/IP connections, using either modems or the target device's Ethernet ports. This allows remote access to diagnostic information or to the values recorded by the Data Logger. The web server is configured by selecting the Web Server category in the Navigation Pane.


## Switching Versions

Note that if you are testing the MonicoView 3.1 web server on a device and then switch that device back to MonicoView II, you may have to press **F5** (or **CTRL+F5** or **SHIFT+F5**, depending on your web browser) to clear your browser's page cache and reload the MonicoView II version of the current page. Many pages have different URLs and so are immune to this issue, but the home page and the remote view page may confuse your browser when switching versions.

## Web Server Properties

The web server's properties are accessed from the root entry of the Navigation List.


## Control Properties



- The *Enable Web Server* property is used to enable or disable the web server. If the server is enabled, the panel will wait for incoming requests and then fulfill the requests as required. If the server is disabled, connections to this port will be refused. Remember that for the server to operate, an Ethernet or modem interface must have been configured via the Communications category.
- The *Transport Protocol* property is used to select between TCP/IP and HTTP, or TLS and HTTPS. The latter is more secure, encrypting the data transferred between the server and its clients, and providing a mechanism for the server's identity to be validated. TLS-HTTPS demands more effort during configuration, however, with a valid server certificate being required to prevent web browsers from complaining about an insecure connection.
- The *Connect Via Port* property specifies the TCP port number on which the web server will listen. Port 80 is the standard port used by the HTTP protocol and port 443 is the standard port for HTTPS. These settings will most likely suit your application unless some form of port mapping device is in use.

- The *HTTP Redirect* property is available in HTTPS mode and instructs the web server to redirect any HTTP requests made to port 80 to the corresponding page on port 443. This allows the web server's IP address or host name to be typed straight into a browser without using the `https://` prefix, while still ensuring that the secure version of the website is accessed. Note that while the port used for HTTPS can be modified via the above setting, HTTP redirect always uses port 80.
- The *Server Certificate* property group is available in HTTPS mode and indicates how the server should obtain the certificate used to identify the site. You may provide a certificate in the form of a PFX file and an associated password, or you may select a certificate from the Windows private certificate store. If you do not specify a certificate, MonicoView device's default server certificate will be used. See the section below for more information on working with certificates.
- The *Identification* property group allows you to provide text strings to be used to identify the server. These can be used to differentiate between several terminals on a network, thereby ensuring that the correct device is being accessed. The *Main Title* is shown in the web browser title bar. The *Main Header* is shown above the web server's main menu. The *Home Label* is shown in the top left-hand corner of the menu bar included on each webpage.
- The *Custom Home Page* property is used to override the default home page displayed by the web server. If this property is enabled, the server will look for a file named `default.htm` in the `WEB` directory of the memory card. A sample home page is included in the `WebServer/Samples` directory of the MonicoView 3.1 installation. The sample is identical to the default page, except that it includes tag data and a message that the page has been customized.
- The *Custom Logon Page* property is used to override the page used by the web server to capture logon credentials in Form authentication mode. If this property is enabled, the server will look for a file named `logon.htm` in the `WEB` directory of the memory card. A sample logon page is included in the `WebServer/Samples` directory of the MonicoView 3.1 installation. The sample is identical to the default page, except for a note that it has been modified.
- The *Custom Style Sheet* property is used to include a custom CSS file in the standard pages provided by the web server. All such pages include a stylesheet named `/custom/css/custom.css` in their header section. If this property is enabled, references to this file will be mapped to a file named `custom.css` in the `WEB` directory of the memory card. If the property is disabled, any such references will return an empty file. A custom CSS file can be used to override the appearance of the standard web server, modifying colors, fonts etc. A sample stylesheet is included in the `WebServer/Samples` directory of the MonicoView 3.1 installation. The sample modifies the pages' background color.
- The *Custom JavaScript* property is used to include a custom script in the standard pages provided by the web server. All such pages include a script named `/custom/js/custom.js` in their header section. If this property is enabled, references to this file will be mapped to a file named `custom.js` in the `WEB` directory of the memory card. If the property is disabled, any such references will return an empty file. Once a webpage has been loaded, the browser will attempt to run a JavaScript function called `doCustom`, allowing your custom script to modify the document model or to implement any other customizations. A sample script is included in the `WebServer/Samples` directory of the MonicoView 3.1 installation. The sample uses JQuery and certain predefined anchors within the webpage structure to add additional menu items. For more details on these anchors, see the next chapter.


## Feature Properties



- The *Remote Viewing* property is used to enable or disable a facility by which a web browser can be used to view the current contents of the target device's display. This facility is very useful when remotely diagnosing problems that an operator may be having with the operator panel or the machine it controls.
- The *Remote Control* property is used to enable or disable a feature whereby the remote viewing facility is extended to allow a web browser to be used to simulate the pressing of keys or display primitives, thereby allowing remote control of the panel or the machine it controls. While this feature is extremely useful, care must be taken to use the various security parameters to prevent tampering.
- The *Display Mode* property is used to control how the remote view will be rendered in the web browser. Regular mode will display the view as part of a normal page, complete with a menu bar to allow navigation to other pages. Full Window mode scales the remote view to the entire browser window, adjusting the scale factor if the window is resized. This mode is useful on mobile devices or whenever the display is too large to view in a regular window. The Bare Display modes show only the device's display without any bezel or keys. These modes are optimized for use on the web browsers incorporated into large-screen TVs.
- The *Display Scale* property is used to control how the display image is scaled within the web browser. Most devices scale the display at 1:1, but devices with lower-resolution displays may use 2:1 by default. This setting can be used to override this behavior and force the scale to 1:1 at all times.
- The *Display Depth* property is used to control how many colors are used to render the display image. The default setting of 16 bits supports about 32,000 different colors and results in a good compromise between performance and fidelity. A setting of 24 bits will produce a completely accurate copy of what is shown on the device's display at the cost of using at least 50% more data. (Opportunities for compression are also reduced by using more bits, so the increase is more than would be expected by simply comparing the bit count.) A setting of 8 bits will reduce the data usage by at least 50% at the cost of much lower fidelity. This setting is only recommended for low-bandwidth or metered applications.
- The *Data Log Access* property is used to enable or disable web access to the files created by the Data Logger. This facility must be enabled if the web server is to be used by a remote client program to automatically synchronize data logs.


- The *Show Batches* property is used to enable or disable the display of batches within the data log section. If it is enabled, the user will be able to review the current and previous batch logs in addition to the current real-time logs.
- The *Custom Site* property is used to enable or disable a facility whereby files stored in the `WEB` directory of the memory card can be exposed via the web server. This facility is described further below, and in even greater detail in the next chapter. Note that the custom home page and logon page can be implemented without enabling this function.
- The *Include in Menu* option is used to control whether the custom site is explicitly included in the web server's default menu and in the menu bar present on each bar. You may not need to enable this feature if you have modified the home page or changed the menu structure using JQuery.
- The *Root Redirect* feature is used to instruct the server to redirect any unresolved references to the server's root directory to the `WEB` directory on the memory card. It is not recommended for new applications as we reserve the right to create other root directory entries that may override your selections.
- The *Maximum Wait* property is used to specify how long MonicoView 3.1 should wait for external communications data before serving a webpage. This applies only to custom webpages which include tag data using the embedded text values described in the next chapter. If these data items are not on the communications scan, MonicoView device must read them before sending the page. This setting limits the wait period to ensure that offline data does not adversely impact server performance.
- The *System Pages* property is used to enable or disable the various system pages that can optionally be added to the web server. These pages are intended for use during commissioning and testing. **They should not in general be left enabled on production devices.** The system console in particular should not be enabled in command mode unless appropriate security settings are used to restrict access.
- The *Debug Console* property is used to show or hide the debug console page. The page may either be enabled in Display Only mode or in Command mode. The former will just display diagnostic information output by various portions of the MonicoView runtime software, while the latter will also allow the execution of various system commands. These commands provide advanced features that can disrupt the operation of the device. **Command mode should therefore not be left enabled on production devices.** Information about the debug console can be found in the chapter on Advanced Debugging.
- The *Packet Capture* property is used to enable or disable a system page that allows the capture of the data from the device's Ethernet ports. This facility can be used to collect some or all of the data transferred over a specific port, allowing easier debugging of connection problems. It also allows the unencrypted form of SSL-secured communications to be monitored. **To prevent data compromise, it should therefore not be left enabled on a production device.**
- The various *Access Control* properties allow a security descriptor to be used to restrict access to each feature to certain users. The properties are only available if security is enabled and the MonicoView 3.1 user database is used for authentication.

## Security Properties



- The *Authentication* property defines how MonicoView 3.1 will authenticate users who connect to the web server. Selecting None will disable all authentication, allowing anonymous access to the server's resources. Selecting Form will use an HTML form to allow entry of the user name and password, with a custom logon page being used if the server is so configured. This method is recommended for HTTPS connections as it is more attractive, more customizable, and it supports the ability to log off in a consistent and secure manner. It should not be used over HTTP as it sends the password in plain text. Selecting HTTP will use HTTP's own authentication method, which typically results in a popup appearing in the client's web browser. If this method is selected, the *HTTP Method* property must be set to select the precise method that will be used. The Basic method is not recommended with HTTP as again it sends the password in plain text. HTTP authentication also requires the *Realm* to be specified. This is displayed in the browser popup to confirm the site identity.
- The *Credentials* property group is used to specify how MonicoView 3.1 should obtain user name and password information. The *Source* setting should typically be left as Security Manager, allowing multiple users with differing permissions to be created via the Security category of the database. For legacy databases, it is sometimes necessary to specify a single user by setting the Source to Web Server and entering the information manually. This facility is also useful during testing when a user needs to be created quickly. Note that only a setting of Security Manager will allow security to be defined at the facility and page level.
- The *IP Restrictions* group is used to restrict web server access to hosts whose IP address matches the mask and data indicated. All access may be restricted, or the filter may be used to restrict just remote control and data editing.


## Advanced Properties



- The *Enable Advanced Settings* property enables or disables the other settings on this page. You will typically not have to adjust any of these settings.
- The other settings are documented via balloon help. Do not adjust them unless you are an advanced user and understand their impact, or have been instructed to do so by the technical support team. The default settings will be suitable for virtually all applications.

## Adding Webpages

In addition to the facilities described above, the web server supports the display of generic webpages, each of which contains a predefined list of tag values. These pages are created in the Navigation Pane in the usual way. Each webpage has the following properties:



- The *Title* property is used to identify the webpage in the menu presented to the user via their web browser. Although the title is translatable, MonicoView 3.1 uses only the US version of the text.
- The *Refresh* property is used to indicate whether the webpage will be updated with new data as it arrives. While previous versions refreshed the entire page, MonicoView 3.1 uses AJAX to update only the data values. There is therefore no flicker and no need to specify the update rate.
- The *Use Colors* property is used to indicate if colors defined by a tag's coloring should be used when rendering this page. If enabled, the color shown in the web browser will change depending on the tag status. Refer to the Using Data Tags chapter for more details.


- The *Allow Editing* property is used to enable the editing of data tags via this page. If it is enabled, each data value will have an Edit button displayed, allowing the user to change that value. If the tag has security settings defined, the user logged on to the web server must have sufficient rights to modify the tag. The use of authentication is recommended when using this feature.
- The *Prefetch Data* property is used to indicate whether the tags for this page should always be placed on the communications scan to minimize any delay when serving the page. If prefetching is disabled, MonicoView 3.1 will read the tags before the page is delivered to the browser, waiting for up until the period specified by the *Maximum Wait* property.
- The *Hide Page* property is used to hide a page from the standard menus presented by the webserver. It is used to create webpages that can be invoked via the AJAX mechanisms described in the next chapter to provide your own custom website with real-time tag data. The Access Control and Allow Editing properties are used to decide whether read or write access will be provided based on the identity of the currently logged on user.
- The *Access Control* property allows a security descriptor to be used to restrict access to this page to certain users. The property is only available if security is enabled and the MonicoView 3.1 user database is used for authentication.
- The *Contents* property is used to indicate which tags should be included on the page. Tags can be dragged into the list from the Resource Pane, and moved up and down within the list using standard drag-and-drop techniques.

## Working with Certificates

If you know all about certificates, skip to [Obtain a Commercial Certificate](#) to learn the various ways to get a certificate; or to [Use the Default Certificate](#) to learn how to get up and running quickly.

### Introduction


Web servers that use HTTPS are required to provide a certificate that verifies that the server is indeed owned by the company referenced by its URL. For example, if you access Google via HTTPS, their server will provide your browser with the following certificate:



The relevant pieces of information to note here are that the certificate is intended to ensure the identity of a remote computer and that it applies to sites that have `*.google.com` as their domain address. Your web browser will compare this name to the address you entered in the address bar and if they match, it will allow you to proceed to the site.



To ensure the validity of a certificate, it must be signed by another certificate. This certificate must in turn be signed by another certificate, all the way back to some set of certificates that are trusted by your browser as being issued by reliable organizations who only hand out certificates to people who have a right to use the associated names. For example, the Google certificate referred to above has the following certification path:



The certificate upon which your browser is depending is vouched for by the Google Internet Authority, which is presumably some part of the Google organization that issues certificates to other parts of the company. But your browser does not really know anything about this Internet Authority and whether it can be trusted it to issue certificates only to valid Google domains. Instead, it relies on the fact that this certificate has in turn been signed by GeoTrust, a company in the business of issuing trusted certificates and that is well known for having in place the procedures necessary to stop anyone other than Google from getting access to a certificate with a name that refers to a google.com domain. Your browser has GeoTrust's certificate as one of its so-called trusted roots. This chain of trust is used to validate that you are indeed talking to Google and not to a hacker trying to steal your identity.

## Using Certificates

All of this means that if you are going to use HTTPS, you need to provide a certificate that matches the name that will be used to access the server, and that this certificate must be traceable back to one of the trusted roots used by the relevant web browsers. There are several ways of accomplishing this goal. If you are testing and just want a quick answer, skip straight to [Use the Default Certificate](#) and you will be able to get up and running much more quickly. Otherwise, the sections below explore your various options in detail.

### Obtain a Commercial Certificate

The most correct way of dealing with this issue is to ensure that your target device is accessed via a DNS name that is part of a domain that your company owns. For example, you may decide to create a DNS entry called `hmi01.hmis.mycom.com` that refers to a specific HMI. If your company can prove that it is the owner of the `mycom.com` domain, you will be able to get one of several trusted certificate providers to issue a certificate that either validates this specific name, or perhaps validates any names ending in the `hmis.mycom.com` suffix. Since these certificates will be traceable to one of the trusted roots that are installed on just about every device in the world, the server will be able to be validated by any client. The downside is that you will need to get your IT department (and, worse, perhaps your legal department) involved and you must pay a fee upon issue and upon renewal. Commercial certificate providers include GeoTrust, Thawte, GoDaddy and Comodo.

### Use a Local Certification Authority

If you do not want to bother with a public certificate, it is possible that you will be able to use your company's own certification authority or CA. Many companies have an internal CA which



issues certificates for servers, workstations and users within the organization. The certificates are not always traceable back to one of the trusted root certificates that you would find installed on a regular computer, in which case every PC in the organization will have been configured to trust the CA's root certificate. If the web server is only to be accessed via devices that belong to your company and trust its CA, this method will work well. As before, you must refer to your device via a DNS name that your organization controls, and you must work with your IT department to get the certificate issued. No fees will be required.


### Use a Self-Signed Certificate

If you do not have access to a public or a private certification authority, you can use what is called a self-signed certificate. This is a certificate that has no chain of trust and basically attests to its own validity. For a self-signed certificate to work, the certificate itself must be installed as a trusted root on each device that will access the web server. Sometimes this means installing it in the operating system's Trusted Roots store. Other times, it means adding it to the browser's own list. This is somewhat painful if you have multiple devices accessing the server, or if you do not know ahead of time which devices will require access. Self-signed certificates can be generated using command line tools for Linux or for Windows PowerShell. There are also several websites that will generate a selfsigned certificate for you. Whichever method you use, ensure that the name matches the DNS entry that will be used to refer to the server, and ensure that the certificate is in PFX format. MonicoView 3.1 does not currently accept certificates in split certificate and key PEM format.

### Use the Default Certificate

You will have realized by now that all of this is a significant amount of work, especially if you just want to test a web server for evaluation purposes. Luckily, MonicoView 3.1 provides a simpler solution in the form of a default certificate.

If your unit has a local name configured via the Zero Config option on the Network page of the Communications category, the MonicoView 3.1 device will generate a certificate for that name upon startup. If you have not entered a name, the default name will be used instead. You will recall that this is `red-xx-yy-zz.local`, where the letter pairs are replaced with the last half of the unit's MAC address. This automatic certificate will be signed by the MonicoView device Local Root, and so per the chain of trust described above, you must trust this root certificate in order to trust the certificates that it is used to sign. You can install the MonicoView device Local Root certificate by clicking on the link immediately below the Zero Config settings, displaying the following:



If you want to verify you are installing the correct certificate, the thumbprint should be:  
**A919C8D1 EF3F11FA E1F21ABE B9A60623 FFCC122D**

Once the MonicoView device Local Root is installed, you may refer to your unit via its local name and you will get no certificate errors. For example, a unit named test may be accessed from anywhere on the same subnet by typing `https://test.local` into your web browser address bar. The `https://` prefix can be omitted for some browsers if HTTP Redirect is turned on.

The default certificate is not recommended for production deployments.

## Beyond the Subnet

If you wish to access a device using the default certificate from beyond its subnet, you can still use the local name but you must put an entry in the HOSTS file on the client machine. For testing, you may be happy to open a command prompt and ping the local name to discover the DHCP-allocated IP address, or you may wish to switch to Manual port configuration and use a fixed IP instead. Note that local name resolution still works with manual addresses.

Let us assume your device is called `test.local` and has an IP address of 192.168.1.250.

Open a Windows command prompt with administrative privileges<sup>2</sup> and change the directory to:

```
C:\Windows\System32\drivers\etc
```

From that directory, run `NOTEPAD HOSTS` and add a line to the end of the file:

```
192.168.1.250 test.local
```

Save the file and references to `test.local` will be resolved to the required IP address.

## Don't Bother

You may simply decide not to provide a certificate or not to bother establishing a trust relationship between your clients' browsers and the web server. This will result in the browser displaying an error each time the site is visited. Indeed, many modern browsers will block access to the site entirely unless the user goes through various gyrations. It also has the effect of numbing your users to the idea of ignoring security warnings, an attitude that may bite them when they stumble across a genuinely insecure site. This approach is therefore most definitely not recommended.

## Using a Custom Website

While the standard webpages provide quick-and-easy access to the data within the terminal, you may find that your inability to edit their precise formatting leaves your artistic capabilities somewhat frustrated. Before resorting to a completely custom site, consider whether the custom stylesheet and JavaScript options detailed above will meet your needs, particularly if you just want to adjust formats and colors.

If you need more than simple format changes, the MonicoView 3.1 custom site facility will allow you to create a completely customized website using your favorite HTML editor. The HTML can include special commands to include the various fragments that make up the standard website, or to include live data from MonicoView 3.1 tags. Once the files have been created, they can be stored on your device's memory card in the WEB subdirectory, at which point they will be available for access via the web server in the under the /custom path.

The next chapter provides more in-depth information on this process.

---

<sup>2</sup> If you don't have admin privileges, see the comments above about working with your IT department and contact your System Administrator.

# Chapter 14 Creating Custom Websites

This chapter contains information on creating a custom website that is to be hosted by a MonicoView 3.1 device. It assumes knowledge of HTML and JavaScript. To create a website that is well integrated with the standard MonicoView 3.1 website, a working knowledge of Bootstrap and JQuery would also be an advantage.

## Naming

Since the filing system is case insensitive, you must not rely on case difference to differentiate between pages. Beyond this limitation, you may use a directory structure nested to any level, provided it is all stored under the `WEB` subdirectory. MonicoView 3.1's web server is aware of virtually every popular file extension and will reply with the appropriate MIME type when the file is requested. Custom MIME types are not currently supported.

## Resources

MonicoView 3.1's standard webpages make use of Bootstrap and JQuery to implement much of their functionality. Each webpage thus includes the following stylesheets and script files:

```
<link href="/assets/css/bootstrap.min.css" rel="stylesheet">
link href="/assets/css/bootstrap-theme.min.css" rel="stylesheet">
<link href="/assets/css/ie10-viewport-bug-workaround.css"
rel="stylesheet">
<link href="/assets/css/theme.css" rel="stylesheet">
<link href="/custom/css/custom.css" rel="stylesheet">
<!--[if lt IE 9]>
<script type="text/javascript"
src="/assets/js/html5shiv.min.js"></script>
<script type="text/javascript"
src="/assets/js/respond.min.js"></script>
<![endif]-->
<script type="text/javascript"
src="/assets/js/jquery.min.js"></script>
<script type="text/javascript"
src="/assets/js/bootstrap.min.js"></script>
<script type="text/javascript" src="/assets/js/ie10-viewport-bug-
workaround.js"></script>
<script type="text/javascript"
src="/assets/js/session.js"></script>
<script type="text/javascript" src="/custom/js/custom.js"></script>
```

You may include as many or as few of these resources as are needed to implement your site, using the URLs shown above. We recommend that you use MonicoView 3.1's own versions of the Bootstrap and JQuery libraries and avoid adding them to your site manually. The current versions of Bootstrap and JQuery are 3.3.7 and 1.12.4, respectively. If MonicoView 3.1 subsequently switches to newer versions that introduce compatibility issues, a property will be added to allow you to select which versions you wish to use for your custom website.

The `session.js` script performs a special function. It rewrites any URLs referenced by `<a>` elements to include the session identifier passed to the page as part of its own URL, thereby allowing MonicoView 3.1 and your browser to distinguish between sessions when caching pages.

This is important as different users will have different user interface options determined by their security settings and caching may not respond correctly to these changes unless the session value is included in the URL. If you are relying on this functionality, you should make sure you include `session.js` and include the following after your closing `</body>` tag:

```
<script  
type="text/javascript">$(document).ready(doSession);</script>
```

The `doSession` function is also responsible for calling `doCustom` from a custom JavaScript file and for invoking the standard functions used for remote access and data animation.

## Server Commands

MonicoView 3.1's webserver does not support CGI, ASP, ASPX or other server-side scripting functionality. However, server-side commands are provided to indicate that a page should not be cached and to include embedded tag or system data within a page.

### Server Include

A server-side include can be performed by inserting the following HTML:

```
<%Include filename%>
```

The `filename` portion should be replaced by the URL-style path of the required file. Note that the URL-style path for custom website files starts with `/custom`, and not the `\WEB` prefix used for the directory in which they are stored.

Two standard files are provided and are often included on custom pages. The `/stdhead.htm` file contains all the HTML code that is required to load the standard libraries and stylesheets described above. It can be added to each page in the `<head>` section to avoid duplication of this content. The `/stdnavbar.htm` file contains the HTML necessary to implement the menu bar provided by the standard website. If you want your custom pages to use this navigation method, include this at the start of the `<body>` section of each page.

### Cache Control

The following directive can be used to disable caching for a page:

```
<%NoCache%>
```

Caching typically needs to be disabled when dynamic data is included on a page.

### Embedded Data

Data can be embedded within a page by using the following syntax:

```
<%=class.name%>
```

## Tag Data

For a `class` value of `Tags`, the following values of `name` are supported:

NAME	RESULT
TagName	The formatted value of the specified tag. For example, <code>Tags.Tag1</code> will insert the value of value of Tag1. The name may be followed by an array index in square brackets to access a specific element, such that for example <code>Tags.Tag2[10]</code> will display the eleventh (think about it!) element of Tag2.

In addition to the `<%=Tags.Name%>` syntax, you may insert a tag value by using the legacy sequence of `[[n]]`, replacing `n` with the index number or name of the tag in question. A tag's index number is displayed in the top right-hand side of the Editing Pane when a tag is selected within the Data Tag category. It more-or-less corresponds to the order in which the tags were created. Index numbers provide marginally faster access to tag data than names, but the newer syntax is nonetheless preferred.

## Global Data

For a `class` value of `Global`, the following values of `name` are supported:

NAME	RESULT
Home	The <i>Home Label</i> property of the web server.
Title	The <i>Main Title</i> property of the web server.
Header	The <i>Main Header</i> property of the web server.
MainNavBar	The code used to implement the main navigation bar at the top of each page. This value is invoked when <code>stdnavbar.htm</code> is included. Placeholder spans with ids of <code>c3navbar-head</code> , <code>c3navbar-home</code> and <code>c3navbar-tail</code> are included to allow JQuery manipulation of the navigation structure. See the <code>sample.js</code> file referenced in the previous chapter for an illustration.
MainMenu	The code used to implement the main menu shown on the default home page. You may use this within a custom home page to avoid replication. Placeholder rows with ids of <code>c3-menu-head</code> and <code>c3-menu-tail</code> are provided to allow JQuery manipulation of the menu structure. See the <code>sample.js</code> file referenced in the previous chapter for an illustration.

## Data Index Data

For a `class` value of `DataIndex`, the following values of `name` are supported:

NAME	RESULT
Dropdown	The code used to implement the drop-down list of the standard webpages created via the MonicoView 3.1 configuration tool, modified to include only those pages that are accessible to the user current.
List	The code used to implement the menu-style list of the standard webpages created via the MonicoView 3.1 configuration tool, modified to include only those pages that are accessible to the user current.

## Data View Data

For a `class` value of `DataView`, the following values of `name` are supported:

NAME	RESULT
Header	The code used to create the header shown at the top of a specific standard webpage. The page number must be included in the URL as the <code>page</code> parameter.
TagHead	The code used to create the header of the table shown on a specific standard webpage. The page number must be included in the URL as the <code>page</code> parameter.
TagList	The code used to create the contents of the table shown on a specific standard webpage. The page number must be included in the URL as the <code>page</code> parameter.

## AJAX Updates

### Reading Tags

The standard webpages that contain tag data are updated by means of a GET request to the `/ajax/dataview-read.htm` resource. The URL must include the required page number as the `page` parameter, with the value being encoded in decimal. Page numbers start at zero and essentially follow the order in which the standard pages were created. They are not exposed via MonicoView 3.1's user interface but can easily be deduced from the links used by the standard website to reference these pages. You may use this URL to obtain the same data for your own purposes, perhaps to animate a custom page that likewise contains tags. The request will return a text file containing a line for each tag. Each line will contain the tag's formatted value, followed optionally by the tag's foreground and background colors if these are enabled for the page in question. If you create a standard webpage just for this purpose, you will typically set its *Hide Page* property to prevent it appearing in the standard menus.

### Writing Tags

The standard webpages that contain tag data perform tag writes via a GET request to the `/ajax/dataview-write.htm` resource. As above, this URL must include the required page number as the `page` parameter, but this time it must also specify the required tag as the `tag` parameter. The tag number is a zero-based index into the list of tags configured for that page via its Contents property. The tag will be set to the value specified in the `data` parameter, which must also be included in the URL. A successful write will produce a return code of 200 with a message in the reply body confirming the change. A write that produces no change will have the same return code but will have an empty body. A return code of 403 indicates that the write failed because of a security problem or invalid data. The operation will also fail if the page in question has not been configured to allow writes. Once again, if you create a standard webpage just for this purpose, you will typically set its *Hide Page* property to prevent it from appearing in the standard menus.

## Site Deployment

To deploy your custom website, copy it into the `\WEB` directory on the memory card to be installed in the target device. To copy the files, either mount the card as a drive as described in the early chapters of this manual, use a suitable card writer connected to your PC, or transfer them via the FTP Server. Enable the custom site in the web server's properties, and if you have included the custom site in the menu, the site will appear in both the menu bar and the main menu list. When the site is selected, a file called `default.htm` within the `\WEB` directory will be displayed. Navigation beyond that point is according to the page's links.

# Chapter 15 Using the Security System

MonicoView 3.1 contains powerful features that allow you to define which operators have access to which display pages and other facilities, and limit those operators able to make changes to specific data. The software also contains a logging facility that can be used to record changes to data values to indicate when each change occurred and by whom it was performed.

## Security Basics


The following sections detail some of the basic concepts used by the security system.

### Object-Based Security

MonicoView 3.1's security system is object-based. This means that security characteristics are applied to a display page or to a tag, and not to the user interface element that accesses the page or makes a change to the tag. The alternative subject-based approach typically means that you have to be careful to apply security settings to every single user interface element that might change restricted data. MonicoView 3.1's approach avoids this duplication and ensures that once you have decided to protect a tag, it will remain protected throughout your database.

### Named Users

MonicoView 3.1 supports the ability to create any number of users, each of whom will have a username, a real name and a password. The username is a case-insensitive string with no embedded spaces that is used to identify the user when logging on, while the real name is typically a longer string that is used within log files to record the human-readable identity of the user making a change. Note that you are free to use these fields in other ways if it suits your application: You may, for example, create users that represent groups of individuals or perhaps roles, such as Operators, Supervisors and Managers.




### User Rights

Each user is granted zero or more access rights. A user with no rights can access those objects that merely require the identity of the user to be recorded, whereas users with more rights can access those objects that demand those rights to be present. Rights are divided into System Rights and User Rights, with the former controlling access to facilities within the MonicoView 3.1 software, and the latter being available for general use. For example, User Right 1 might be used within your database to control access to production targets. Only users whom you want to be able to vary such things would then be assigned this right.

## Access Control


Objects that are subject to security have an associated *Access Control* property. Editing the property displays the following:



These settings allow you to specify whether the item can be accessed by anyone, by any operator whose identity is known, or by users with specific user rights. You may also specify whether a tag can be changed by a program that is running as a result of something other than user action. This facility allows you to guarantee that no background changes occur to sensitive data, even if a programming error attempts to make such a change.

## Write Logging

Tags also have a *Write Logging* property. Editing the property displays the following:



The selection indicates whether changes made to a tag by users or by programs should be logged. This facility allows you to create an audit trail of changes to your system, thereby simplifying faultfinding and providing quality-control information as to process configuration. Note that care should be taken when logging changes made by programs, as certain database may log unmanageable amounts of data in such circumstances.

## Default Access

To speed the configuration process, MonicoView 3.1 also provides the ability to specify default access and write logging parameters for mapped tags, internal tags and display pages. The differentiation between mapped and unmapped tags is important in systems where all changes to external data must be recorded, but where data internal to MonicoView 3.1 can be manipulated without the need for such an audit trail.

## On-Demand Logon

MonicoView 3.1's security system supports both conventional and on-demand logon. A conventional logon can occur when a user interface element such as a pushbutton is used to activate the Log On User action or to call the `UserLogOn()` function. On-demand logon occurs if the operator attempts an action without sufficient access rights, and if a failed logon attempt has



not occurred within the same action. For example, a user may press a button that runs a program to reset a number of values. As soon as the program attempts to change a value that requires security access, the system will prompt for logon credentials. This method limits operator interaction and produces a more responsive system.

## Maintenance Access


The system also provides a facility called Maintenance Mode to allow the user inactivity timeout to be overridden during system commissioning. This mode is activated if a display page is marked as being accessible with the Maintenance Access right and if the current user has gained access to the page because of that right. Use of this mode avoids the need to logon repeatedly when testing the system.

## Check Before Operate

The Check Before Operate feature allows you to force the user to confirm every change to a sensitive data item. The feature is enabled by selecting the appropriate setting on a data tag's security descriptor. When a change is made to a tag that has this feature enabled, a popup will appear displaying the old and new values and demanding confirmation before the change is permitted. This feature operates whether or not a user is currently logged on, and is in addition to any user rights required for the change to occur. It is also independent of the action Protection operations defined when creating the user interface.

## Security Settings

The security system settings are accessed via the root item in the Security category:




The available properties are as follows:

- The *Inactivity Timeout* property is used to indicate how much time must pass without user input before the current user is automatically logged off. Too high a value for this setting will produce an insecure system, while too low a value will produce a system that is awkward for operators.
- The *Clear Logon Name* property is used to indicate whether or not the username should be cleared before asking the operator to logon. If this setting is disabled, the previous username will be displayed, and only the password will need to be reentered. Enabling this feature produces higher security, and may be required to comply with security standards in certain industries.
- The *Default Access* properties are used to indicate the access to be provided to various objects should no specific access be defined for that item. The settings are as described in the Access Control section above.

- The *Default Logging* properties are used to indicate whether changes to mapped and unmapped tags should be logged should no specific logging criteria be defined for a tag. It is not possible to log programmatic access by default, as such logging should be carefully considered to avoid excessive log activity.
- The *Logging Control* properties define whether and how the security logs should be created. Refer to the Using the Data Logger chapter for information on how the data is written and how files are named.

## Creating Users

Users are created and otherwise manipulated via the usual methods in the Navigation List.



Each user has the following properties:


- The *Real Name* property is used to record the user's identity in security logs, and is also shown in the Security Manager primitive that is used to change passwords at runtime. If maximum security is required, the user name should not be easily derived from the real name.
- The *Password* property specifies an initial password for this user. The password is case-sensitive and comprises alphanumeric characters. Note that if the *Override Existing* box is checked, any changes made to this password from the target device will be overridden when this database is downloaded.
- The *System Rights* properties are used to grant a user the ability to perform certain system actions. The properties relating to password changes are self-explanatory, while the user of Maintenance Mode is described above.
- The *Custom Rights* properties are used to grant a user certain rights which may then be used within the database to allow access to groups of tags or display pages. The exact usage of these rights is up to the system designer.

## Specifying Tag Security

Each tag has a tab called Security which defines the access control and write logging settings for that tag. If you do not define specific settings, the system will use the appropriate default settings, depending on whether it is mapped to external data.

## Specifying Page Security

The access control settings for display pages are defined via their Properties dialog:



Once again, if no setting is defined, default settings will be used.

## Security Related Functions

Please refer to the Reference Manual for details on the `UserLogOn()`, `UserLogOff()` and `TestAccess()` functions. This last function is useful when changing many values from within a program, as it allows you to force an access check early in the code to avoid making changes only to have later operations fail due to insufficient user rights.




# Chapter 16 Using SQL Queries

The SQL Queries category is used to create SQL queries that can be used to extract data from a Microsoft SQL Server database and store it within tags. These tags can then be used elsewhere in the MonicoView 3.1 database to control production, update recipe settings or perhaps display productivity information related to the factory in which the device is installed.

## Configuring the Server


The first step in accessing SQL data is to configure the Microsoft SQL Server from which the data is to be obtained. This is done by selecting the root entry in the Navigation List that is displayed within the SQL Queries category, as follows:



- The *Enable SQL Queries* property is used to enable the SQL Queries function.
- The *Server* property is used to specify the address of the Microsoft SQL Server to which the device will connect. It may be specified as an IP address, a fixed DNS name, a DNS name determined by a string tag, or a numeric expression.
- The *TCP Port* property is used to specify the TCP/IP port to which the device will connect. This port must agree with the port configured for TCP/IP access on the server. Contact your database administrator for more information.
- The *Logon Username* and *Logon Password* are the credentials that are submitted to the server when the connection is established. The password is always case sensitive. The case sensitivity of the username depends on the server. The user must have the rights necessary to read table data.
- The *Database Name* property is used to specify the name of the database on the server from which the SQL Queries will extract data. Again, contact your database administrator to ensure that the correct name is specified.

## Creating Queries


SQL Queries are created in the Navigation Pane in the usual way. Each query has the following properties:



- The *Query Mode* property is used to control how the query will be executed. If the property is set to Periodic, the query will be executed at the rate specified by the Refresh Rate property. If the property is set to On Demand, the query can be executed by calling the `RunQuery()` function and passing as a parameter the name of the query, or by calling the `RunAllQueries()` function. If the property is set to Disabled, the query will not be executed.
- The *Table Name* property is used to specify the name of the table against which the query will be run. It should correspond to a suitable table within the SQL database specified when the server was configured.
- The *Schema Name* property is used to override the default schema name of `dbo` when schemas have been used to manage table visibility. It should correspond to the schema via which the specified user will access the specified table.
- The *Number of Rows* property is used to specify how many rows will be requested from the database when the queries are executed. It will be passed to the database as a `TOP` element in the `SELECT` query. The filters and sort order specified below will determine exactly which rows are returned.
- The *Sort Results* property is used to define the `ORDER BY` clause of the query, and thus to sort order of the resulting row. This impacts both the order in which the data is stored in the mapped tags and the effect of the `TOP` clause controlled by the *Number of Rows* property. If *Sort Results* is enabled, the *Sort by Column* property is used to specify the column to be used as the sort key.

## Filtering the Results


You may filter the rows return by each query by selecting the Edit Filters option:



A filter condition may be added by selecting the required column in the first field of the Create Filter section, and then selecting the required operator and data value. Once this has been done, press the Add button to append the condition to the list. Note that filter data values are constants and cannot be set to MonicoView 3.1 tags or other expressions. Conditions may be removed by selecting them in the Applied Filters list and pressing Delete Filter.


## Checking the SQL Code

Once a query has been defined, the View Generated SQL option may be used to review the SQL that will be sent to the server. The example below shows a query that reads up to eight rows of two columns, applying filters and sorting by one of the columns:



## Creating Columns

When a query is created, MonicoView 3.1 creates a single column in the Navigation Pane to represent the returned data. Additional columns will typically be needed, and these can be created by selecting the required query and choosing the Column option under the New button at the top-left of the Navigation List. Each column has the following properties:




- The *SQL Column Name* property is used to specify the name of the column as it is shown in the SQL table on which the query is to be performed. It should correspond to the name specified when the table was created.
- The *SQL Type* property is used to select the data type of the column. The type should correspond to the type specified when the table was created. It is used to control the mapping of SQL tags to MonicoView 3.1 tags.

## Mapping Tags

For each column contained within the query, the Navigation List will show several row entries, the quantity being driven by the number of rows selected in the query properties. You may drag and drop tags from the Resource Pane to establish a mapping between the query results and the tags that will be used to store the resulting data. You will typically use an array to represent each column, with each row being mapped to a specific array element.

The following example shows each row of each column being mapped to an element in a MonicoView device array, allowing the result data to be easily accessed by the rest of the MonicoView 3.1 database:





# Chapter 17 Using IEC-61131

The Control category of the database is used to create and manage programs written in one of the four IEC-61131 languages supported by MonicoView 3.1 (Sequential Function Charts are not currently supported.) These programs can be executed periodically to perform control-based activities related to the I/O connected to the device as plug-in expansion modules or via communications links. Programs may use their own local variables, while global variables can be used to store shared information. A wide variety of system functions are provided, allowing rich control solutions to be created within your MonicoView 3.1 device.

## Why Use Control?

Not that much of what can be accomplished with the IEC-61131 engine could in theory be achieved via MonicoView 3.1's Programs category. The Control category, however, offers several significant advantages. First, the programming languages that the Control category supports are much more suited to machine and process control, while the C-like language used in the Programs category is more suited to data processing and managing the user interface. Second, programs within the Control category are executed on a periodic, semi-deterministic basis, while programs within the Programs category are more likely to be run in response to data changes or user actions. Finally, the Control category's function block library is more suited to control applications, while MonicoView 3.1's own programs are designed to interact with library functions that relate to communication and to the user interface.

## Learning IEC-61131

This chapter is not designed to teach how to program in IEC-61131. That is far too rich a topic for a manual like this and you are referred to many of the excellent online resources that are available. Monico's Technical Support team will be happy to help with MonicoView 3.1-specific questions and they will of course do their best to assist you more broadly, but they will not be able to make you into an IEC-61131 programmer over the phone.

## Working with Programs

Programs are the basic units of execution within MonicoView 3.1's IEC-61131 engine.


### Types of Program

Three types of program are supported:

- Main Programs are called by the IEC-61131 engine either on every scan or once every so many seconds. Your database should contain at least one Main Program, and may contain many more. The execution order of Main Programs is managed from the Project object in the Navigation List via the process described below.
- Sub-Programs are called by other programs. They will not be executed unless a Main Program calls them either directly or via another sub-program. They can be used to divide your control solution into more manageable sections, or to conditionally execute portions of the solution based on specific conditions.
- User-Defined Function Blocks are like sub-programs, but they have specifically defined inputs and output variables so that they can be placed within another program to implement a specific function. For example, a user-defined function block may be placed within a Function Block Diagram program, with its inputs and outputs wired to other blocks or to I/O points.

## Creating Programs

Programs are created in the usual way from the Navigation Pane under the Programs sections of the Control category. Menu options exist under the New button to create programs of all three types described above. When a program is created, you will be prompted for the program name and for the IEC-61131 language to be used:



The supported languages are:


- Structured Text, a high-level text-based language resembling the PASCAL programming language. Structured Text supports function calls to access other programs and the function library, plus several control constructs that can be used to create loops and to add decision-making capabilities.
- Function Block Diagram, a graphical language that allows function blocks to be wired together to represent the flow of data between them. Each function block will have one or more inputs and one or more outputs. These can be connected to other blocks or to I/O points that represent to IEC-61131 variables.
- Ladder Diagram, the graphical language traditionally used to program PLCs, representing power flow from one rail to another through a series of simulated relay coils and contacts that map to IEC-61131 variables.
- Instruction List, a low-level text-based language resembling a form of assembly code. It lacks the high-level constructs of Structured Text, using jump and call instructions to implement flow control. Instruction List is not recommended for new applications and has been deprecated in the later IEC-61131 standards.

## Editing Programs

When a program is selected, a suitable editor will be shown in the Editing Pane. The exact form of the editor will depend upon the language in which the program was created. The following sections describe each editor in turn.

### The Structured Text Editor

The picture below shows the editor used for programs written in Structure Text:




Instructions are entered and edited just as one would into any Windows text editor, except that variables, operators and function calls may be dragged from the Resource Pane and dropped in the

text. As with other editors, pressing **CTRL+T** will validate the code and place any errors in the Global Error List, where they can be accessed via the **F8** and **F4** key sequences.

## The Function Block Diagram Editor

The picture below shows the editor used for programs written in Function Block Diagram:




Variables and both standard and user-defined function blocks can be accessed via the Resource Pane and placed within the program. Function blocks may optionally include variables bound to their inputs and outputs if the appropriate option is selected from the Options menu in the toolbar. Once elements have been added, placing your mouse cursor on one of the input or output connection points will allow you to drag a wire to another block to create a connection and thereby indicate the flow of data. The picture below shows this process being used to link a variable to the input of a comparison operator:



Commands exist on the Function Block Diagram editor toolbar to control the zoom level at which the diagram is shown, to turn on or off the grid, and to add a variety of standard items to the program. As with other editors, pressing **CTRL+T** will validate the code and place any errors in the Global Error List, where they can be accessed via the **F8** and **F4** key sequences.

## The Ladder Diagram Editor


The picture below shows the editor used for programs written in Ladder Diagram:



As with programs written in Function Block Diagram, Variables and both standard and user-defined function blocks can be accessed via the Resource Pane and placed within the program. In addition, a variety of standard ladder diagram elements can be accessed directly from the toolbar, allowing contacts and coils to be added more easily. Commands exist on the Function Block Diagram editor toolbar to control the zoom level at which the diagram is shown, to turn on or off the grid, and to add a variety of standard items to the program. As with other editors, pressing **CTRL+T** will validate the code and place any errors in the Global Error List, where they can be accessed via the **F8** and **F4** key sequences.

## The Instruction List Editor

The picture below shows the editor used for programs written in Instruction List:




Instructions are entered and edited just as one would into any Windows text editor. Note that the low-level nature of Instruction List does not allow access to Resource Pane items beyond variables. As with other editors, pressing **CTRL+T** will validate the code and place any errors in the Global Error List, where they can be accessed via the **F8** and **F4** key sequences.

## Converting Programs

Programs may be converted from one language to another by right-clicking on a program in the Navigation List and selecting the one of the Convert options from the context menu. Note that the conversion process cannot be undone and clears the global undo list. Note also that not all language constructions can be converted. If the conversion fails, an appropriate error message will be displayed explaining why.

## Program Properties

The Properties tab in the Editing Pane can be used to access a program's properties:



- The *Execution* property is used to control when the program is executed. For programs that are not Main Programs, it will always be set to Called by Another Program and the remaining properties will be hidden. For Main Programs, a setting of Called on Each Cycle will result in the program being called each time the IEC-61131 engine completes

a scan. A setting of Called Periodically will result in the program being called at a rate defined by the other properties. A setting of Do Not Execute can be used to disable a program during testing.


- The *Period* and *Phase* properties are used to control the rate at which a Main Program set for periodic execution will be run. The *Period* property defines how many scans will elapse between one invocation of the program and the next, such that this value multiplied by the scan time will define the rate at which the program will run. The *Phase* property can be used to shift the scans on which programs of a given period will execute. It should be set to a value between 0 and the value specified by the *Period*. A program will execute when the remainder of the scan number divided by the period is equal to the phase. For example, if Program 1 and Program 2 both have their period set to 5 and their phase set to 0, they will both execute on scans 0, 5, 10 and so on. If the phase of Program 2 is changed to 1, it will now execute on scans 1, 6, 11 and so on. The phase can thereby be used to balance the execution load on a system with many periodic programs by distributing them between individual scans.

## Using Variables

The IEC-61131 engine works upon variables. These variables may be internal to the Control category or may be mapped to the other MonicoView 3.1 data items such as tags, expressions, or references to communications or I/O data points.


## Creating Variables

Variables can be created in the Navigation List under the Local Variables folder of a program or under the Project Variables folder of the project. Local Variables are only visible to the program to which they belong while Project Variables are visible to all programs and can be used to store information that is shared within the project. When a variable is created, you will be prompted for its name and its IEC61131 data type:



## Variable Properties

Each variable has the following properties:




- The *Data Source* property is used to specify whether the variable is internal to the IEC-61131 engine or whether it should be mapped to an expression, a MonicoView 3.1 tag or to some other data item. Its operation is just as described in the earlier chapter on tags. If a variable is mapped to a MonicoView 3.1 tag, the IEC-61131 data type must be suitable for direct conversion to the tag's data type.
- The *Data Type* property is used to specify or modify the IEC-61131 data type of the variable. If the type is changed after the variable has been referenced in a program, you may be required to rebuild your control project and to correct any resulting errors. Refer to later in this chapter for more information.
- The *String Length* property is used only for variables of type `STRING` and is used to indicate how many characters the string will be able to store.
- The *Extent* property is used to indicate whether this variable is a single data item or a one-dimensional array. If a setting of Array is selected, a further property will appear allowing the length of the array to be specified.
- The *Flags* property is used to restrict access to a variable by marking it as read only. This can be used to prevent MonicoView 3.1 tags from being changed or to otherwise protect data that has been configured via Initial Values.
- The *Initial Value* property is used to specify to what value or values this variable should load upon a cold start where retentive data is not used, or upon the first execution of this database by a given target device. For complex data types, a Pick button will be presented to allow the data to be edited.


## Parameters

Parameters are somewhat like local variables but while all programs can have local variables, parameters exist only for User-Defined Function Blocks. They are shown in a separate folder within the Navigation List and have slightly different properties. For example, each parameter may be specified as an Input, an Output or both. And parameters cannot be mapped to MonicoView 3.1 data items. Rather, upon execution of the function block, the input parameters will be loaded with the data bound to the block via the program that is invoking it. After execution, the values placed in the output parameters will be passed on to whichever elements in the calling program consume that data.


Consider a User-Defined Function Block configured as follows:



It contains a very simple piece of code which simply adds its two inputs:




And it is invoked from another program in the following manner:



Before the User-Defined Function Block is executed, its `In1` parameter will be set to the contents of `Variable2` and its `In2` parameter will be set to a constant value of 1. The function block will then run and it will place `Variable2+1` into its `Out` parameter. The calling program will then take this output and store it in `Variable3`, completing the operation.

## Project Properties

Selecting the Project element in the Navigation List allows access to properties that relate to the execution of the entire project. These properties are shown below:



- The *Program Execution* property is used to globally enable or disable IEC-61131 execution. It is by default set to disabled to avoid the display of certain prompts that are required when downloading to devices that contain a running instance of the IEC-61131 engine. **Be sure to set this property to Execute Periodically or your programs will not execute.**
- The *Start Mode* property is used to define the state of retained variables upon power-up. If Cold Start is selected, the initial values will be used and the retentive values will be discarded. If Warm Start is selected, the retentive values will be used if they are available, with the initial values used as a fallback.
- The *MonicoView Action* properties are used to define MonicoView programs or other actions that will be executed by the IEC-61131 engine at startup and before each scan. These actions are performed within the main scan, and care must be taken not to execute complex code that will prejudices the requested scan time. Note that you do

not require an IEC-61131 license in order to use these actions. Any device that can support MonicoView control will run these actions even if it requires but lacks a license for the IEC-61131 engine.

- The *Cycle Time* property is used to define how often the IEC-61131 engine should execute all the programs set as Called on Each Cycle. It also provides the timebase for the periodic execution mechanism described above.
- The *Execution Order* property is used to control the order in which Main Programs will be executed by the IEC-61131 engine. The programs shown in the list can be moved up and down using the buttons on the attached toolbar.

## Project Rebuilding


Certain changes may require that you rebuild your IEC-61131 programs to accommodate, for example, a change in the type of a global variable. The **CTRL+B** sequence can be used to accomplish this, as can the hammer icon in the toolbar or the Rebuild option in the Control menu. MonicoView 3.1 will also prompt you before downloading your database if the database contains programs or other control elements that need to be rebuilt.

## IEC-61131 Debugging

The IEC-61131 system supports two debugging modes where the execution state of a program and the associate data items can be viewed from within the associated editors.


- Offline Emulation mode runs the control program on your Windows-based configuration PC, emulating the behavior that can be expected when the database is downloaded to the target device.
- Online Debugging mode downloads the database to the target device and then allows you to debug the control programs within the MonicoView 3.1 configuration tool as they execute on that device.

The debugging modes are activated via the Play button control on the toolbar. This button displays a menu allowing the appropriate mode to be selected, at which point the current editor will switch into debug mode:




The editor is framed with a double rectangle as a reminder that debug mode has been activated, with the rectangle being drawn in blue for offline mode and red for online mode. The editor contents can no longer be changed, but the current values of data items are shown in the appropriate locations, as shown in the close-up below:





As the program executes, the values of Variable2 shown in the program will be updated in real time. If you wish to edit the value of a variable, double-click on the variable to display the editing window:



A new value can be entered into the box and the Force button pressed, or the various checkboxes can be used to update the individual bits of the variable. Always take care when editing values associated with control systems connected to operating machinery!

Other buttons on the toolbar can be used to control the debugging process:



The Play button or the Stop button can be used to halt emulation or to disconnect from an online debugging session. The Pause button can be used to stop the execution of the program, allowing the Step button to be used to single-step through the execution. The Pause button will be highlighted and the Step button made available when this mode is selected. Pressing Pause again will resume normal execution. Single stepping is very useful in the text-based programming languages, as it allows program flow to be verified. Note that disconnecting an online debugging session while the system is paused will leave the system in that state. A warning message to this effect will be displayed.




# Chapter 18 Using Connectors

MonicoView 3.1 connectors allow tag data and device status information to be pushed to the cloud or to an on-premises SCADA system. Support is provided for JSON-based MQTT to Amazon Web Services™ (AWS), Microsoft Azure and the Google Cloud Platform™ service, and for Sparkplug-based MQTT to packages such as Inductive Automation's® Ignition® SCADA system. A generic JSON-based MQTT driver is also provided to allow connectivity to a wide variety of other systems, including B-Scada's Status Enterprise system and Kepware's® MQTT driver.

## Configuring Connectors

MonicoView 3.1 connectors are configured via the Communications section in the Navigation pane.



## Common Settings


The connectors have very similar properties, split over the following tabs:

- The *Service* tab is used to configure the connector-specific information.
- The *Network* tab is used to configure the underlying connection options.
- The *Device Data* tab specifies the device status data to be pushed to the server.
- The *Tag Data* tabs specifies the tag data that will be pushed to the server.

## Network Options

The Network tab is used to configure the underlying connection options that are used by the connector. The default settings will be appropriate for the connector in question but may need adjustment if for example you are connecting to a non-standard port.

The Network options are shown below.




connection will be closed and re-opened. The setting need not be changed unless instructed by Technical Support.

- The *Keep Alive Time* is used to define how often an MQTT keep-alive packet should be sent to the server. These packets are used to ensure that the connection is kept open and that the server is still responding to requests.
- The *Back Off Time* is used to define how long the connector should initially wait before trying to re-establish communications after a failed connection to all defined hosts. The delay will start at this value and then double after each cycle until it reaches the time specified by the *Back Off Limit* property. Smaller values will allow connections to be re-established more quickly, but at the cost of increased bandwidth usage when there are no hosts are available.
- The *Debug Output* property is used to enable or disable the printing of advanced diagnostic information to the system's various debug consoles. This information will be of a technical nature and is not 100% documented. It is meant for use by Monico technical support or for more advanced users. Refer to the chapter on *Advanced Debugging* for information on how to configure debug consoles.

## Device Data Options

The Device Data tab is used to control how and when device status information is pushed to the server. The connectors do not currently pass anything useful in the device data block, but future releases will provide information on the device hardware, its revision information, and its software load. GPS position or cellular signal data may optionally be included if available.

The Device Data options are shown below.




- The *Transfer Mode* property is used to control how the device data will be transferred. A setting of Disabled will prevent the data being transferred; a setting of Periodic will send the data on a periodic basis; and a setting of Triggered will send it on the rising edge of a triggering expression. Device data is transferred to the server whether it has changed or not.
- The *Update Rate* property is used to control how often the device data is pushed to the server when Periodic mode is selected. Device data will typically not be pushed too often, as it is not expected to change to any great extent.
- The *Request* property has two uses. In Periodic mode, it acts as a level-sensitive enable for the transfer, in that the transfer will only occur if the expression is true or undefined. In Triggered mode, it acts as an edge-sensitive trigger for the transfer, initiating the operation on a rising edge.

- The *Acknowledge* property is used in Triggered mode to provide feedback as to the status of the transfer. It should be set to a modifiable expression that will be set to *true* once the transfer has completed, and *false* once the Request property has returned to a false state.
- The *Include Location* property is used to indicate whether position information from a GPS receiver should be included in the device data block. At the time of writing, this property merely enables a placeholder in the JSON structure. No actual data is transferred. The *Include Cell Data* property is used to indicate whether signal strength and cell information from a cellular modem should be included in the device data block. At the time of writing, this property merely enables a placeholder in the JSON structure. No actual data is transferred.

## Tag Data Options

The Tag Data tabs are used to control which tags are pushed to the server, and how and when the transfer occurs. By default, four blocks of tag data are supported, but additional blocks may be created using the *Tag Set Count* property on the Service page. The multiple tag sets allow data to be pushed at different frequencies and allow writes from the server to the MonicoView 3.1 device to be limited to a restricted set of tags.

The Tag Data options are shown below.




- The *Transfer Mode* property is used to control how the tag data will be transferred. A setting of Disabled will prevent the data being transferred; a setting of Periodic will send the data on a periodic basis; and a setting of Triggered will send it on the rising edge of a triggering expression. Unless sent as a result of the *Force Update* property, tag data is only sent upon initial connection or when it has changed by more than a particular tag's deadband property. The special setting of Write Only prevents updates being published from the specified tags but allows them to still accept writes. This can be useful if you want to avoid writes being immediately reflected to the server.
- The *Data Buffering* property is used to enable or disable data buffering for this tag set. Refer to the section on Data Buffering later in this chapter for more information. Note that data buffering must also be enabled on the Services tab for this property to have any effect.
- The *Update Rate* property is used to control how often the tag data is pushed to the server when Periodic mode is selected. Different tag data sets will often have different settings, allowing more important data to be transferred more often.

- The *Force Update* property is used to ensure that the value of each tag is pushed to the server at least this often. If the setting is left at zero, tag data is only sent as described above under *Transfer Mode*.
- The *Request* property has two uses. In Periodic mode, it acts as a level-sensitive enable for the transfer, in that the transfer will only occur if the expression is true or undefined. In Triggered mode, it acts as an edge-sensitive trigger for the transfer, initiating the operation on a rising edge.
- The *Acknowledge* property is used in Triggered mode to provide feedback as to the status of the transfer. It should be set to a modifiable expression that will be set to *true* once the transfer has completed, and *false* once the Request property has returned to a *false* state.
- The *Tag Writes* property is used to indicate whether the connector should accept writes from the server to the tags in this set. The exact method by which the server sends a write will vary between connectors and is detailed below.
- The *Tag Naming* property is used to define how MonicoView 3.1 will generate the label for each tag in the JSON that it will create. By default, the tag's name as entered in the Navigation Pane will be used, but you may also select the tag's description, label or alias. When a localizable source is selected, the default translation will be used, no matter which language is selected for display in the user interface.
- The *Label Set* property is used to indicate whether or not the tag data from this set should be placed in a distinct object within the JSON data structure. See the section below on data layout for more information.
- The *Tag Structure* property is used to indicate how tags within MonicoView 3.1 folders should be represented in the JSON data structure. If Simple Tag List is selected, each tag will exist as a root level property of the tags object, with its name being equal to the dotted form of its MonicoView 3.1 name. If Folders with Short Names is selected, a JSON object will be created for each MonicoView 3.1 folder and the relevant tags will be placed in that object. Each tag's name will be equal to the last portion of its MonicoView 3.1 name. If Folders with Full Names is selected, the behavior will be similar, but the tag's name will be its full dotted form. See the section below on data layout for more information. Note that this property is not supported for connectors that do not use JSON for data representation.
- The *Array Layout* property is used to indicate how array elements should be represented in the JSON data structure. If Create Elements in List is selected, each array element will appear as a distinct tag, named after the tag and the element index. If Create Elements in Folder is selected, each array element will appear as a property within a JSON object named after the tag. See the section below on data layout for more information. Note that this property is not supported for connectors that do not use JSON for data representation.
- The *Send Properties* property is used to indicate whether MonicoView 3.1 should provide the various properties associated with the tag. If this feature is enabled, a JSON object will be created for the tag, and a subset of the tag properties accessible via the dot operator will be included in that object. A property named Value will also be created to hold the current tag data. Note that the connector treats the detailed tag properties as read-only and neither checks for changes nor sends such changes to the server. For the Sparkplug connector, this property is always enabled and is thus not displayed.

## Triggered Mode

When operating in Triggered transaction mode, the data transfer for device data or tags is controlled by a *Request* and *Acknowledge* property. The behavior is described in the text above, but the diagram below may make this clearer.



As can be seen, the transfer is triggered by the database setting the *Request* to *true*. Once the transfer has completed, the connector sets the *Acknowledge* to *true* and waits for the database to set the *Request* to *false*. Once this has occurred, the connector sets the *Acknowledge* to *false* and the cycle is ready to repeat.

## Connector Diagnostics

Each connector allows you to specify a numeric tag into which a value will be written that reflects the state of the connector. This provides a simple form of diagnostics, allowing you to ensure that you are successfully connecting to the cloud. The values that will be placed into the tag are as follows.

VALUE	CONNECTOR STATE
0	Starting up or recovering from a dropped connection.
1	Connecting to the server after identifying its IP address from the hostname.
2	Connected to the server but waiting for the Primary Application.
3	Connected to the server and ready to pass data.
4	Connected to the server and data updates have been published.

As can be seen, the transfer is triggered by the database setting the *Request* to *true*. Once the transfer has completed, the connector sets the *Acknowledge* to *true* and waits for the database to set the *Request* to *false*. Once this has occurred, the connector sets the *Acknowledge* to *false* and the cycle is ready to repeat.

## Data Buffering

MonicoView 3.1's MQTT connectors can be configured to buffer data within the device when a connection to the server is not available. If this option is not configured, no samples are taken when the service is offline, with the latest values being pushed to the server as soon as a connection is restored. Data buffering is controlled via the eponymous property on the connector's Service tab and can be set to indicate whether data should be buffered just to memory or whether the device's memory card should be used to provide further storage that will survive a power-cycle. In memory-based mode, the connector will buffer up to 14,400 values, this being 4 hours of data at one sample per second. In disk-based mode, the connector will attempt to buffer for as long as it can until it runs out of disk space.

If data buffering is enabled, messages submitted to the server have additional properties named *adhoc* and *historic*. The *adhoc* property is set to *true* to indicate data that was collected outside the



usual sampling schedule, while the *historic* property is set to *true* to indicate data that is being replayed from the data buffer.

In normal operation, both the *adhoc* and *historic* properties are *false*, but consider a situation where a device is configured to store data every minute, and then loses and regains connectivity to its server after a break of two hours. Immediately after the connection is restored, the connector will replay all 120 or so historical records that it stored, marking each as *historic* so that the backend knows, for example, not to update mimics or other status displays with stale data. Once the historical data has been replayed, the connector will immediately send a single reading containing live data. Readings would normally occur only exactly on the minute, but this reading will be sent immediately and marked as *adhoc*. If you are storing data to a database and only want data collected at the interval defined by the sampling period, the *adhoc* flag allows you to ignore values that are sampled off-schedule. You should still pass these values to any mimics or status displays, however, as you will want to ensure that fresh data is available as soon as possible.

For JSON-based connectors, the *adhoc* and *historic* properties are encoded in the JSON alongside the timestamp. For Sparkplug, the *adhoc* property is not supported, while the *historic* property is encoded using the protocol's `MetricIsHistorical` flag.

## JSON Data Layout

Connectors that use JSON for data transfer create a JSON fragment that contains the device and tag data. The fragment will typically be embedded as an object within a larger JSON structure defined by the requirements of the connector protocol. The descriptions below assume that the *Tag Naming* property is set to *Name*. If another naming source is used, the JSON will be modified to reflect that setting. Grouping by folders will then only occur if the naming source provides values that contain embedded periods.

A typical JSON fragment is shown below.

```
{
  "device": {
    "status": "okay",
    "cellular": {
      "valid": "false"
    }
  },
  "location": {
    "valid": "false"
  }
},
{
  "tags": {
    "Tag1": 0,
    "Tag2": 0,
    "Tag3": 0,
    "Tag4": 0
  }
}
```

Note that depending on how you view them, the objects and properties may be in a different order. The underlying structure will nonetheless be the same. As you can see, the fragment contains two objects, the first being *device* and the second being *tags*, plus a value that indicates that the connection is valid and a timestamp for the reported data.

## Connector Options

By default, MonicoView 3.1 encodes true-or-false values as strings rather than using JSON's specific Boolean format, but this can be overridden using the *Data Encoding* property of the connector's Service tab. Changing this property from *Standard* to *Use Booleans* will remove the

quotation marks from the true-or-false values, while changing it to Numeric Only will encode true as 1 and false as 0. This last option is only available on the Generic MQTT Connector and is typically used for platforms such as Ubidots which do not understand anything beyond numeric data values.

## Connection Status

As noted above, the JSON submitted by the connector contains a property called `connected` that is always set to `true` in normal messages. MQTT supports a mechanism called a Last Will and Testament (LWT) that allows a device to register a message to be posted to a specified topic by the broker if the connection is dropped. The JSON-based connectors typically register an LWT message containing just the `connected` property and a value of `false`. This ensures that the device twin or shadow will contain a `connected` value that accurately represents the device's connection status, and that telemetry-based applications will receive a message that similarly allows them to detect a broken connection.


## Device Data

The device object contains a property called `status` which is always set to `okay`, and objects called `cellular` and `location`. These two objects in turn contain a property called `valid` which is currently set to `false` as they are not functional at this time.


## Tag Data

In this example, the `tags` object contains four tags with no folder structure. This represents a simple database which has these four tags configured in the top level of the tag list. For more complex structure, various options exist to control how the tags are displayed.

Consider a database with the following tag structure.



Here we have four tags within a folder, and a further two tags at the top level. The second of these two tags is an array. In our connector configuration, we map all of these tags into the first tag data set as shown below, including four elements from the array.



With default settings, this will produce the JSON `tags` object shown below.

```
"tags": {  
  "Group1.Tag1": 0,  
  "Group1.Tag2": 0,  
  "Group1.Tag3": 0,  
  "Group1.Tag4": 0,  
  "Tag1": 0,  
  "Tag2 [0]": 0,  
  "Tag2 [1]": 0,  
  "Tag2 [2]": 0,  
  "Tag2 [3]": 0  
}
```

Here the four tags from the folder are encoded with their dotted names, the simple tag from the top level is encoded using its simple name, and the four array elements are encoded using names that represent the tag and the element index.

Note that certain cloud services do not support dots or square brackets in tag names. In these circumstances, the dots and the opening square bracket will be replaced with dashes, while the closing bracket will be removed. This resulting JSON fragment will look like this.

```
"tags" {  
  "Group1-Tag1": 0,  
  "Group1-Tag2" 0,  
  "Group1-Tag3": 0,  
  "Group1-Tag4": 0,  
  "Tag1": 0,  
  "Tag2-0": 0,  
  "Tag2-1": 0,  
  "Tag2-2": 0,  
  "Tag2-3": 0  
}
```

As noted above, the *Tag Structure* property can be used to control how tags within folders are represented in the JSON. The example above shows the default setting of Simple Tag List. If the Folders with Short Names option is selected, the JSON will be as follows.

```
"tags": {  
  "Group1" {  
    "Tag1": 0,  
    "Tag2": 0,  
    "Tag3": 0,  
    "Tag4": 0  
  },  
  "Tag1": 0,  
  "Tag2 [0]": 0,  
  "Tag2 [1]": 0,  
  "Tag2 [2]": 0,  
  "Tag2 [3]": 0  
}
```

As you can see, the tags from within the folder are now within a JSON object named after that folder, with the properties within the object being the last portions of the tag's names. In contrast, if the Folders with Full Names option is selected, the JSON will be as follows.

```
"tags": {  
  "Group1": {  
    "Group1.Tag1": 0,  
    "Group1.Tag2": 0,  
    "Group1.Tag3": 0,  
    "Group1.Tag4": 0  
  },  
  "Tag1": 0,  
  "Tag2 [0]": 0,  
  "Tag2 [1]": 0,  
  "Tag2 [2]": 0,  
  "Tag2 [3]": 0  
}
```

Here the object structure is the same, but the properties within the folder object are now named after the full dotted name of the relevant tag. This is less efficient than the short names form but has been requested by certain customers for their applications.

As further noted above, the *Array Layout* property can also be used to change how array elements are presented in the JSON. The examples so far have all been created with the property set to *Create Elements in List*. If we return the *Tag Structure* property to *Folders with Short Names* and set the *Array Layout* property to *Create Elements in Folder*, the resulting JSON will be modified as follows.

```
"tags": {  
  "Group1": {  
    "Tag1": 0,  
    "Tag2": 0,  
    "Tag3": 0,  
    "tag4": 0  
  },  
  "Tag1": 0,  
  "Tag2": {  
    "0": 0,  
    "1": 0,  
    "2": 0,  
    "3": 0  
  }  
}
```

Here a JSON object has been created for the array and properties have been created within this object to represent each element. This may provide a more natural representation of arrays within your application.

In all of the examples above, the *Send Properties* setting has been turned off. If this is enabled, a raw richer structure is created under each tag or array element. The JSON fragment below shows how a tag might be represented in such circumstances. The properties are as described in the *Tag Properties* section of the *Writing Expressions* chapter. Note how the tag has changed from a JSON value into an object, with actual data stored in the *Value* property.

```
"tags": {  
  "Group1": {  
    "Tag1": {  
      "Deadband": 0,  
      "Description": "This is Tag1",  
      "Label": "Group1.Tag1",  
      "Maximum": 1234,  
      "Minimum": 0,  
      "Name": "Group1.Tag1",  
      "Prefix": "",  
      "TextOff": "",  
      "TextOn": "",  
      "Units": "",  
      "Value": 22  
    }  
  }  
}
```

One final option exists that may modify the tags object within the JSON structure, namely the ability to label tag data sets. By default, all tags data is placed directly under the tags object, even if that data is sourced from multiple tag data sets. Setting the *Label Set* property to Yes will create an intermediate object named after that set under tags object, modifying the JSON to look similar to this.

```
"tags": {  
  "set1": {  
    "Group1.Tag1": 0,  
    "Group1.Tag2": 0,  
    "Group1.Tag3": 0,  
    "Group1.Tag4": 0  
  }  
}
```

Here the set1 object indicates that all these tags came from the Tag Data 1 tab.

## Site Naming

Some connectors allow a *Site Name* property to be defined on their Service tab. If defined, this value will be included as a property called *cid* under each tag set and under the device object. The value will be included in all updates, whether or not it has changed, and is designed to allow the back-end to more easily associated each message with the device from which it originated. A sample JSON structure containing the *cid* property is shown below.

```
{
  "device": {
    "cid": "site-name"
    "status": "okay"
    "cellular": {
      "valid": "false"
    },
    "location": {
      "valid": "false"
    }
  },
  "tags": {
    "set1": {
      "cid": "site-name",
      "Tag1": 0,
      "Tag2": 0,
      "Tag3": 0,
      "Tag4": 0
    }
  }
}
```


Here the *Site Name* value of site-name is included at the device and tag set level.

## The Generic MQTT Connector

The Generic MQTT Connector is designed to publish data in JSON format to an arbitrary MQTT topic and to listen for writes by subscribing to another arbitrary topic. It is not optimized for operation with any particular cloud provider but does contain certain facilities to assist with integration with B-Scada's Status Enterprise product.

## Connector Settings

The settings for the connector are shown below.



- The *Enable Agent* property is used to enable or disable this connector.
- The *Tag Set Count* property is used to change the number of tag sets supported by the connector. Up to thirty tag sets may be created. Changes to this value cannot be undone and will clear the undo buffer.
- The *Update Mode* property is used to specify which data values should be sent in each update message. Send Changes will send only those values that have changed by more than their deadband since data was last sent. Send All If Any will send all the data values from a tag set if any values in that set changed by more than the deadband. Send All Data will send all the data on each update event, whether or not anything has changed.
- The *Reconnection* property is used to specify how the connector should behave when a connection is dropped and re-established. Send All Data will reset the history values used to detect changes, and thereby resend all the data. Per Update Mode will treat the reconnection update as a normal update and therefore use the same behavior as defined by the *Update Mode* property.
- The *Data Buffering* property is used to enable or disable data buffering. Refer to the specific section earlier in this chapter for more information. Note that data buffering must also be enabled at the tag set level if it is to occur.
- The *Host Name 1* and *Host Name 2* properties are used to specify the names of the MQTT servers to which the connector will publish data and from which it will receive subscription updates. They may be provided as an IP address or an actual hostname, but connections using TLS will typically require a name if the server certificate is to be validated. The connector will start by trying to connect to *Host Name 1* and will then move to *Host Name 2* if a connection cannot be successfully established. If neither host is responsive, the connector will wait for the back-off time and then begin the cycle again.
- The *Client ID* property is used to specify the client identifier that will be included in the MQTT frames. The exact interpretation of this value will vary according to the server to which you are connecting. The value is also used to construct the default topic names if these are not specified.
- The *Publication Topic* is used to specify the MQTT topic to which the connector will publish a JSON fragment containing the device and tag data. If you do not specify a value, \$mvi/generic/device-id/pub will be used, with the device-id portion being replaced by the *Client ID* property. The dollar sign will be omitted if the *Drop Dollar Sign* property is set to Yes.

- The *Subscription Topic* is used to specify the MQTT topic to which the connector will subscribe in order to receive JSON fragments containing tag writes. If you do not specify a value, `$mvi/generic/device-id/sub` will be used, with the `device-id` portion being replaced by the *Client ID* property. The dollar sign will be omitted if the *Drop Dollar Sign* property is set to Yes.
- The *Use Dollar Sign* property is used to instruct the connector to add an initial dollar sign from the default publication and subscription topics. Certain brokers such as ActiveMQ do not like the initial dollar sign.
- The *Force Into Root* property is used to flatten the entire JSON structure such that all values are included in the root object. This is designed for use with servers such as Ubidots which perform only very basic JSON parsing.
- The *Data Encoding* property controls how Boolean values are represented in the JSON sent to the server. The behavior is described earlier in this chapter. The Generic Connector supports an additional setting of *Numeric Only* which forces all data items into numeric form. Again, this is designed for use with servers such as Ubidots which perform only very basic JSON parsing.
- The *User Name* and *Password* properties are used to provide the authentication information to be included when the MQTT connection is established.
- The *Site Name* property is used to provide a string that will be included in every update published to the server, making it easier for the back-end application to identify the source of the update.
- The *Status* property is used to specify the numeric tag into which connector state information will be written. See the table earlier in this chapter for more details.

## Connector Operation

The connector will publish JSON fragments containing device and tag data to the *Publication Topic* specified in the configuration. The fragments will be formatted as described above, with the tags and device objects being at the top level of the fragment. The connector will also accept writes to MonicoView 3.1 tags when so configured. It does this by subscribing to the *Subscription Topic* specified in the configuration, expecting to see JSON fragments formatted in the same manner as the fragments that it publishes. For example, a simple fragment of `{"tags":{"Tag1":100}}` will write value 100 to Tag1, assuming of course that Tag1 is included in a tag data set that is configured to allow writes.


## The Amazon MQTT Connector

The Amazon MQTT Connector is a specialized connector designed to publish tag and device data to the reported section of the shadow object created for a thing within the AWS IoT environment. It also subscribes to changes to the desired section, allowing writes to be submitted to tags that are configured to accept changes. The connector implements TLS security using the certificates made available when an AWS IoT thing is created.

## Connector Settings

The settings for the connector are shown below.





- The *Enable Agent* property is used to enable or disable this connector.
- The *Tag Set Count* property is used to change the number of tag sets supported by the connector. Up to thirty tag sets may be created. Changes to this value cannot be undone and will clear the undo buffer.
- The *Update Mode* property is used to specify which data values should be sent in each update message. Send Changes will send only those values that have changed by more than their dead-band since data was last sent. Send All If Any will send all the data values from a tag set if any values in that set changed by more than the deadband. Send All Data will send all the data on each update event, whether or not anything has changed.
- The *Reconnection* property is used to specify how the connector should behave when a connection is dropped and re-established. Send All Data will reset the history values used to detect changes, and thereby resend all the data. Per Update Mode will treat the reconnection update as a normal update and therefore use the same behavior as defined by the *Update Mode* property.
- The *Data Buffering* property is used to enable or disable data buffering. Refer to the specific section earlier in this chapter for more information. Note that data buffering must also be enabled at the tag set level if it is to occur.
- The *Host Name 1* and *Host Name 2* properties are used to specify the names of the MQTT servers to which the connector will publish data and from which it will receive subscription updates. *Host Name 1* should match the name provided in the AWS IoT console on the Interact page of the thing's information, while *Host Name 2* will only be used in topologies involving redundancy. The connector will start by trying to connect to *Host Name 1* and will then move to *Host Name 2* if a connection cannot be successfully established. If neither host is responsive, the connector will wait for the back-off time and then begin the cycle again.
- The *Client ID* property is used to specify the name of the thing.
- The *Data Encoding* property controls how Boolean values are represented in the JSON sent to the server. The behavior is described earlier in this chapter.
- The *Certificate File*, *Private Key File* and *Server CA File* properties are used to specify the three files that were downloaded from the AWS IoT console when the thing was created. The public key file is not required.
- The *Site Name* property is used to provide a string that will be included in every update published to the server, making it easier for the back-end application to identify the source of the update.
- The *Status* property is used to specify the numeric tag into which connector state information will be written. See the table earlier in this chapter for more details.

## Connector Operation


The connector will publish JSON fragments containing device and tag data to the reported section within the shadow of the specified thing. If a corresponding tag value is created within the desired section of the shadow, the connector will update the tag if that tag is included in a data set with writes enabled. It will then remove the desired value from the shadow.

## The Azure MQTT Connector

The Azure MQTT Connector is a specialized connector that can either publish tag and device data to the reported section of the twin object created for a device within the Azure IoT environment, or to the device's Events topic. When operating in twin mode, the connector reads the desired section of the twin upon initial connection and then monitors it for changes, allowing writes to be submitted to tags that are configured to accept changes. In telemetry mode, the data will instead be published to the device's events endpoint. No matter which mode is selected, the connector subscribes to the device's devicebound endpoint, once again processing writes to tags that are configured to accept them. Either endpoint name can be changed if required by the application. The connector implements authentication using the device key associated with the Azure IoT device.

## Connector Settings

The settings for the connector are shown below.



- The *Enable Agent* property is used to enable or disable this connector.
- The *Tag Set Count* property is used to change the number of tag sets supported by the connector. Up to thirty tag sets may be created. Changes to this value cannot be undone and will clear the undo buffer.
- The *Message Type* property is used to specify the type of messages that the connector should send. Device Twin mode will send the reported status to the Azure twin and look for changes to the desired status. The Telemetry mode will send and receive telemetry messages and do not need twin support from Azure.
- The *Update Mode* property is used to specify which data values should be sent in each update message. Send Changes will send only those values that have changed by more than their deadband since data was last sent. Send All If Any will send all the data values from a tag set if any values in that set changed by more than the deadband. Send All Data will send all the data on each update event, whether or not anything has changed.

- The *Reconnection* property is used to specify how the connector should behave when a connection is dropped and re-established. Send All Data will reset the history values used to detect changes, and thereby resend all the data. Per Update Mode will treat the reconnection update as a normal update and therefore use the same behavior as defined by the *Update Mode* property.
- The *Data Buffering* property is used to enable or disable data buffering. Refer to the specific section earlier in this chapter for more information. Note that data buffering must also be enabled at the tag set level if it is to occur.
- The *Host Name 1* and *Host Name 2* properties are used to specify the names of the MQTT servers to which the connector will publish data and from which it will receive subscription updates. *Host Name 1* should match the hostname of the IoT hub created within Azure, while *Host Name 2* will only be used in topologies involving redundancy. The connector will start by trying to connect to *Host Name 1* and will then move to *Host Name 2* if a connection cannot be successfully established. If neither host is responsive, the connector will wait for the back-off time and then begin the cycle again.
- The *Host Name* property is used to specify the name of the MQTT server to which the connector will publish data and from which it will receive subscription updates. It should match the hostname of the IoT hub created within Azure.
- The *Client ID* property is used to specify the name of the IoT device.
- The *Device-to-Cloud* property is used to specify the name of the endpoint to which data will be submitted in the Telemetry mode. The full MQTT topic name will be device/device-id/messages followed by the specified endpoint name, with device-id being replaced with the Client ID property specified above. If no value is entered, the default endpoint name of events will be used.
- The *Cloud-to-Device* property is used to specify the name of the endpoint to which the connector will subscribe so that it can listen for writes. In Twin mode, the device twin will also be monitored for changes. The full MQTT topic name will be device/device-id/messages followed by the specified endpoint name, with device-id being replaced with the Client ID property specified above. If no value is entered, the default endpoint name of devicebound will be used.
- The *Data Encoding* property controls how Boolean values are represented in the JSON sent to the server. The behavior is described earlier in this chapter.
- The *Device Key* property is used to authenticate with Azure and should be set to the Primary Key displayed on the Device Details page of the associated device within the Azure management console. The connector will create an appropriate access token using this key each time it connects.
- The *Site Name* property is used to provide a string that will be included in every update published to the server, making it easier for the back-end application to identify the source of the update.
- The *Status* property is used to specify the numeric tag into which connector state information will be written. See the table earlier in this chapter for more details.

## Connector Operation

In twin mode, the connector will publish JSON fragments containing device and tag data to the `reported` section within the twin of the specified thing. If a corresponding tag value is created within the `desired` section of the twin, the connector will update the tag the connector will update the tag if that tag is included in a data set with writes enabled. The connector does not remove the desired value, as the Azure framework does not allow the `desired` section to be

altered by the device. This can make bidirectional data transfer complicated as a pending cloud write can unexpectedly override a local change.


In Telemetry mode, the connector will publish JSON fragments containing device and tag data to the device's `events` endpoint. The fragment will in addition to the usual data contain a timestamp and the Azure device name of the source device. The connector will subscribe to the device's `devicebound` endpoint and check any messages for a `tags` section that contains information that correspond to tags with writes enabled. A write to a tag may produce an event message reflecting the change. If this is not the desired behavior, place your writable tags in a tag set that is configured for Write Only operation.

## The Google MQTT Connector

The Google MQTT Connector is a specialized connector designed to publish tag and device data to the Google Cloud Platform (GCP). Updates are published to the events topic and writes to tags that are configured to be writable are accepted from the config topic. The connector implements security using locally-generated RS256 key pairs.

## Connector Settings

The settings for the connector are shown below.



- The *Enable Agent* property is used to enable or disable this connector.
- The *Tag Set Count* property is used to change the number of tag sets supported by the connector. Up to thirty tag sets may be created. Changes to this value cannot be undone and will clear the undo buffer.
- The *Update Mode* property is used to specify which data values should be sent in each update message. Send Changes will send only those values that have changed by more than their deadband since data was last sent. Send All If Any will send all the data values from a tag set if any values in that set changed by more than the deadband. Send All Data will send all the data on each update event, whether or not anything has changed.
- The *Reconnection* property is used to specify how the connector should behave when a connection is dropped and re-established. Send All Data will reset the history values used to detect changes, and thereby resend all the data. Per Update Mode will treat the reconnection update as a normal update and therefore use the same behavior as defined by the *Update Mode* property.

- The *Data Buffering* property is used to enable or disable data buffering. Refer to the specific section earlier in this chapter for more information. Note that data buffering must also be enabled at the tag set level if it is to occur.
- The *Host Name 1* and *Host Name 2* properties are used to specify the names of the MQTT servers to which the connector will publish data and from which it will receive subscription updates. *Host Name 1* should match the hostname of the IoT hub created within Azure, while *Host Name 2* will only be used in topologies involving redundancy. The connector will start by trying to connect to *Host Name 1* and will then move to *Host Name 2* if a connection cannot be successfully established. If neither host is responsive, the connector will wait for the back-off time and then begin the cycle again.
- The *Project Name* property is used to specify the name of the GCP project. The *Region Name* property is used to specify the region in which the device registry was created. The *Registry Name* property is used to specify the name of that registry. The *Device Name* property is used to specify the name of the device in the registry.
- The *Data Encoding* property controls how Boolean values are represented in the JSON sent to the server. The behavior is described earlier in this chapter.
- The *Authentication* section contains operations for managing the cryptographic key pair used to identify a device to the GCP. When the connector is first enabled, a public and private key is created. The public key can be exported to a file or placed on the clipboard. It must be provided to GCP with a type of RS256 when the corresponding device is created. If you are connecting to a device that has an existing key pair, you may import the private key and override MonicoView 3.1's own values. An option is also provided to generate a new key pair. The new public key must be provided to GCP if the connector is to pass data successfully.
- The *Site Name* property is used to provide a string that will be included in every update published to the server, making it easier for the back-end application to identify the source of the update.
- The *Status* property is used to specify the numeric tag into which connector state information will be written. See the table earlier in this chapter for more details.

## Connector Operation


The connector will publish JSON fragments containing device and tag data to the events topic and listen for incoming messages on the `config` topic. Any tag data in the incoming messages will be routed to appropriate tags, assuming they are configured to accept writes.

## The Sparkplug MQTT Connector

The Sparkplug MQTT Connector is a specialized connector designed to publish tag and device data to the Ignition SCADA system from Inductive Automation. In contrast to the textual JSON representation used by most other connectors, Sparkplug uses a binary representation that is slightly more efficient. This also means that most of the tag data options relating to JSON formatting are not available for this connector.

## Connector Settings

The settings for the connector are shown below.



- The *Enable Agent* property is used to enable or disable this connector.
- The *Tag Set Count* property is used to change the number of tag sets supported by the connector. Up to thirty tag sets may be created. Changes to this value cannot be undone and will clear the undo buffer.
- The *Update Mode* property is used to specify which data values should be sent in each update message. Send Changes will send only those values that have changed by more than their deadband since data was last sent. Send All If Any will send all the data values from a tag set if any values in that set changed by more than the deadband. Send All Data will send all the data on each update event, whether or not anything has changed.
- The *Data Buffering* property is used to enable or disable data buffering. Refer to the specific section earlier in this chapter for more information. Note that data buffering must also be enabled at the tag set level if it is to occur.
- The *Host Name 1* and *Host Name 2* properties are used to specify the names of the MQTT servers to which the connector will publish data and from which it will receive subscription updates. They may be provided as an IP address or an actual hostname, but connections using TLS will typically require a name if the server certificate is to be validated. The connector will start by trying to connect to *Host Name 1* and will then move to *Host Name 2* if a connection cannot be successfully established or if the *Primary App ID* property is defined and the server reports that the primary application is offline. If neither host is responsive, the connector will wait for the back-off time and then begin the cycle again.
- The *Client ID* property is used to identify the connector to the MQTT server. It is not used in the presentation of data and can be set to any value. For most applications, it makes sense to use a value that is unique to this MonicoView 3.1 device.
- The *Group ID* and *Node ID* properties are used to specify how this device should presents its data within the Ignition tag browser. The strings are arbitrary, but should together form a unique value that identifies this MonicoView 3.1 device.
- The *Primary App ID* property is used to define the identifier of the primary application that must be connected to the server before the connector will start passing data. If the primary application is reported as offline or if no report of an online status is received within 75% of the keep-alive time, the connector will switch to an alternative server if one is available. Leaving this field blank will disable this functionality. If you



enter a value for this field, it must match the Primary Host ID field in the configuration of the Ignition MQTT Engine, or the equivalent field of whatever primary application you may be using. If the fields do not match, the connector will not pass data to the server.

- The *User Name* and *Password* properties are used to authenticate the connector to the MQTT server. The default values used by Ignition are `admin` and `changeme`, and these are similarly the defaults for this connector
- The *Server CA File* property is reserved for future use.
- The *Status* property is used to specify a numeric tag into which state information will be written. See the table earlier in this chapter for more details.

## Connector Operation

The connector will publish device and tag data to Ignition and will respond to tag writes if so configured. Tags within folders are placed in the corresponding folders within the Ignition tag browser, and array elements are placed within folders that correspond to the underlying tag. If the Primary App ID is defined, the connector will ensure that the corresponding application is connected to the server and is reported as online before data is transmitted. If the application is not connected, the server will attempt to contact an alternative host if one is defined. If the application cannot be found on either host, the connector will wait for the back-off time and begin the process again until the primary application is detected.





# Chapter 19 Using Services


In addition to the core functions described earlier in this document, the Communications category also allows various services to be configured. These services appear in the Navigation Pane under the Services icon, and each is described below.

## Using the OPC UA Server

MonicoView 3.1 contains an OPC UA server that allows the tags defined by your database to be exposed using the OPC UA protocol. The server supports anonymous connections via the TCP protocol on a user-defined port, and uses the None security profile. The server supports subscriptions and publication and so can provide updates to clients without data values having to be read continuously. Note that it is important when configuring the OPC UA server to provide some mechanism of time synchronization, as the protocol depends upon accurate timestamps. Please refer to the Time Management section later in this chapter for information on how to configure this functionality.

## Configuring the Service

The OPC UA Server is configured via the associated icon in the Navigation Pane:



## Service Properties

The following properties can be configured via the Service tab:

- The *Enable Server* setting enables or disables the OPC UA server.
- The *Server Name* property is used to define the server name that will be returned to the OPC UA client during the connection process. The name should typically be distinct for every OPC UA device connected to a given network. If you leave the name blank, the server will use the endpoint host name.
- The *Endpoint Host* property is used to define the host portion of the endpoint name that will be returned to the OPC UA client. It typically corresponds to the DNS name used to identify the unit. The full endpoint name will be this name prefixed with `opc.tcp://` and followed by a colon and the TCP port number. If you leave the name blank, the server will use the device's name as defined on the Zero Config tab. This will itself default to the `red-xx-yy-zz.local` form discussed elsewhere in this manual.

- The *Listen on Port* property is used to define the TCP port on which the server will listen. The default value is 4840 and corresponds to the default value used by most OPC UA clients.
- The *Debug Output* property is used to enable or disable the printing of advanced diagnostic information to the system's various debug consoles. This information will be of a technical nature and is not 100% documented. It is meant for use by Monico technical support or for more advanced users. Refer to the chapter on *Advanced Debugging* for information on how to configure debug consoles.
- The *Model Layout* property is used to select between the default data model layout and a simplified layout where the tags are placed directly in the server's Objects folder. The simplified layout produces shorter data item path names, but at the expense of removing a mechanism that is specifically designed to provide backward compatibility as software updates are deployed. It is recommended that you use the default model unless you have strong reasons otherwise.
- The *Tag Structure* property is used to define how the server will present data tags within in the OPC UA model. A setting of Simple Tag List will list all of the selected tags under a single folder, using dotted names to represent any folder structure created in MonicoView 3.1. A setting of Folders with Short Names will duplicate the folder structure created in MonicoView 3.1, naming the tag nodes with the short names of the tags. A setting of Folders with Full Names will similarly duplicate the folder structure, but will name each tag node with its full dotted name.
- The *Array Layout* property is used to define how MonicoView 3.1 will present array elements in the data model. A setting of Create Elements in List will create an element named `Tag[x]` for each array element and will place these elements directly in the folder that contains the tag. A setting of Create Elements in Folder will create a folder called `Tag` in the same location, and will create elements with numerical names within that folder.
- The *Show Properties* property is used indicate whether or not the server should expose the various tag properties described in the Writing Expression chapter in order to allow access to additional information. If you enable StateText, any tags that use multi-state format objects will also have a property that defines the number of states that they represent, and a further property that presents an array of strings that can be used to convert the tag's numeric value to strings.
- The *Record History* property is used to indicate whether historic data should be recorded to the memory card and made available via the OPC UA protocol. Data will be recorded at the rate specified by the Sample Rate property, using up to the proportion of the memory card specified by *Disk Usage Limit*. See the Historic Data section below on historic data for more information.
- The *Allow Writes* property is used to enable or disable writes to tags.

## Data Properties

The Data tab is used to define the tags to be exposed by the server. Tags within folders are listed by their full dotted names. MonicoView 3.1 may or may not convert this flat list back into a folder hierarchy depending on the setting of the Tag Structure property.

## Data Presentation

In its default configuration, the OPC UA server exposes the configured tag in two ways:

- The `Arrays` folder contains three arrays, each containing as many elements as there are tags exposed by the device. The `Integer` array contains the integer representation of numeric tags, and zeros where string tags are located; the `Double` array contains the

floating-point representation of numeric tags, and zeros where string tags are located; and the `String` array contains the string representation of each tag, converted using the appropriate format object.

- The `Tags` folder contains an entry for each exposed tag, optionally organized using folders that align with the database's tag structure and with each tag optionally containing additional properties related to that tag.

Both folders are located in the `v1` folder under the `Objects` folder in the server's OPC UA data model. The `v1` folder provides a versioning mechanism such that existing deployments will not be broken by subsequent releases. If the data model is changed in a manner that is incompatible with existing versions, the old model will be retained under the `v1` folder and the new model will be included under a folder called `v2`. Any future changes made under `v1` are therefore guaranteed to be compatible with existing deployments.

The default model can be overridden with the *Model Layout* property, as described above.

## Historic Data


The OPC UA Server can be configured to store historic data so that readings can be recovered upon the restoration of a lost connection to the server. While data can be extracted from arbitrary points in the history buffer, performance will be limited. The feature is not intended to support the random browsing of data. Rather, it is expected that a client such as the OSIsoft PI Historian will read any missing data items using this functionality and then return to accepting published data. Further, it should be noted that the historic data feature used considerable memory card bandwidth, especially when operating at high sample rate with large numbers of tags. While it has been tested with 500 tags and a one-second sample rate, it is not recommended that these numbers be exceeded, or that other memory card heavy operations such as MQTT store-and-forward be used the same time. Please review Monico's website for technical notes on integrating with various historians via this feature.

## Using Time Management

MonicoView 3.1 contains facilities to allow you to synchronize the time and date within the target device with a variety of sources. The Time Manager can also maintain information about the device's time-zone, and whether daylight saving time is currently enabled. In fact, having accurate time-zone information available is vital to proper synchronization, as the various synchronization methods are all designed to work with Universal Coordinated Time, also known as UTC or Greenwich Mean Time. An accurate UTC time may also be required if you are using TLS or SSL to connect to a remote device, as the server certificate validation process may optionally check the expiration date of the certificate. MonicoView 3.1 can act both as a client and a server, either requesting the time from or providing the time to other MonicoView 3.1 devices. Note that the server implementation does not currently support third-party clients.

## Configuring the Service

The Time Manager is configured via the associated icon in the Navigation Pane:



The *Enable Time Manager* property is used to control access to the other facilities. If it is not checked, MonicoView 3.1 will operate in the local time zone only and will have no knowledge of timezones or other time management information.

## Time Server

Appropriately configuring the *Enable SNTP* property of the Time Server section will instruct MonicoView 3.1 to act as an SNTP server. This will allow other MonicoView 3.1 devices to synchronize their own clocks to the clock of this unit. Note that MonicoView 3.1's implementation of SNTP is not fully RFC-compliant, and is not supported as a source of synchronization for third-party clients.

## Time Client

Selecting Yes in the *Enable SNTP* property of the Time Client section will cause MonicoView 3.1 to synchronize its clock with another MonicoView 3.1-based device or with another SNTP-based time source accessible via the local network or via the Internet. The time client has the following additional properties:

- The *Linked DST* property is used to instruct the SNTP client to attempt to read the current Daylight Savings Time setting from the SNTP server. As this facility is not a part of the standard SNTP protocol, it will only operate if another MonicoView 3.1 device is specified as the server. The facility is useful in that it allows the Daylight Savings Time adjustment to be made via a single device on the factory net-work, with the other devices then following the central setting.
- The *SNTP Mode* and *SNTP Server* properties are used to configure the IP address of the Simple Network Time Service server. If Configured via DHCP is selected, at least one Ethernet port must be configured to use DHCP and the server must be configured to designate a server via option 42. The default server setting for Manual Configuration is a publicly-accessible server maintained by the National Institute of Standards and Technology (NIST) in the United States. This will only be suitable if the device has Internet access.
- The *Enable GPS* property is used to instruct the time client to use a GPS unit connected via NMEA- 0183 as an alternative method of obtaining the current time. The unit may be connected to any serial port using the appropriate driver.
- The *Frequency* property specifies how often MonicoView 3.1 should attempt to synchronize its time by the methods enabled above. MonicoView 3.1 will always attempt to sync twenty seconds after power-up, and will then sync as specified by this property. If a given attempt to sync fails, the unit will retry every 30 seconds until it is successful in finding a suitable time source.

## Time Stamps

MonicoView 3.1 can record a variety of log files on the target device's memory card and each log entry has a time stamp. By default, the time stamp comes from the local real time clock and is in the local time zone. The behavior can be changed via the following properties:

- The *Time Source* property is used to indicate from where the time stamps should be obtained. The default setting obtains the time from the unit's own real time clock, while the alternative allows the use of an expression to define the current time. This expression is typically a reference to a data item in a connected device, allowing that device's clock to be used for data logging. The expression must be entered in the *Expression* property.
- The *Sync Clock* property is used to indicate whether the local real time clock should be synced to the alternative time source specified above. If this option is enabled, the local clock will be synchronized on startup and periodically thereafter. The local clock will be used as a time stamp source if the alternative source is not available due to comms problems.
- The *Time Zone* property is used to indicate the time zone to be used for time stamps. It is only applicable when the local real time clock is configured as the source for time stamps. Selecting Local will use the local time zone; selecting UTC will use Universal Coordinated Time instead. This latter setting produces log files which are more easily portable across time-zones, and which do not suffer from discontinuities when switching in and out of Daylight Savings Time.

## Choosing an SNTP Server

When configuring the SNTP client, you have several options when selecting a server.

If you have a Windows- or Unix-based time server as part of your network infrastructure, you should ultimately synchronize to this source to ensure enterprise-wide synchronization. If you have several MonicoView 3.1 devices on the same network, though, you will find it better to nominate one of these as the master device for the purpose of setting Daylight Savings Time, and then have that device alone synchronize to the enterprise time source. You can then configure the other devices to synchronize to the master device, and enable the Linked DST facility to propagate the Daylight Savings Time setting around your factory.

If you have no enterprise time source available, you may choose to nominate a single MonicoView 3.1 device as the point where an operator will set the time, and then have other devices synchronize to that source. Alternatively, if your installation provides TCP/IP access to the Internet via either Ethernet or a modem connection, you may configure the SNTP client to synchronize to a public time server. An example of this would be 192.6.15.28, which is the current IP address of a public time server provided by NIST.

A list of other servers can be found at:

<http://support.microsoft.com/kb/262680>

If you have DNS enabled on your device, you should ideally use a DNS name to refer to the SNTP server. For the NIST servers referenced above, a name of `time.nist.gov` will randomly choose one of the active servers in the server pool. This mechanism provides better load balancing and redundancy, while also being immune to IP address changes.

## Time-Zone Configuration

As mentioned above, a MonicoView 3.1 device must have knowledge of the current time-zone if it is to use advanced time management. This information can be provided in two ways. The easiest method is to use the Send Time command on the Link menu of the MonicoView 3.1 configuration software. In addition to setting the clock, this command also sends the PC's current time zone and

the status of Daylight Savings Time. MonicoView 3.1 will store this data in nonvolatile memory, and use it from that point forward. Obviously, you should be sure that the PC contains valid time and date information before sending it to the unit!


The alternative method is to use the system variables `TimeZone` and `UseDST`. The former holds the number of hours by which the local time zone differs from UTC, and may be either negative or positive. For example, a setting of -5 corresponds to Eastern Standard Time in the United States. The latter contains either 0 or 1, depending on whether Daylight Savings Time is active. Editing either of these variables via the user interface will result in the unit's clock changing to take account of the new settings. For example, enabling Daylight Savings Time will move the clock forward one hour, while disabling it will move it back. A typical database will only need to expose `UseDST` for editing by the user, and even this may not be necessary if the Linked DST facility described above is in use.

## Using the FTP Server

MonicoView 3.1's FTP server provides a method to exchange files between a MonicoView 3.1 device and a remote computer running an FTP client application. The MonicoView 3.1 device will act as a server, waiting for client applications to connect and download or upload files.

## Configuring the Service

The FTP Server is configured via the associated icon in the Navigation Pane:



The following properties can be configured:

- The *Anonymous Access* property defines the rights, if any, granted to a user accessing the server using anonymous FTP. A setting of Disabled will prevent anonymous access. A setting of Read-Only will allow the user to download files from the memory card, but will prevent uploads. A setting of Read-Write will allow both uploads and downloads.
- Enable the *Record Log File* to keep a log of all FTP interactions in the root directory of the memory card. This file can be useful when debugging FTP operations, but it will tend to degrade performance slightly.
- The *Debug Output* property is used to enable or disable the printing of advanced diagnostic information to the system's various debug consoles. This information will be of a technical nature and is not 100% documented. It is meant for use by Monico technical support or for more advanced users. Refer to the chapter on *Advanced Debugging* for information on how to configure debug consoles.



## FTP Security


As the FTP Server can provide full access to the memory card, it is high recommended that you use the Security Manager to define specific username and password combinations and to grant those users the appropriate access rights. In general, you should avoid granting anonymous access, and you should especially avoid allowing anonymous writes.

## Using the OPCWorx Proxy

The OPCWorx Proxy is a service that gives Monico's OPCWorx software access to the device's tag database. It does not implement any OPC-style communications itself, but rather provides a mechanism for OPCWorx to provide a PC-based OPC server that can expose tags from one or more MonicoView 3.1 devices. In addition, the OPCWorx proxy can accept connection from the Monico OPC Driver. This driver allows one device to access the tags in another device without the need to set up Modbus or some other register-based protocol.

## Configuring the Service

The OPCWorx Proxy service is configured via the associated icon in the Navigation Pane:



- The *Enable OPCWorx Proxy* setting enables or disables the service.
- The *TCP Port* option specifies on which port the service should listen. OPCWorx and the Monico OPC Driver by default expect to connect to port 790 and the default value should be suitable for most applications.
- The *Session Limit* property controls how many simultaneous sessions will be supported. It should be equal to at least one more than the maximum number of devices (either PCs running OPCWorx or other MonicoView 3.1 devices running the OPC Driver) that will be connecting to this device.
- The *IP Restrictions* property group allows access to the server to be limited to certain IP addresses, either for all access or for writes to tags. It can be used to ensure that only authorized devices are allowed access to the tag database.


## Using File Synchronization

The Synchronization Manager can be used to exchange files between a MonicoView 3.1 device and an FTP server. This facility can be used to synchronize log files with a server computer, either automatically or on-demand, thereby providing an alternative to accessing the log file via the web server and allowing for unattended transfer of files from several devices to a central collection

point. Note that although it is called the Synchronization Manager for historical reasons, the service is a general-purpose FTP client that can also be used to perform other FTP operations. See the `FtpGetFile()` and `FtpPutFile()` functions in the Reference Manual for information on how to manually initiate file transfers.

## Configuring the Service

The Synchronization Manager is configured via the associated icon in the Navigation Pane:



## FTP Client

The following properties relate to the FTP client:

- The *Enable Sync Manager* property is used to enable the FTP client. The client may be enabled without enabling synchronization, allowing it to be used for manual file transfer via the FTP functions mentioned above.
- The *Enable Log File Sync* property is used to enable automatic log synchronization. See the next section for details of the other settings related to this feature and how they control file location and the synchronization timing.
- The *Server IP address* property is used to indicate the IP address of the server. As with many address fields in MonicoView 3.1, this may be set to a fixed IP address, a string that represents a hostname, or a tag that contains such a name. It may also be set to a 32-bit integer that contains the packed version of the address.
- The *Port Number* property is used to indicate the TCP port to which the FTP client service will attempt to connect. The default value is suitable for most applications, as most servers will listen on port 21.
- The *Logon Username* and *Logon Password* are the credentials that are submitted to the server when the connection is established. Both are typically case sensitive, although that depends on the server implementation. For anonymous login, leave the Username at its default value, and either leave the password blank, or enter your email address as a courtesy to the provider.
- The *Data Connection* provides a choice between standard and PASV mode. You can enable the PASV mode to force the FTP client to initiate all data connections rather than waiting for incoming connections from the server. This mode is sometimes required when working behind non-FTP aware firewalls or when operating via certain forms of network address translation. It is also preferred when working over cellular modem connections.
- The *Keep Alive* time is the period for which the FTP connection should be kept alive in case further transfers are required. A value of zero will close the connection as soon as



the current transfer has been completed. Non-zero values make for more efficient operation when transferring multiple files.

- The *Record Log File* property can be used to keep a log of all FTP interactions in the root directory of the memory card. This file can be useful when debugging FTP operations, but it will tend to degrade performance slightly.
- The *Debug Output* property is used to enable or disable the printing of advanced diagnostic information to the system's various debug consoles. This information will be of a technical nature and is not 100% documented. It is meant for use by Monico technical support or for more advanced users. Refer to the chapter on *Advanced Debugging* for information on how to configure debug consoles.

## Log Synchronization


The following properties relate specifically to log file synchronization:

- The *Base Directory* property defines the directory on the server where the log files will be placed. This directory is relative to the FTP server's folder space, not to the underlying directory structure of the server's own filing system. You will typically specify a different base directory for each MonicoView 3.1 device that is synchronizing to a given server.
- The *Sync Period* property specifies how often the FTP client will connect to the server and transfer its files. It is measured in hours and is always based from midnight. For example, selecting a value of three will result in transfers at midnight, 3:00 am, 6:00 am and so on.
- The *Sync Delay* property defines an offset in minutes from the standard time at which file transfers will occur. This property can be used to allow multiple terminals to talk to one server without all the file transfers occurring at once and thereby overloading the target's capabilities.

## Using Electronic Mail

MonicoView 3.1 can be configured to send email messages when alarm conditions are present or when notifications need to be provided of other events within the system. These messages may be sent via SMS to cellular devices, or via SMTP email to any device which accepts mail using standard internet protocols.

The mail transports and the email address book are configured via the Mail Manager:




The properties on the Mail tab are used to enable or disable the mail manager, and to provide a name for the device on which MonicoView 3.1 is running. This name will be used within email

messages to identify the originator of the message. Applications will typically use the name of the machine to which the device is attached or the name of the site that it is monitoring.

## Adding Contacts

The Contacts button can be used to access MonicoView 3.1's address book:




Each entry allows a Display Name and an Address to be entered, together with an optional expression that will enable or disable email to that contact. The address should be in a format suitable for the required transport. For example, SMTP names should be in the usual `name@domain` format, while SMS names should be entered as international-format telephone numbers without the leading plus sign. Multiple email addresses can be entered by separating them by semicolons, allowing simple mailing lists to be created.

## Configuring SMTP

The SMTP tab is used to configure the Simple Mail Transport Protocol. This is the standard protocol used to send email over the Internet or over other TCP/IP networks. SMTP addresses follow the familiar `name@domain` standard.

The configuration options for the SMTP transport are shown below:




- The *Transport Mode* property is used to enable or disable the transport. Note that the mail manager must be enabled via the Mail tab before the SMTP transport can be enabled. Note also that at least one transport must be enabled if the mail manager is to be able to deliver messages.
- The *Server Selection* property defines how the transport will locate an SMTP server. If Manual Selection is used, the Server IP Address property should be used to manually designate a server. If Configured via DHCP is selected, at least one Ethernet port must be configured to use DHCP and the network's DHCP server must be configured to designate an SMTP server via DHCP option 69.
- The *Server IP Address* property is used to designate an SMTP server when manual server selection is enabled. The server must be configured to accept mail from the panel and to relay messages if required by the application.
- The *Server Port Number* property defines the TCP port number that will be used for SMTP sessions. The default value is 25. This value will be suitable for most applications, and will only need to be adjusted if the SMTP server has been reconfigured to use another port.
- The *Domain Name* property specifies the domain name that will be passed to the SMTP server in the HELO or EHLO command. The vast majority of SMTP servers ignore this string. In the unlikely event that your SMTP server attempts to do a DNS lookup to confirm the identity of its client, you may need to enter something appropriate to your DNS configuration.
- The *Reverse Path* property specifies the email address that will be supplied as the originator of the messages sent by the target device. The property comprises a display name, and an email address. Since MonicoView 3.1 is not capable of receiving messages, the email address will often be set to something that will return an "undeliverable" message if a reply is sent.
- The *Initial Timeout* property specifies how many seconds the mail client will wait for the SMTP server to send its welcome banner. Some Microsoft servers attempt to negotiate Microsoft-specific authentication with mail clients, thereby delaying the point at which the banner appears. You may want to extend this time period to 2 minutes or more when working with such servers.
- The *Record Log File* property can be enabled to keep a log of all SMTP interactions in the root directory of the memory card. This file can be useful when debugging SMTP operations, but enabling it all the time will tend to degrade performance slightly. A log file can only be created when a connection with the mail server has been established.
- The *Debug Output* property is used to enable or disable the printing of advanced diagnostic information to the system's various debug consoles. This information will be of a technical nature and is not 100% documented. It is meant for use by Monico technical support or for more advanced users. Refer to the chapter on *Advanced Debugging* for information on how to configure debug consoles.
- The *Method* property indicates the type of authentication to be attempted by the client. A selection of Digest will insist upon an authentication technique that sends the password in an encrypted form and will skip authentication if the server does not support such a method. A selection of Basic will attempt to use the more secure technique, but will fall back to trivially encoded transmission if necessary. A selection of None will not attempt to authenticate. Your server may or not require authentication. Contact your network administrator or mail provider for more details of the setting that should be used for your server.
- The *Username* and *Password* properties provide the optional credentials for the authentication process described above.

- The *Use Secure Connection* option is used to enable SSL for encrypted email transmission. Many public servers now insist on SSL and so this option should be enabled when using such services. The TLS-SSL option starts the connection in secure mode, while the STARTTLS option starts the connection as usual but manually switches to secure operation once it is established. Contact your network administrator or mail provider for more details of the setting that should be used for your server.

## Configuring SMS

The SMS tab is used to configure the Short Message Service transport that is supported when using a GPRS modem in association with the target device. Email addresses for the SMS transport are in the form of international-format telephone numbers without the plus sign. For example, an address of 17175551111 would send a message to the cell phone or other GSM device that had a number of (717) 555-1111 within the United States.

The configuration options for the SMS transport are shown below:




- The *Transport Mode* property is used to enable or disable the transport.
- The *Message Relay* property is used to enable or disable MonicoView 3.1's SMS relay feature. If this feature is enabled, a user who receives an SMS message that has been sent to several recipients can reply to that message and have the MonicoView 3.1 device runtime relay the message to the other recipients. This provides a simple conferencing facility between message recipients.
- The *On Message* property is used to define an action to be executed each time a message is received. A local system variable called `Data` is defined within the action, allowing access to the message itself. The source number of SMS is prefixed to the message, with a colon separating it from the message body.

## Using SQL Sync

SQL Sync can be used to set up a connection to a Microsoft SQL Server database to periodically synchronize all log files to a remote database. This service allows direct integration with enterprise-level systems without the need to push CSV files via FTP and then have a server script harvest those files.

## Configuring the Service

SQL Sync is configured via the associated icon in the Navigation Pane:



- The **Server** property is used to specify the IP address of the SQL Server.
- The **TCP Port** property is used to specify the TCP/IP port to which the SQL Sync will connect. This port must agree with the port configured for TCP/IP access on the server. Contact your database administrator for more information.
- The **Logon Username** and **Logon Password** are the credentials that are submitted to the server when the connection is established. The password is always case sensitive. The case sensitivity of the username depends on the server. The user must have the rights necessary to create tables and write data.
- The **Database Name** property is used to specify the name of the database on the server to which SQL Sync will synchronize.
- The **Table Name Prefix** property is used to specify a namespace for all tables created by SQL Sync. This prefix will be prepended to the name of the log using an underscore to create the table name. This property can be used to avoid naming collisions when other devices are synchronizing to the same server.
- The **Primary Key Type** setting is used to control how SQL Sync distinguishes between rows of data. By default, the timestamp of the event or data log entry will be used as each table's primary key. But for event logs and data logs that update more than once a second, the resulting key will not be unique. For these cases, select *Auto-Increment* to specify that an automatically incrementing number should be used as the table's primary key. This may also be required if non-UTC logging is used and if Daylight Savings Time adjustments are made, as this can result in two entries with the same time and date combination.
- The **Select Log Directories** option displays a dialog box to allow synchronization for each data log to be turned on or off. This allows only certain logs to be pushed to the server, avoiding the transfer of information that is needed only on the local device.
- The **Include Security Logs** and **Include Alarm and Events** properties control whether the respective event logs will be pushed to the server. Enable the properties if this information is required centrally.
- The **Sync Period** property specifies how often SQL Sync will connect to the server and transfer its data. It is measured in hours and is always based from midnight. For example, selecting a value of three will result in transfers at midnight, 3:00 am, 6:00 am and so on.
- The **Sync Delay** property defines an offset in minutes from the standard time at which data transfers will occur. This property can be used to allow multiple terminals to talk to one server without all the transfers occurring at once and thereby overloading the target's capabilities.

- The *Record Log File* property is a flag to determine whether SQL Sync activity should be logged to the compact flash. Information logged includes commands sent to the SQL server and messages about any errors that occur. This feature can be useful for debugging failed synchronization attempts.

# Chapter 20 Sharing Ports


MonicoView 3.1 provides a port sharing facility that allows either physical or virtual serial connections to be made to any serially-connected device. For example, you may be using an operator panel with a programmable controller, but since the PLC has only a single serial port, you may find yourself swapping cables when modifying the ladder program. By sharing the communications port to connect to the PLC, you can send data directly to the controller, either from another serial port or by means of a connection made over a TCP/IP link.

## Enabling TCP/IP

The first configuration step when using port sharing is to enable the Ethernet port as described elsewhere in this manual. While you may not choose to use the virtual serial port facility, even the local sharing of ports is based upon the TCP/IP protocol, which will not be available unless at least one network interface is enabled.

## Sharing the Required Ports

The next step is to share the required port, which is done by selecting Yes in the Share Port property and then entering a suitable TCP/IP port number to indicate exactly how the virtual port should be addressed:




If you leave the port setting at zero, a number of 4000 plus the logical index of the port will be used. You may use any number that is not already used by another TCP/IP protocol. If you are stuck for ideas, we recommend numbers between 4000 and 4099.



## Connecting via Another Port

If you want to use another port on the target device to route data to the shared port, you must select the Generic Program Thru driver for that port, and configure this driver with the TCP/IP port number of the port that you have shared. In the example below, we are routing data from the programming port to a PLC that is connected via the RS485 comms port:



Note that in most cases, the Baud rate and other port settings do not have to be the same as those for the port that we are sharing, as MonicoView 3.1 will perform the conversion. The one exception to this is where one device transmits large bursts of data without any replies from the other. In this case, the device carrying out the larger transmissions must not be using a higher Baud rate than the device receiving them, or MonicoView 3.1 may not have enough memory to buffer the data while waiting for it to be retransmitted.

In the example above, to make use of the shared port you would connect a spare serial port on your PC to the programming port of the target device, and configure the PLC programming software to talk to this COM port. As soon as the PC begins to send to the PLC, all communications between MonicoView 3.1 and the PLC will be suspended, and the target device's two ports will be connected in software, such that the PC will appear to be talking directly to the PLC. If no data is transferred for more than a minute, communications between MonicoView 3.1 and the PLC will be resumed.

## Connecting via Ethernet


Rather than using an additional serial port on your PC and on the MonicoView 3.1-based device, it is possible to use a third-party utility to create what are known as virtual serial ports on your PC. These appear to applications to be physical COM ports, but they in fact send and receive data to a remote device over TCP/IP. By installing one of these utilities and configuring it to address the MonicoView 3.1-based device, you can have serial access to any devices connected to that device without any additional cabling. Indeed, there is no need to have any physical serial ports available on the PC at all—something that is very valuable when working with modern laptops, where a COM port is often an expensive option.

Several third-party virtual serial port utilities are available. On the freeware side, a company known as HW Group (<http://www.hw-group.com>) provides a utility called HW Virtual Serial Port. There are also a number of other freeware port drivers available, most of which seem to be derived from the same source base. On the commercial side, a company called Tactical Software (<http://www.tacticalsoftware.com>) offers Serial/IP for about \$100 a port.

While the various freeware drivers no doubt have many contented users, we have found that these drivers have occasional stability problems on certain PCs. Tactical Software's Serial/IP is the only package that we are able to support, and the following information assumes that you are using this package.



To create a virtual serial port, open Serial/IP's configuration screen, and select the name of the COM port you wish to define. This will typically be the first free COM port after those allocated to the physical ports and modems installed in your PC. Next, enter the IP address of the MonicoView 3.1-based device, and enter the TCP/IP port number that you allocated when sharing the port. The example below is configured as required by the previous samples in this document. Finally, ensure Raw TCP Connection is selected, and close the Serial/IP dialog.



You will now be able to configure any Windows-based software to use the newlycreated COM port for download. When the software opens the connection, MonicoView 3.1 will suspend communications on the shared port, and data will be exchanged between the PC software and the remote PLC—just as if they were connected directly! When the port is closed, or if no data is transferred for a minute, communications will be resumed.

Assuming you have purchased the appropriate number of licenses for Serial/IP, you will be able to create as many virtual ports as you need. This means that you can be connected to multiple devices from the same PC, downloading to each via its respective programming package—all without plugging or unplugging a single cable. This feature is extremely valuable when you have many devices in a complex system.

## Pure Virtual Ports

In some circumstances, you may want to use a spare serial port on a MonicoView 3.1-based device to provide access to a remote device that is not otherwise referenced in your database, effectively using the spare port as a remote serial server. To do this, configure the port in the usual way, selecting the Virtual Serial Port driver for that port. Then, share the port as described above, exposing it via TCP/IP. The Virtual Serial Port driver performs no comms activity of its own, but still allows the device to be shared for remote access.

## Limitations


Note that some PLC programming packages may not work with virtually or physically shared ports. Issues to watch out for are tight timeouts that do not allow MonicoView 3.1 time to relay the data to the PLC; a reliance on sending break signals or on the manipulation of hardware handshaking lines; or DOS-style port access such that the package cannot see the virtual serial port. Luckily, these issues are rare, and most packages will happily communicate as if they were directly connected to the PLC in question.

## Chapter 21 Using Modems


This chapter explains how to configure MonicoView 3.1 to work either with modems, or with direct serial connections to computers running the Windows operating system. MonicoView 3.1's modem support is entirely based upon running TCP/IP over the Point-To-Point Protocol, otherwise known as PPP. While protocols such as Modbus allow a single conversation to occur between any two devices, PPP is more akin to an Ethernet connection in that it allows an unlimited number of logical connections to exist on a single physical link. A single PPP connection can allow simultaneous access to the panel's TCP/IP download facility, its web server, its shared serial ports, and to any TCP/IP protocols that have been defined.

### Adding a Dial-In Connection

To add a dial-in connection to your database, select the Communications category and navigate to the serial port via which the connection will be made. Click on the Pick button of Driver property, and select the *PPP and Modem Server* driver from the System section.



The Editing Pane will now show the modem configuration:




The modem has the following configuration options:

- The *Connect Using* property is used to select the physical device to be used to make the connection. The devices supported via serial ports are direct serial connections to computers running the Microsoft Windows operating system, generic landline modems which implement the Hayes command set, and GSM modems implementing industry-standard GSM commands. When used for dialing, GSM devices must be configured in Circuit Switched Data mode.
- The *Manufacturer* property is used to select from the manufacturers or models for which specific configurations have been developed and stored within MonicoView 3.1. Leaving this setting at Generic will allow you to customize the settings related to initialization strings and the like. Please consult Technical Support for the settings required for any particular modem.

- The *Activity Timeout* property is used to define how long a period must pass without the G3 sending a packet over the PPP link in order for the connection to be terminated. For dial-in connections, it is assumed that the connecting device is friendly, so no effort will be made to filter out optional packets that might result in the link staying active for long periods. Note that even if you want a permanent connection, you must enter a timeout to allow the detection of dead links. This implies that so-called permanent connections may still drop on occasions, but will in any case be immediately reestablished.
- The *Init String* property is used to enable or disable certain commands during the initialization sequence. It is automatically configured if a specific setting is entered in the *Manufacturer* property.
- The *Additional Init* string is used with non-direct links, and provides a series of AT commands to be used to initialize the modem. The initial AT prefix is not required. Several commands may be combined by simply placing one after the other. The exact string that will be required for your modem is dependent upon its internal software, so if you contact Technical Support for assistance, be sure to have exact make and model information available.
- The *SMS Support* property is used to enable Short Message Service messaging when using a GSM modem. For SMS messaging to operate properly, you will also have to enable the SMS Transport in the Mail Manager as described elsewhere in this manual.
- The *Log File* property is used to enable the logging to the memory card of data exchange with the modem. This file can be used for debugging purpose during initial modem setup or when attempting to find the appropriate configuration options. Be sure to disable this feature once the correct modem configuration sequence has been established or performance will be greatly degraded.
- The *Logon Username* and *Logon Password* properties are used to define the credentials that the remote client must provide to be allowed to connect to this device. The username is not case sensitive, while the password is. MonicoView 3.1's PPP implementation will ask its peer to use CHAP authentication to avoid transmitting or receiving plaintext password, but will fall back to using PAP if the remote client does not support CHAP.
- The *Local Address* property is used to define the IP address to be allocated to the local end of the connection. This will thus be the IP address of the MonicoView 3.1 device for this link. Please note that this must not be the same as the IP address of the device's Ethernet port, as every physical interface using IP must have a distinct address. The default value will work in most situations, unless your network design demands that you use a different setting.
- The *Remote Address* property is used to define the IP address to be allocated to the remote end of the connection. It is used together with the *Remote Mask* property to determine what packets will be routed to this connection. For most applications, a mask of 255.255.255.255 will be used, thereby instructing MonicoView 3.1 to send via this interface only those packets directly bound for the remote client. A mask of 0.0.0.0, by contrast, will allow all packets that do not specifically match another interface to be forwarded to the remote client, presumably for further forwarding to the intended host. Intermediate masks may be used to control exactly which packets are sent.

## Adding a Dial-Out Connection

Dial-out connections are added exactly as described above, except that the PPP and Modem Client driver should be selected for the required communications port. The configuration options for this modem are shown below:



- The *Connect Using* property is as for dial-in connections, with the addition of support for GPRS and HSPA+ connections via a GSM modem. These connections differ from CSD connections in that they achieve much higher speeds and are typically charged based on how much data is transferred rather than how long the connection is maintained. GPRS and HSPA+ connections may therefore be configured for permanent connection unless there is a need to provide downtime to allow SMS messages to be transferred.
- The *No Firewall* property is used to turn off the firewall protection that is otherwise provided for dial-out connections. This protection prevents incoming connections from being made to this interface, and prevents the device from sending certain diagnostic packets that might either provide a hacker with information about the system, or might be used by an attacker to keep a connection active in the absence of any actual data transfer. If you are connecting directly to the Internet by means of this connection, you should not normally turn off the firewall. The firewall should be disabled only for connections to corporate networks or to other controlled environments.
- The *Connection Type* property is used to indicate whether you want this connection to be permanently maintained, or whether you want it to be established automatically when an attempt is made to transfer data to hosts that are reachable via this interface. If you select an ondemand connection, you must specify the timeout after which the link will be terminated if no packets have been transmitted by the MonicoView 3.1 device.
- The *Number or APN* property is used to configure the telephone number which a conventional modem will dial, or the APN required to access the service associated with the SIM installed in a GSM modem. Your GSM service provider will typically provide this information.
- The *Logon Username* and *Logon Password* properties are used to define the credentials that will be passed to the remote server when attempting to initialize this connection. The username is not case sensitive, while the password is. MonicoView 3.1's PPP implementation will ask its peer to use CHAP authentication to avoid transmitting or receiving plaintext password, but will fall back to using PAP if the remote server does not support CHAP.
- The *Route Type* property is used to define the data that will be transferred via this interface. For ondemand connections, this effectively defines when the connection will

be activated. If *Default Gateway* is selected, any packets that do not match the address and network mask of the Ethernet connection will be sent to this interface. Note that in this mode, the Ethernet port must have a gateway setting of 0.0.0.0, or it will take all the packets and leave none to activate the modem! If *Specific Network* is selected, you must provide the address and netmask that define the network to which packets will be routed.

- The *DNS Configuration* options are used to configure the DNS servers that can be reached via this interface. Manual mode allows the servers to be specified individually, while Automatic mode will use the servers negotiated during the PPP connection process. The default Manual mode servers for new databases are Google's public DNS servers at 8.8.8.8 and 8.8.4.4.
- The *Dynamic DNS* options are used to control whether this interface's public IP address should be registered using a third party Dynamic DNS service. The Provider property selects the Dynamic DNS provider to use. Current releases support only DynDNS using one of two domain suffixes. The *Username* and *Password* properties specify the credentials associated with your DynDNS account, while the Host Prefix specifies the name that will be prefixed to the dnsalias.com or dyndns.org domain when registering this device.
- The remaining properties are exactly as for dial-in connections.

## Adding an SMS Connection

SMS connections are used when text messaging functionality is required, but where neither dial-in nor dial-out PPP connections will be established. They are configured as described above, except that the *SMS via GSM Modem* device is selected for the required port. The properties for this driver are a subset of those provided for dial-in connections. SMS support is always enabled with this driver, but note once again that for SMS messaging to operate, you will have to enable the SMS Transport within the Mail Manager.


## SMS Message Processing

When SMS messaging is enabled, MonicoView 3.1 will instruct the GSM modem to check for new incoming or outgoing messages every five seconds. Incoming messages are forwarded to the mail manager, which will optionally forward them to other users according to its configuration. Note that it is not possible to check for messages while the modem is connected to a CSD or GSM session, so you may want to avoid using permanent connections when you are working with SMS. Note also that if more than one GSM modem is configured, all will be able to receive messages, but only the last modem will be used for sending.

## Modem Expansion Cards

The information above describes the process of connecting a modem via one of the device's serial ports. Modems expansion modules and expansion cards are also available for many devices. These are configured by adding the expansion option as described in the Using Communications chapter and then selecting the appropriate driver for the port that then appears in the Navigation Pane.

This example shows an Asset Series HMI expansion module being used to provide SMS connectivity:



## Checking the Modem Status

In order to help debug modem connections, MonicoView 3.1 provides the `GetInterfaceStatus()` function. This function takes a single argument, which is the numeric index of the required interface. Interface zero is the internal loopback interface. Next come any Ethernet interfaces that are enabled, followed by the PPP interfaces. In a system using a single Ethernet port, for example, the first PPP interface will have an index of 1.

The function returns a string, which can be interpreted according to the following table:

STATUS	MEANING
CLOSED	The interface has not yet been initialized. This state will only occur for a short time during system start-up.
INIT	The modem is being initialized. If the connection remains in this state, there are probably errors in the init strings being sent to the modem.
IDLE	The link is idle. GSM modems will return a number at the end of the string to indicate signal strength. The next table explains how to interpret these values.
SMS	The modem is sending SMS messages, or polling the modem to see if new SMS messages are available. If SMS messaging is enabled for a modem, you will see this state appear for a short period every five seconds.
CONNECTING	The modem is establishing a connection. This state typically appears only for client connections, and indicates that a call is being placed.
LISTENING	The modem is waiting for a call. This state appears only for server connections. Note that GSM modems will also return an IDLE state while waiting for a call in order to show signal strength.
ANSWER	The modem is answering a call and trying to negotiate the Baud rate for the connection. This state appears only for server connections. If the connection is established, the modem will enter the CONNECTED state.
CONNECTED	The modem has established a connection. This state will persist for only a short time, as the LCP negotiation process will begin after a small delay.
NEG LCP	The connection is negotiating LCP options. This process decides on a set of link protocol settings that are acceptable to both the client and the server.
AUTH	The connection is performing the authentication process to ensure that the appropriate user credentials are used.
NEG IPCP	The connection is negotiating IPCP options. This process decides on a set of network protocol settings that are acceptable to both the client and the server.
UP	The connection is active and IP data can be exchanged.

STATUS	MEANING
HANGING UP	The modem is disconnecting. This state will exist for only a short time before the modem returns to IDLE.

The signal strength values returned by GSM modems have the following meaning:

VALUE	SIGNAL STRENGTH
0	-113dBm or less.
1	-111dBm.
2-30	-109dBm to -52dBm in 2dBm steps.
31	-51dBm or greater.
99	Signal strength cannot be determined.

Cell phones typically interpret these values as follows when displaying signal strength:

VALUE	STRENGTH	NUMBER OF BARDS
5 or less.	-103dBm or less.	One
6 thru 9.	-101dBm thru -95dBm	Two
10 thru 14.	-93dBm thru -85dBm	Three
15 or greater.	-83dBm or greater.	Four

## Using Multiple Interfaces

MonicoView 3.1 supports up to two independent modem connections. When combined with the one or two Ethernet ports provided by the target device, this gives a total of up to four distinct IP interfaces, all of which will operate according to the configuration parameters defined for each connection. This section describes how these multiple interfaces will interact, and how MonicoView 3.1 will decide where to send each packet of data.

### Interface Selection

Each interface has an IP address and a network mask, which are used to decide whether to forward packets to that interface. For example, if an Ethernet interface is configured with an IP address of 192.168.1.0 and a network mask of 255.255.255.0, any packets for IP addresses starting with 192.168.1 will be sent to this interface. Likewise, if an on-demand modem connection has a remote IP address of 192.168.2.2 and a network mask of 255.255.255.255, sending a packet to address 192.168.2.2 will result in the connection being established.

Note that this mechanism will only send a packet to a single interface. This implies that interfaces should have distinct network addresses, as defined by their IP address and netmask. If you breach this requirement, packets will not get routed to the second interface with that network address, and communications on that port will fail. For example, you must not configure one Ethernet port as 192.168.100.1 and the other as 192.168.100.2, as packets for the 192.168.100.0 network will only be sent to the first port.



## Default Route

In addition, one single interface may also define a default route, which will be used to handle packets that do not specifically match any other interface. The method used to configure the route varies according to the interface type, as shown in the table below:

INTERFACE	TO DEFINE DEFAULT ROUTE
Ethernet	Enter a non-zero value for the <i>Gateway</i> property.
Dial-In	Enter 0.0.0.0 for the <i>Remote Mask</i> .
Dial-Out	Select Default Gateway for the <i>Route Type</i> property

Again, only a single interface may define a default route. For example, an operator panel may be connected to a number of Ethernet devices using an IP address of 192.168.1.0 and a network mask of 255.255.255.0, with no gateway defined. An on demand modem connection may be configured to access an Internet Service Provider to send emails when alarms occur. Its *Route Type* is set to Default Gateway, making it the destination for any packets for IP addresses that do not match the network defined for the Ethernet port. The SMTP server is configured as 24.104.0.39, resulting in a dial-out connection when an attempt is made to send a message.




# Chapter 22 Using the USB Host

If your target device has one or more USB host ports, the corresponding icon in the Communications category can be used to configure the devices that it will support. Current builds of MonicoView 3.1 support USB memory devices, keyboard and mice. The keyboard driver supports the many USB bar-code readers that provide keyboard emulation, and the mouse driver will also support some types of touchscreen or touchpad.

## Memory Stick Support


USB memory devices are configured via the Memory Stick icon:

### General Properties



- The *Enabled* property is used to globally disable or enable memory stick support.
- The *Updates* property is used to configure the automatic transfer of an update file to the root directory of the target device's memory card. If the setting is enabled, the file specified will be copied when the memory device is first inserted into the USB port. When the target device restarts, the file will be used to update the device's firmware and configuration database.
- The *Database* property defines the name of the database image to be copied to the `image.mvi` file on the memory card. This setting allows several files to be placed on a single stick, with each MonicoView 3.1 device copying the file that is appropriate to the device into which the stick is inserted.
- The *Location* property specifies the location on the memory stick where the database image file specified above can be located.
- The *Restart* property is used to indicate whether an automatic restart should be performed once the file has been copied. Enabling this property allows the information from the database image to be immediately loaded by MonicoView 3.1.

## Transfer Properties



The screenshot shows a configuration window titled "File Synchronization 1". It contains five settings, each with a label and a control element:

- Transfer:** A dropdown menu with "Copy Files" selected.
- Direction:** A dropdown menu with "Memory Card To Memory Stick" selected.
- Update:** A dropdown menu with "New and Modified Files Only" selected.
- Source:** A text input field containing "Root Folder".
- Destination:** A text input field containing "Root Folder".

- The *Transfer* property for each synchronization group defines the function that should be performed. Information may either be copied or moved, and the operation may either be applied to the files in the specified folder, or to those files and the folder's sub-folders and their contents on a recursive basis.
- The *Direction* property specifies the direction of the transfer.
- The *Update* property is used to indicate whether files that appear to be already present on the target device should be copied in any case or whether only new and modified files should be transferred. MonicoView 3.1 uses the file's time-stamp and size to decide whether the file should be processed.
- The *Source* and *Destination* properties are used to indicate the folders on the source and target devices where the files should be located.

## Keyboard Support


A USB keyboard may be connected to the target device to provide a further method of data entry. MonicoView 3.1 primitives will accept the characters from the keyboard as if they had been entered via the popup keypad. The keyboard is configured via the Keyboard section of the USB Host Ports, with the only option being to choose the keyboard layout so that MonicoView 3.1 can convert the scan-codes into the corresponding characters. Only US and UK layouts are currently supported. Note that USB barcode readers that implement the keyboard HID class are also supported. This allows barcodes to be entered directly into MonicoView 3.1 string tags by means of a simple data entry primitive.

## Mouse Support

A USB mouse or similar pointing device may be connected to the target device to provide a further method of input. MonicoView 3.1 primitives will accept clicks from the mouse as if they had come from the device's touchscreen. This mouse is configured via the Mouse section of the USB Host Ports, with the only options being a scale factor that can be used to make the mouse less sensitive, and a period after which the mouse pointer will be hidden.

# Chapter 23 Using Programs

The previous chapters of this manual refer to using actions to perform operations in response to key or touchscreen presses, or to changes in data tags. If you need to perform an action that is too complex to fit on a single line, or that demands more complex decision-making logic, you can use the Programming category to create and manipulate programs.



## The Program List

The program list in the Navigation Pane is a conventional Navigation List that can be used to create, delete, rename and otherwise organize programs. Note that programs can be grouped into folders, and that each program's icon can display three states: green, indicating a program that has been translated and validated; yellow, indicating a program that has been edited but not yet translated; or red, indicating a program that contains one or more errors.

## Finding Program Usage

You can find all the items that refer to a given program by right-clicking that item in the Navigation Pane and selecting the Find Usage command. The resulting items will be placed on the Global Search Results List, and can be accessed by means of the **F4** and **SHIFT+F4** key combinations. The list itself can be shown or hidden by pressing **F8**.

## Editing Programs

To edit a program, simply edit the program text using the Source tab shown in the Editing Pane. You will notice that the program's icon turns yellow as soon as you start typing, indicating that you have made changes that have yet to be translated. You will also notice that MonicoView 3.1's program editor performs syntax coloring, auto-indentation and a variety of other features appropriate for a code editor. Editor options can be configured by right-clicking on the Editing Pane and selecting the appropriate command from the resulting menu.


When you have finished writing your program, press the **CTRL+T** key combination or select the Translate button on the toolbar. The program will then be checked for errors. If an error is found, a dialog box will be displayed and the program's icon will turn red. The cursor will also be moved to the position of the error. If no errors exist, a chime sound will be omitted and the program's icon will turn green, indicating that the program has been translated into a form suitable for execution within the target device.

## Getting Help

While working within the editing pane, a shortcut is available to provide help on system functions. Place your cursor within or at the end of the function name, and press the F1 key to display information on the function's operation, arguments and return type. You may also press F1 after typing a function's name to gain access to the same information.

## The Resource Pane


The Resource Pane displayed by the program editor contains a variety of items that can be dragged into your code. The Data Tags and Programs categories are self-explanatory and provide quick access to the respective items in your database by allowing the name of the item to be inserted into the editor. The System category provides access to MonicoView 3.1's extensive library of system variables and functions:



As you can see, variables and functions are grouped into categories. When a function is selected, its return type and argument types are shown on the status bar. Dropping a function into your code enters the appropriate text, and put the cursor in the parentheses following the function name, thereby allowing you to enter the required arguments.

## Program Data Types

The field above the program editor can be used to edit the program's data types:




- The *Data Type* property is used to indicate whether this program should simply perform a series of actions, or whether it will perform a calculation and return the value of that calculation to the caller. Programs that return values cannot by definition be run in the background.
- The *Parameters* property section defines up to six parameters that the program will accept. Each parameter has a name and a data type. In this example, the program

accepts two parameters, the first named `Value1` and the second named `Value2`, and both being 32-bit signed integers.

Returning values and passing parameters are discussed in more detail below.

## Global Settings


Selecting the root item in the Navigation List will access the global program settings...



- The *Compiler Settings* property are used to maintain compatibility with code imported from much earlier versions of MonicoView. Unless requested by Monico Technical Support, you should not adjust any of these settings.
- The *Enable Debug* property is used to globally enable or disable the output of execution trace information to the system's various debug consoles. Trace output will print a message to the console whenever a particular action is performed by a particular fragment of code. Information about the debug console can be found in the chapter on *Advanced Debugging*.
- The *Debug Programs* property is used to globally enable or disable trace output from the execution of programs. Each program has a similar property that can be used to override this setting, allowing finer-grained control of what trace information is output.
- The *Debug Actions* property is used to globally enable or disable trace output from the execution of actions. These actions may be triggered by user activity such as pressing a button or by system activities such as the one-second tick or the activation of a trigger associated with a tag.
- The *Debug Expressions* property is used to globally enable or disable trace output from the evaluation of expressions. Since MonicoView uses expressions for everything from calculating values to be displayed to deciding on what colors to use for display primitives, enabling this option will generate voluminous output.
- The *Trace Options* property is used to globally select the events that will be logged to the debug console. Options include entering or leaving programs, assignments to local variables or tags, calls to system functions that perform actions, calls to system functions that calculate values, or calls to programs.
- The *Program Storage* property is used to indicate whether programs should be stored within the MonicoView database file as usual, or if they should be stored in external files in the same directory as the database. External storage is an advanced option that allows the use of an external source control system to make program changes and to merge changes by different users. MonicoView will keep internal and external edits in-sync insofar as this is possible, but you should not attempt to internally and externally edit the same program at the same time.

## Program Properties

The second tab of the editor defines the program's execution environment:



- The *Execution Task* property is used to indicate how MonicoView 3.1 should execute the program. If the property is set to Same as Caller, the program will be run by the task that called it and MonicoView 3.1 will wait for the program to complete execution before continuing with whatever that task was doing. For example, selecting this setting and running a program in response to a key being pressed will result in a pause in display updates until the program completes. (Since most programs take very little time to execute, this may not even be noticeable.) If this property is set to one of the background settings, MonicoView 3.1 will use one of three tasks allocated for background execution, and the calling task will immediately be able to continue perform its own work. Each task can run only one background program at once, so subsequent requests are queued for later execution. Note also that programs that return values cannot be run in the background, as their return value would then not be available for the caller to use! Programs set to Same as Caller that are called from programs running in the background will themselves run in the background, interrupting the previously executing program. Programs set to background execution that are called from programs already executing in the back-ground will be queued if they are directed to the same task or to a task that is already busy, or executed immediately if directed to an unused task.
- The *External Data* and *Timeout* properties are used to control how the program interacts with MonicoView 3.1's communication infrastructure with respect to external data items to which the program refers. You will recall that MonicoView 3.1 only reads data items when they are used. This property is used to control the exact interpretation of this rule with respect to programs:

MODE	BEHAVIOR
Read When Referenced	External data used by the program will be added to the comms scan whenever the program is referenced. If the program is referenced by a display page, the data will be read when that page is displayed; if the program is referenced by a global action or a trigger, the data will be read at all times. This is the default mode, and is acceptable for all programs, except those that use very large amounts of external data.
Read Always	External data used by the program will be read at all times, whether or not the program is referenced. This means that the program will always be ready to run, and that the operator will not see the "NOT READY" message that might otherwise occur when the program is first referenced. The downside of this mode is that comms performance may be reduced if large amounts of data are referenced by the program.
Read When Executed	External data used within the program will be read only when the program is invoked. The program will wait for the period defined in the timeout property for such data to be available. If the data cannot be read—perhaps because a device is offline—the program will not execute. This mode is typically used with globally-referenced programs that consume large amounts of data that would otherwise slow down the communications scan.
Read But Run Anyway	External data will be treated as described for Read Always mode, but the program will execute whether or not the data has been read successfully. The operator will therefore never see the "NOT READY" message, but if a device is offline, there is no guarantee that the program's data items contain valid data.



- The *Enable Debug* property is used to locally enable or disable trace output from the execution of this program. Selecting anything other than the Default setting will override the global *Debug Programs* property.
- The *Trace Options* property is used to select the events that will be logged to the debug console for this program. Options include entering or leaving programs, assignments to local variables or tags, calls to system functions that perform actions, calls to system functions that calculate values, or calls to programs.

## Adding Comments

You can add comments to your programs in two ways. First, you can use the `//` sequence to introduce a comment which will continue for the rest of the current line. Secondly, you can use the `/*` sequence to introduce a single or multiline comment. This comment will continue until the `*/` sequence appears. The sample below shows both commenting styles:

```
// This is a single-line comment

/* This is line 1 of the comment
   This is line 2 of the comment
   This is line 3 of the comment */
```

A single-line comment may also be placed at the end of a line that contains code.

## Returning Values

As mentioned above, programs can return values. Such programs can be invoked by other programs or by expressions anywhere in the database. For example, if you want to perform a particularly complex decode on a number of conditions relating to a motor and return a value to indicate the current state, you could create a program that returns an integer like this:

```
If( MotorRunning )
return 1;
else {
if( MotorTooHot )
return 2;
if( MotorTooCold )
return 3;
return 0;
}
```

You could then configure a tag to invoke this program, and use a multi-state format to provide names for the various states. The invocation would be performed by setting the tag's Value property to `Program()`, where `Program` is the name of the program in question. The parentheses are used to indicate a function call and cannot be omitted.

## Avoiding Pitfalls

Note that you have to exercise a degree of caution when using programs to return values. In particular, you should avoid looping for long periods of time, or performing actions that make no sense in the context in which the function will be invoked. For example, if the code fragment above called the `GotoPage` function to change the page, the display would change every time the program was invoked. Imagine what would happen if you, say, tried to log data from the associated tag, and you'll realize that this would not be a good thing! Therefore, keep programs

that return values simple, and always consider the context in which they will be run. If in doubt, avoid doing anything other than simple math and `if` statements.

## Passing Arguments

As mentioned above, programs can accept arguments. Suppose you want to write a program called `FindMean` to take the average of two integer values. The program would be configured to accept two integer arguments, `a` and `b`. The program would also be configured to return an integer. The code within the program would then be defined as:

```
Return (a+b)/2;
```

Once this program has been created and translated, you will be able to enter an expression such as `FindMean(Tag1, Tag2)` to invoke it with the appropriate arguments. In this case, the expression would be equal to the average of `Tag1` and `Tag2`.

## Programming Tips

The sections below provide an overview of the programming constructions supported by MonicoView 3.1. The basic syntax used is that of the C programming language. Note that the aim is not to try to teach you to become a programmer, or to master the subtleties of the C language. Such topics are beyond the scope of this manual. Rather, the aim is to provide a quick overview of the facilities available, so that the interested user might experiment further.

## Multiple Actions

The simplest type of program comprises a list of actions, with each action taking up a single line, and being followed by a semicolon. All of the various actions defined in the Writing Actions section are available for use. Simple programs like this are typically used where combining the actions in a single action definition would otherwise prove unreadable.

The sample shown below sets several variables, and then changes the display page:

```
Motor1 = 0;  
Motor2 = 1;  
Motor3 = 0;
```

```
GotoPage(Page1);
```

The actions will be executed in order, and the program will then return to the caller.

## If Statements

This type of statement is used within a program to make a decision. The construct consists of an `if` statement with a condition in parentheses, followed by an action (or actions) to be executed if the condition is true. If more than one action is specified, each should be placed on a separate line, and curly-brackets should be used to group the statements together. An optional `else` clause can be used to provide for code to be run if the condition is false.

The example below shows an `if` statement with a single action:

```
if( TankFull )  
StartPump = 1;
```

The example below shows an `if` statement with two actions:

```
if( TankEmpty ) {  
StartPump = 0;  
OpenValue = 1;  
}
```

The example below shows an `if` statement with an `else` clause:

```
if( MotorHot )  
StartFan = 1;  
else  
StartFan = 0;
```

Note that it is very important to remember to place the curly-brackets around groups of actions to be executed in the `if` or `else` portion of the statement. If you omit the brackets, MonicoView 3.1 will most likely misunderstand exactly which actions you want to be dependent upon the `if` condition. Although line breaks are recommended between actions, they are not used to figure out what is and is not included within the conditional statement.

## Switch Statements

A `switch` statement is used to compare an integer value against a number of possible constants, and to perform an action based upon which value is matched. The exact syntax supports a number of options beyond those shown in the example below, but for the vast majority of applications, this simple form will be acceptable.

This example below will start a motor selected by the value in the `MotorIndex` tag:

```
switch( MotorIndex ) {  
  
case 1:  
MotorA = 1;  
break;  
case 2:  
case 3:  
MotorB = 1;  
break;  
case 4:  
MotorC = 1;  
break;  
default:  
MotorD = 1;  
break;  
}
```

A value of 1 will start motor A, a value of 2 or 3 will start motor B, and a value of 4 will start motor C. Any value which is not explicitly listed will start motor D. Things to note about the syntax are the use of curlybrackets around the `case` statements, the use of `break` to end each conditional

block, the use of two sequential `case` statements to match more than one value, and the use of the optional `default` statement to indicate an action to perform if none of the specified values is matched by the value in the controlling expression. (If this syntax looks too intimidating, a series of `if` statements can be used instead to produce the same results, but with marginally lower performance, and somewhat less readability.)

## Local Variables

Some programs use variables to store intermediate results, or to control one of the various loop constructs described below. Rather than defining a tag to hold these values, you can declare what are known as local variables using the syntax shown below:

```
int      a; // Declare local integer 'a'
float    b; // Declare local real   'b'
cstring  c; // Declare local string 'c'
```

Local variables may optionally be initialized when they are declared by following the variable name with `=` and the value to be assigned. Variables that are not initialized in this manner are set to zero, or to an empty string, as appropriate.

Note that local variables are truly local in both scope and lifetime. This means that they cannot be referenced outside the program, and they do not retain their values between function invocations. If a function is called recursively, each invocation has its own variables.

## Loop Constructs

The three different loop constructs can be used to perform a given section of code while a certain condition is true. The `while` loop tests its condition before the code is executed, while the `do` loop tests the condition afterwards. The `for` loop is a quicker way of defining a `while` loop, allowing you to combine three common elements into one statement.

You should note that some care is required when using loops within your programs, as you may make a programming error which results in a loop that never terminates. Depending on the situation in which the program is invoked, this may seriously disrupt the terminal's user interface activity, or its communications. Loops which iterate too many times may also cause performance issues for the subsystem that invokes them.

### The While Loop

This type of loop repeats the action that follows it while the condition in the `while` statement remains true. If the condition is never true, the action will never be executed, and the loop will perform no operation beyond evaluating the controlling condition. If you want more than one action to be included in the loop, be sure to surround the multiple statements in curly-brackets, as with the `if` statement. The example below initializes a pair of local variables, and then uses the first to loop through the contents of an array, totaling the first ten elements, and returning the total value to the caller:

```
int i=0, t=0;

while( i < 10 ) {
    t = t + Data[i];
    i = i + 1;
}

return t;
```

The example below shows the same program, but rewritten in a compressed form. Since the loop statement now controls only a single action, the curly-brackets have been omitted:

```
int i=0, t=0;

while( i < 10 )
t += Data[i++];

return t;
```

## The For Loop

You will notice that the `while` loop shown above has four elements:

1. The initialization of the loop control variable.
2. The evaluation of a test to see if the loop should continue.
3. The execution of the action to be performed by the loop.
4. The making of a change to the control variable.

The `for` loop allows elements 1, 2 and 4 to be combined within a single statement, such that the action following the statement need only implement element 3. This syntax results in something similar to the FOR-NEXT loop found in BASIC and other such languages.

Using this statement, the example given above can be rewritten as:

```
int i, t;

for( i=t=0; i<10; i++ )
t += Data[i];

return t;
```

You will notice that the `for` statement contains three distinct elements, each separated by semicolons. The first element is the initialization step, which is performed once when the loop first begins; the next is the condition, which is tested at the start of each loop iteration to see if the loop should continue; the final element is the induction step, which is used to make a change to the control variable to move the loop on to its next iteration. Again, if you want more than one action to be included in the loop, include them in curly-brackets!

## The Do Loop

This type of loop is similar to the `while` loop, except that the condition is tested at the end of the loop. This means that the loop will always execute at least once.

The example below shows the example from above, rewritten to use a `do` loop:

```
int i=0, t=0;

do {
t += Data[i];
} while( ++i < 10 );

return t;
```

## Loop Control

Two additional statements can be used within loops. The `break` statement can be used to terminate the loop early, while the `continue` statement can be used to skip the balance of the


loop body and begin another iteration without executing any further code. To make any sense, these statements must be used with `if` statements to make their execution conditional.

The example below shows a loop that terminates early if another program returns true:

```
for( i=0; i<10; i++ ) {  
    if( LoopAbort() )  
        break;  
    LoopBody();  
}
```

# Chapter 24 Writing Expressions

You will recall from the earlier sections of this manual that many fields within MonicoView 3.1 are configured as what are called expression properties. You will further recall that these fields are edited by means of a user interface element similar to that shown below:



In many situations, you will be configuring these properties to be equal to the value of a tag, or to the contents of a register in a remote communications device. In these cases, you will either be dragging items from the Resource Pane, or you will be clicking the appropriate option on the drop-down menu, and then selecting the item from the resulting dialog box.

There will be situations, though, when you want to make a property dependent on a more complex combination of data items, perhaps using some math to combine or compare their values. Such eventualities are handled via what are known as expressions, which can be entered in the property's edit box whenever General mode is selected via the drop-down.

## Data Values

All expressions contain at least one data value. The simplest expressions are references to single constants, single tags, or single PLC registers. If you enter either of the last two options, MonicoView 3.1 will simplify the editing process by automatically changing the property mode as appropriate. For example, if you enter a tag name in General mode, MonicoView 3.1 will switch to Tag mode, and show the tag name in the selection field.

## Constants

Constants represent—not surprisingly—constant numbers or strings.

### Integer Constants

Integer constants represent a single 32-bit signed number. They may be entered in decimal, binary, octal or hexadecimal as required. The examples below show the same number entered in the four different number bases:

BASE	EXAMPLE
Decimal	123
Binary	0b1111011
Octal	0173
Hexadecimal	0x7B

The 'U' and 'L' suffixes supported by earlier versions of software are not used.

### Character Constants

Character constants represent a single Unicode character, encoded in the lower 16 bits of a 32-bit signed number. A character constant comprises a single character enclosed in single quotation marks, such that 'A' can be used to represent a value of 65. Certain otherwise unprintable or unrepresentable characters can be encoded using what are called escape sequences, each of which is introduced with a single backslash:

SEQUENCE	VALUE	ASCII
\a	Hex 0x07, Decimal 7	BEL
\t	Hex 0x09, Decimal 9	TAB
\n	Hex 0x0A, Decimal 10	LF
\f	Hex 0x0C, Decimal 12	FF
\r	Hex 0x0D, Decimal 13	CR
\e	Hex 0x1B, Decimal 27	ESC
\xnn	The hex value represented by nn.	-
\unnnn	The hex value represented by nnnn.	-
\nnn	The octal value represented by nnn.	-
\\	A single backslash character.	-
\'	A single quotation mark character.	-
\"	A double quotation mark character.	-

## Logical Constants

Logical constants represent a 1 or 0 value that is used to indicate the truth or otherwise of a yes-or-no expression. An example of something that can be assigned to be equal to a logical constant is a tag that represents a digital output in a PLC. Logical constants can either be entered simply as 1 or 0, or by use of the keywords `true` or `false`.

## Floating-Point Constants

Floating-point constants represent a 32-bit single-precision floating point value. They are represented as you might expect—by the integer portion, followed by a single decimal point, followed by the fractional portion. Scientific notation is also supported by specifying a value for the mantissa and following this with an 'E' and an exponent.

## String Constants

String constants represent sequences of characters. They comprise the characters to be represented, enclosed in double quotation marks. For example, the string "ABCD" represents a four-character string, comprising the values 65, 66, 67 and 68. (Actually, five 16-bit words are used to store the string, with a null value being appended as a terminator.) The various escape sequences discussed above may also be used within strings.

## Tag Values

The value of a tag is represented in an expression by the tag name. Tags that are organized into folders are represented by the pathname of the tag with each pair of elements being separated by a period. Therefore, a tag named PV in a folder named Loop would be referenced as `Loop.PV`. Note that uppercase and lowercase characters are considered equivalent when finding the required tag. Once an expression has been entered, any changes to the name of the tag will modify all of the expressions that make reference to it.

## Tag Properties

Data tags have certain properties than can be accessed by following a tag name with a period and then with the name of the required property. The following properties are defined:

PROPERTY	DESCRIPTION	DATA TYPE
Name	The tag's name.	String.



PROPERTY	DESCRIPTION	DATA TYPE
AsText	The tag's value formatted as text.	String.
Label	The tag's Label property.	String.
Desc	The tag's Description property.	String.
Prefix	The prefix defined by the tag's format.	String.
Units	The units defined by the tag's format.	String.
SP	The tag's setpoint property.	Same as Tag.
Min	The tag's lower data entry limit.	Same as Tag.
Max	The tag's upper data entry limit.	Same as Tag.
Fore	The tag's current foreground color.	Integer.
Back	The tag's current background color.	Integer.

## Page Properties

Display pages also have certain properties that can be accessed in the same way:

PROPERTY	DESCRIPTION	DATA TYPE
Name	The page's name.	String.
Label	The page's Label property.	String.
Desc	The page's Description property.	String.

## Comms References

References to registers in master communications devices can be entered into an expression by means of a syntax comprising an opening square bracket, the register name, and a closing square bracket. An optional device name may be prefixed to the register name and separated by a period. The device name is not needed when referring to the only device in a database.

Examples of this syntax are shown below:

EXAMPLE	MEANING
[D100]	Register <b>D100</b> in first device.
[AB.N7:0]	Register <b>N7:0</b> in device <b>AB</b> .
[FX.D100]	Register <b>D100</b> in device <b>FX</b> .

## Simple Math

As mentioned above, expressions often contain more than one data value, with their values being combined mathematically. The simplest of these expressions may add a pair of values, while a more complex expression might obtain the average of three values. These operations are performed using the familiar syntax you will have seen in applications such as Excel. The examples below show the basic operations that can be performed:

OPERATOR	PRIORITY	EXAMPLE
Addition	Group 4	Tag1 + Tag2
Subtraction	Group 4	Tag1 - Tag2
Multiplication	Group 3	Tag1 * Tag2
Division	Group 3	Tag1 / Tag2

OPERATOR	PRIORITY	EXAMPLE
Remainder	Group 3	Tag1 % Tag2

Although the examples show spaces surrounding the operators, these are not required.

## Operator Priority

You will have noticed the Priority column in the above table. As you no doubt recall from your algebra classes, when several operators are used together, they are evaluated in a defined order. For example, multiplication is always evaluated before addition. MonicoView 3.1 implements this ordering by means of what are known as operator priorities, with each operator being placed in a group, and with operators being applied from the lowest numbered group to the highest. Except where noted otherwise in the text, operators within a group are evaluated left-to-right. The default order of evaluation can be overridden by using parentheses.

## Type Conversion

Normally, MonicoView 3.1 will automatically decide when to switch from evaluating an expression in integer math to evaluating it using floating point. For example, if you divide an integer value by a floating point value, the integer will be converted to floating point before the division is carried out. However, there will be some situations where you want to force a conversion to take place.

For example, suppose you are adding together three integers that represent the levels in three tanks, and then dividing the total by the tank count to obtain the average level. If you use an expression such as `(Tank1+Tank2+Tank3)/3` then your result may not be as accurate as you demand, as the division will take place using integer math, and the average will not contain any decimal places. To force MonicoView 3.1 to evaluate the result using floating-point math, the simplest technique is to change the 3 to 3.0, thereby forcing MonicoView 3.1 to convert the sum to floating point before the division is performed. A slightly more complex technique is to use syntax such as `float (Tank1+Tank2+Tank3)/3`. This invokes what is known as a type cast on the term in parentheses, manually converting it to floating point.

Type casts may also be used to convert a floating-point value to an integer value, perhaps deliberately giving up some precision from an intermediate value before storing it in a PLC register. For example, the expression `int(cos(Theta)*100)` will calculate the cosine of an angle, multiply this value by 100 using floating-point math, before converting it to an integer, dropping any digits after the decimal place.

## Comparing Values

You will quite often find that you wish to compare the value of one data item with another, and make a decision based on the result. For example, you may wish to define a flag formula to show when a tank exceeds a particular value, or you may wish to use an `if` statement in a program to execute some code when a motor reaches its desired speed. The following comparison operators are provided:

OPERATOR	PRIORITY	EXAMPLE
Equal To	Group 7	Data == 100
Not Equal To	Group 7	Data != 100
Greater Than	Group 6	Data > 100
Greater Than or Equal To	Group 6	Data >= 100
Less Than	Group 6	Data < 100

OPERATOR	PRIORITY	EXAMPLE
Less Than or Equal To	Group 6	Data <= 100

Each operator produces a value of 0 or 1, depending on the condition it tests. The operators can be used on integers, floating point values or strings. If strings are being compared, the comparison is case-insensitive such that “abc” is considered equal to “ABC”.

## Testing Bits

MonicoView 3.1 allows you to test the value of a bit within a data value by using the bit selection operator, which is represented by a single period. The left-hand side of the operator should be the value in which the bit is to be tested, and the right-hand side should be an expression indicating the bit number to test. This right-hand value should be between 0 and 31. The result of the operator is equal to 0 or 1 depending on the value of the bit in question.

OPERATOR	PRIORITY	EXAMPLE
Bit Selection	Group 1	Input.2

The example shown tests bit 2 (i.e. the bit with a value of 4) within the indicated tag. If you want to test for a bit being equal to zero, you can use the logical NOT operator:

OPERATOR	PRIORITY	EXAMPLE
Logical NOT	Group 2	!Input.2

This example is equal to 1 if bit 2 of the indicated tag is equal to 0, and vice versa.

## Multiple Conditions

If you want to define an expression that is true if a number of conditions are all true, you can use the logical AND operator. Similarly, if you want to define an expression that is true if any of a number of conditions are true, you can use the logical OR operator. The examples below show each operator in use:

OPERATOR	PRIORITY	EXAMPLE
Logical AND	Group 11	A>10 && B>10
Logical OR	Group 12	A>10    B>10

The logical AND operator produces a value of 1 if and only if the expressions on the left-hand and right-hand sides are true, while the logical OR operator produces a value of 1 if either expression is true. Note that—unlike the bitwise operators referred to elsewhere in this section—the logical operators stop evaluating once they know what the answer will be. This means that in the above example for logical AND, the right-hand side of the operator will only be evaluated if A is greater than 10, as, if this were not true, the result of the AND operator must already be zero. While this property makes little difference in the examples given above, if the left-hand or right-hand expressions call a program or make a change to a data value, this behavior must be taken into account.

## Choosing Values

You may find situations where you want to select between two values—be they integers, floating point values or strings—depending on the value of some condition. For example, you may wish to set a motor’s speed equal to 500 rpm or 2000 rpm based on a flag tag. This operation can be performed using the ?: operator, which is unique in that it takes three arguments, as shown in the example below:

OPERATOR	PRIORITY	EXAMPLE
Selection	Group 13	Fast ? 2000 : 500

This example will evaluate to 2000 if `Fast` is true, and 500 otherwise. The operator can be thought to be equivalent to the `IF` function found in applications such as Microsoft Excel.

## Manipulating Bits

MonicoView 3.1 also provides operators to perform operations that do not treat integers as numeric values, but instead as sequences of bits. These operators are known as bitwise operators.

### AND, OR and XOR

These three bitwise operators each produce a result in which each bit is defined to be equal to the corresponding bits in the values on the operator's left-hand and right-hand sides, combined using a specific truth-table:

OPERATOR	PRIORITY	EXAMPLE
Bitwise AND	Group 8	Data & Mask
Bitwise OR	Group 9	Data   Mask
Bitwise XOR	Group 10	Data ^ Mask

The table below shows the associated truth tables:

A	B	A & B	A   B	A ^ B
0	0	0	0	0
0	1	0	1	1
1	0	0	1	1
1	1	1	1	0

### Shift Operators

MonicoView 3.1 also provides operators to shift an integer a number of bits to the left or right:

OPERATOR	PRIORITY	EXAMPLE
Shift Left	Group 5	Data << 2
Shift Right	Group 5	Data >> 2

Each example shifts `Data` two bits in the specified direction.

### Bitwise NOT

Finally, MonicoView 3.1 provides a bitwise NOT operator to invert the sense of the bits in a value:

OPERATOR	PRIORITY	EXAMPLE
Bitwise NOT	Group 2	~Mask

This example produces a value where every bit is equal to the opposite of its value in `Mask`.

## Indexing Arrays

Elements within an array tag can be selected by following the array name with square brackets that contain an indexing expression. This expression must range from 0 to one less than the number of elements in the array. If you create a 10-element array, for example, the first element will be `Name[0]` and the last will be `Name[9]`.

## Indexing Strings

Square brackets can also be used to select characters within a string. For example, if you have a tag called `Text` that contains the string "ABCD", then the expression `Text[0]` will return a value of 65, this being equal to the Unicode value of the first character. Index values beyond the end of the string will always return zero.

## Adding Strings

As well as adding numbers, the addition operator can be used to concatenate strings. So, the expression `"AB"+"CD"` evaluates to "ABCD". You may also use the addition operator to add an integer to a string, in which case a single character equal to the Unicode representation of the integer is appended to the data in the string.

## Calling Programs

Programs that return values may be invoked within expressions by following the program name with a pair of parentheses. For example, `Program1()*10` will invoke the associated program, and multiply the return value by 10. Obviously, the return type for `Program1` must be set to integer or floating point for this to make sense.

## Using Functions

MonicoView 3.1 provides a number of predefined functions that can be used to access system information, or to perform common math operations. These functions are defined in detail in the Function Reference. They are invoked using a syntax similar to that for programs, with any arguments to the function being enclosed within the parentheses. For example, `cos(0)` will invoke the cosine function with an argument of 0, returning a value of +1.0.

## Priority Summary

The table below shows the priority of all the operators defined in this section:

GROUP	OPERATORS
Group 1	.
Group 2	! ~
Group 3	* / %
Group 4	+ -
Group 5	<< >>
Group 6	< > <= >=
Group 7	== !=
Group 8	&
Group 9	
Group 10	^

Group 11	&&
Group 12	
Group 13	?:

Operators in the lower-numbered groups are applied first.

# Chapter 25 Writing Actions

While expressions define values, actions define what you want to happen when an event occurs. Most of the actions in a database will relate to interactions with primitives or with the keyboard. Since MonicoView 3.1 provides a simple method of defining commonly used actions for these items, you will often be able to avoid writing actions by hand. Actions are needed, though, if you want to use triggers, write programs, or use primitives in User Defined mode.

## Changing Page

To create an action that changes the page shown on the panel's display, use the syntax `GotoPage (Name)`, where `Name` is the name of the display page in question. The current page will be removed, and the new page will be displayed in its place.

## Changing Numeric Values

MonicoView 3.1 provides several ways of changing data values.

### Simple Assignment

To create an action that assigns a new value to a tag or to a register in a communications device, use the syntax `Data=Value`, where `Data` is the data item to be changed, and `Value` is the value to be assigned. Note that `Value` need not just be a constant value, but can be any valid expression of the correct type. Refer to the previous section for details of how to write expressions. For example, code such as `[N7:0]=Tank1+Tank2` can be used to add two tank levels and store the total quantity directly in a PLC register. Note that all assignment operators fall into Group 14. In other words, they will be evaluated after all other operators in an action. They are also unique in that they group right-to-left. This means that a code fragment such as `Tag1=Tag2=Tag3=0` can be used to clear all three tags at once.

### Compound Assignment

To create an action that sets a data value equal to its current value combined with another value by means of any of the operators defined in the previous section, use the syntax `Dataop=Value`, where `Data` is the tag to be changed, `Value` is the value to be used by the operator, and `op` is any of the available operators. For example, the code `Tag+=10` will increase `Tag` by a value of 10, while `Tag*=10` will multiply the current value by 10.

### Increment and Decrement

To create an action that increases a data value by one, use the syntax `Data++`. To create an action that decreases a tag by one, use the syntax `Data--`. Note that the `++` or `--` operators may be placed before or after the data value in question. In the former case, the value of the expression represented by `++Data` is equal to the value of `Data` *after* it has been incremented. In the latter case, the expression is equal to the value *before* it has changed.

## Changing Bit Values

To change a bit within a tag, use the syntax `Data.Bit=1` or `Data.Bit=0` to set or clear the bit as required, where `Data` is the tag in question and `Bit` is the zero-based bit number. Note again that the value on the right-hand side of the `=` operator can be an expression if desired, such that an

example such as `Data.1=(Level>10)` can be used to set or clear a bit depending on whether or not a tank level exceeds a preset value.

## Running Programs

Programs may be invoked within actions by following the program name with a pair of parentheses. For example, `Program1()` will invoke the associated program. The program will execute in the foreground or background as defined by the program's properties.

## Using Functions

MonicoView 3.1 provides a number of predefined functions that can be used to perform various operations. These functions are defined in detail in the Function Reference. They are invoked using a syntax similar to that for programs, with any arguments to the function being enclosed within the parentheses. For example, `SetLanguage(1)` will set the terminal language to 1.



# Chapter 26 Advanced Debugging

MonicoView 3.1 contains various facilities to make it easier for you to create and debug complex programs. These facilities are accessed via debug consoles, each of which provides a mechanism for displaying diagnostic messages and optionally entering system commands.

## Accessing a Console

Debug consoles may be created in one of three ways...

- The web server may be configured to display a web-accessible console;
- A serial port may be configured to act as a serial debug console; and
- A network protocol may be configured to provide a TCP/IP debug console.

**Since debug consoles provide low-level system access, they should not be left enabled in production units unless appropriate security is put in place.** For the web server, this means using the security settings to restrict access to a subset of authenticated users. For a serial console, this means restricting physical access to the device. And for a TCP/IP console, this means disabling the facility completely as it cannot reasonable be secured.

## Viewing Output

Various elements within MonicoView will output information to whatever debug consoles are active at the time. The MQTT connectors and the OPC-UA Server can be configured to output information via the Debug Output property, as can services like the FTP server, the FTP client of the Sync Manager and the SMTP client of the Mail Manager. **Since debug output will have an impact on performance, it should not be left enabled in production units.**

The debugging output produced by MonicoView is intended for advanced users who already have knowledge of the protocol that they are monitoring. We shall not therefore be providing information in this manual as to the content of that output or how it is to be interpreted. If you need help diagnosing connection problems, please contact Monico Technical Support, who may themselves ask you to forward the associated debugging information.

## Debugging Programs

When creating complex sets of programs, it is sometimes difficult to know what is going on within a MonicoView device. If you refer to the earlier section on *Creating Programs*, you will note that several properties have been added to the make it easier to see under the hood.

Enabling debug output will print a message to all active consoles whenever certain actions occur. The example below shows the output that might be produced when a button on a page calls a program that then sets certain local variables (*i*, *j* and *k*) and then calls another program that sets another local variable, before adjusting some tags and then returning a value that is assigned by the original action to `Tag1...`

```

957.570 : USER      : Pages.Page1.ImageButton1.Action.Press(px = 69, py =
32)
957.570 : USER      :   Program1(a = 1234, b = 1.234, c = "1234")
957.570 : USER      :     i := 1
957.570 : USER      :     j := 3.141
957.570 : USER      :     k := "FRED"
957.570 : USER      :   Program2(void)
957.570 : USER      :     b := 2
957.570 : USER      :     return
957.570 : USER      :   Tag2 := 1
957.570 : USER      :   Tag3 := 3.141
957.570 : USER      :   Tag4 := "FRED"
957.570 : USER      :   return 5678
957.570 : USER      :   Tag1 := 5678
957.570 : USER      :   return

```

Each line starts with a timestamp in seconds and millisecond, followed by the name of the task that is executing the code. (This will typically be *USER* but can be *SCANNER* for triggers or *DISPATCH* for programs run in the background.) The balance of the line shows the action that was carried out, with indentation being used to show nested program calls. The very first line shows the action that set the whole chain in motion, this being an *On Press* action on an image button located on *Page1*. You will notice that the action has two parameters, these being the x and y coordinates of the touch event that triggered the button. (You probably did not know about these since they were not documented!) Subsequent function calls also include any parameters, plus, if appropriate the return value.

## Running Commands

If you are using the web console in command mode or any of the other consoles, you may also enter commands. These commands typically take the form of an object name followed by a dot and then the action to be executed. A list of available commands can be obtained by typing `diag.help` or just `help`—but note that many of these commands concern the internal operation of MonicoView and will not be documented here. **These system commands are left available in case you are requested to use them by Monico technical support. Using them without understanding their operation may interrupt your device's operation or even cause data loss.** That said, several of the more useful commands are described below.

### Tag Commands

- `tags.list` will list all the tags in the system;
- `tags.list name` will list all the tags starting with *name*;
- `tags.get tag` will display the current value of *tag*; and
- `tags.set tag value` will set *tag* to *value* per its format object.

### Program Commands


- `progs.list` will list all the programs in the system; and
- `progs.run prog` will run *prog* in the background.

# Chapter 27 Asset I/O Modules


This chapter provides information on how to configure the I/O modules supported by the Asset range of HMIs and the associated controllers. While communications modules are configured via the Communications tab, I/O and control modules have their own dedicated I/O Modules category at the bottom of the categories list.

## Selecting Modules

As mentioned above, modules are selected via the I/O Modules category:



To add a module, select the required slot and press the New button to display a dialog box:




Select the appropriate module and press OK to close the dialog. After the module has been created, you may provide a descriptive name by right-clicking on the module that was added and then selecting Rename or by simply pressing the F2 key. Additional modules can be added by repeating the process. Modules can be moved between slots by drag-and-drop.

## The GMTC and GMRTD Temperature Modules

The GMTC and GMRTD parameters are broken into two groups, each with their own page.

### Configuration Properties




#### General

- *Temperature Units* selects the Kelvin, Fahrenheit, or Celsius temperature scale.
- The *Input Filter* is a time constant used to stabilize fluctuating input signals.

#### Inputs

- The *Enabled* property provides a means to disable unused inputs, thereby increasing the rate at which the remaining inputs are read. See the module hardware bulletin for more information on the resulting update rates.
- The *Thermocouple* or *RTD* property is used to select the sensor standard being used, with the available options being defined by the module type. The Millivolt option is available on GMTC modules to indicate that the input is to be used as a linearly-scaled voltage input rather than a thermocouple input.
- The *Slope* and *Offset* properties can be used to adjust or rescale the PV value to compensate for an error in the attached sensor. They can also allow correction of the PV value in applications in which the sensor isn't measuring the process directly, thereby inducing a fixed or variable offset. The GMPID section above provides a worked example on how to configure these properties.

### Millivolt Properties (GMTC Only)



## General

- The *Decimal Places* property is used to allow MonicoView 3.1 to display the engineering units in the proper resolution. This is only used to display the appropriate resolution throughout the software, and is not used within the module.

## Millivolt Scaling

- For inputs configured to Millivolt mode on the Configuration tab, the *Display Low* and *Display High* properties are used together with the *Signal Low* and *Signal High* properties to scale the input voltage into appropriate display units. For example, suppose an application employs a sensor that produces 0 to 42.5mV for a pressure of 0 to 1000psi. Enter 0 for *Display Low* and 1000 for *Display High* to set the display range, and then enter 0 for *Signal Low* and 42.5 for *Signal High* to set the input corresponding range.

## Available Data

The tables below show the module data values that are available to the Asset Series HMI host.

### Input/Status

DATA	DESCRIPTION	RANGE	ACCESS
PV1-8	Process Value, after slope and offset calculation.	Pro Sensor	R
ColdJunc	Cold Junction Calibration value.	n. z.	R
InputAlarm1-8	Input Out of Range indicator.	0 or 1 (bit)	R

### Input/Control

DATA	DESCRIPTION	RANGE	ACCESS
InputFilter	Input Filter	0 – 60.0 sec	R/W
InputOffset1-8	Offset value added to PV.	Per Sensor	R/W
InputSlope1-8	Slope value applied to PV.	.001 – 10.000	R/W


### Input/ScaleMvInputs

DATA	DESCRIPTION	RANGE	ACCESS
DispLo1-8	Display Low 1-8	+/-30,000	R/W
DispHi1-8	Display High 1-8	+/-30,000	R/W
SigLo1-8	Signal Low 1-8	-10.00 – +56.00	R/W
SigHi1-8	Signal High 1-8	-10.00 – +56.00	R/W

## The GMINI And GMINV Analog Input Modules

The GMINI and GMINV parameters are configured on a single page.

## Configuration Properties



### General

- The *Input Filter* is a time constant used to stabilize fluctuating input signals.
- The *Input Range* property selects between available input ranges.

### Inputs

These settings allow independent customization of each input's parameters.

- The *Enabled* property provides a means to disable unused inputs, thereby increasing the rate at which the remaining inputs are read. See the hardware bulletin for more information regarding reading rates.
- The *Decimals* property is used to allow MonicoView 3.1 to display the engineering units in the proper resolution. This is only used to display the appropriate resolution throughout the software, and is not used within the module.
- The *PV at 0%* and *PV at 100%* properties are used to scale DC input signals. Enter the desired PV reading for the minimum and maximum input signal levels. For example, if the application accepts an input from a flow sensor with a 4 to 20 mA output that represents 5 to 105 gallons per minute, select Process 420mA for the *Input Type*, enter 5 for *PV at 0%* and enter 105 for *PV at 100%*.
- The *Square Root* property allows the unit to be used in applications in which the measured signal is the square of the PV. This is useful in applications such as the measurement of flow with a differential pressure transducer.

## Available Data

The tables below show the module data values that are available to the Asset Series HMI host.

### Input/Status

DATA	DESCRIPTION	RANGE	ACCESS
PV1-8	Process Value – scaled per channel settings.	Per Sensor	R
InputAlarm1-8	Input Out of Range indicator.	0 or 1 (bit)	R


### Input/Control

DATA	DESCRIPTION	RANGE	ACCESS
InputFilter	Input Filter.	0 – 60.0 sec	R/W
ProcessMin1-8	Desired PV at minimum input signal level.	+/- 30,000	R/W
ProcessMax1-8	Desired PV at maximum input signal level.	+/- 30,000	R/W

## The GMOUT Analog Output Module

The GMOUT module's parameters are broken into two groups, each with their own page.


### Configuration Properties



#### Output 1 to Output 4

- The *Output Type* property is used to select between 0-5V, 0-10V, +/-10V, 0-20mA or 4-20 mA outputs.
- The *Decimal Places* property is used to allow MonicoView 3.1 to display the data values in the proper resolution. This is only used to display the appropriate resolution within MonicoView 3.1, and is not used within the module.
- The *Data Low* and *Data High* properties are used in conjunction with the *Output Low* and *Output High* properties to scale the output from raw data value's unit of measure. For example, if the application involves a data value of 0.0 to 500.0 that will provide an output of 1.000 to 5.000V, enter 0 for the *Data Low* property and 500 for the *Data High* property to set the data range, and then enter 1V for the Output Low and 5V for the Output High properties to set the output range.

### Initial Output Properties




#### Initialization

- The *Include in Download* property is used to determine whether the initialization values will be downloaded to the module. Selecting no allows modification and download of databases at will, without accidentally overwriting the values.
- The *Data 1* to *Data 4* properties are the initial output values used for Output 1 to Output 4, respectively. These values are scaled per the Data Low, Data High, Output Low and Output High properties described on the previous page.

## Output Action

The output is controlled to “peg” at the *Output Low* and *Output High* values. In other words, if a data value that is less than *Data Low* is written to the module, the output will remain at *Output Low* and the alarm will turn on. Likewise, if a data value that is greater than *Data High* value is used, the output will go to *Output High* and the alarm will again turn on.



## Available Data

The tables below show the module data values that are available to the Asset Series HMI host.

### Data

DATA	DESCRIPTION	RANGE	ACCESS
Data1	Output 1 scaled value.	DataLo1 to DataHi1	R/W
Data2	Output 2 scaled value.	DataLo2 to DataHi2	R/W
Data3	Output 3 scaled value.	DataLo3 to DataHi3	R/W
Data4	Output 4 scaled value.	DataLo4 to DataHi4	R/W

### Scaling

DATA	DESCRIPTION	RANGE	ACCESS
DataLo1	Output 1 data low value.	+/-30,000	R/W
DataLo2	Output 2 data low value.	+/-30,000	R/W
DataLo3	Output 3 data low value.	+/-30,000	R/W
DataLo4	Output 4 data low value.	+/-30,000	R/W
DataHi1	Output 1 data high value.	+/-30,000	R/W
DataHi2	Output 2 data high value.	+/-30,000	R/W
DataHi3	Output 3 data high value.	+/-30,000	R/W
DataHi4	Output 4 data high value.	+/-30,000	R/W
OutputLo1	Output 1 output low value.	Per Modus	R/W
OutputLo2	Output 2 output low value.	Per Modus	R/W
OutputLo3	Output 3 output low value.	Per Modus	R/W
OutputLo4	Output 4 output low value.	Per Modus	R/W
OutputHi1	Output 1 output high value.	Per Modus	R/W
OutputHi2	Output 2 output high value.	Per Modus	R/W
OutputHi3	Output 3 output high value.	Per Modus	R/W
OutputHi4	Output 4 output high value.	Per Modus	R/W




## Alarms

DATA	DESCRIPTION	RANGE	ACCESS
Alarm1	Output 1 alarm status	0 or 1 (bit)	R
Alarm2	Output 2 alarm status	0 or 1 (bit)	R
Alarm3	Output 3 alarm status	0 or 1 (bit)	R
Alarm4	Output 4 alarm status	0 or 1 (bit)	R

## The GMDIO Digital I/O Module

The GMDIO parameters are contained on a single page.

## Configuration Properties



- The *Input Mode* property determines whether high or low should be considered active for each input channel. Note that the sourcing or sinking mode of an input is configured via hardware links. See the product bulletin for more information.
- The *Output Mode* property determines the output state for each channel on system startup. Use Default to force the output to the last known state. Use Active LO or Active Hi to force the output to the state specified.

## Available Data

The tables below show the module data values that are available to the Asset Series HMI host.

### Variables/Inputs

DATA	DESCRIPTION	RANGE	ACCESS
Input1-8	Input State	0 or 1 (bit)	R


### Variables/Outputs

DATA	DESCRIPTION	RANGE	ACCESS
Output1-6	Output State	0 or 1 (bit)	R/W

## The GMUIN Universal Input Module

The GMUIN module's parameters are broken one page for each of the four channels.

## Input Properties



### Operation

- The *Input Type* property is used to select among the following inputs: 0-10V, 0-50mV, 0-20mA, 4-20mA, RTD or Thermocouple.
- The *TC / RTD* property is used to select the sensor standard being used.
- The *Input Filter* is a time constant used to stabilize fluctuating input signals.
- The *Slope* and *Offset* properties can be used to adjust or rescale the PV value to compensate for an error in the attached sensor. They can also allow correction of the PV value in applications in which the sensor isn't measuring the process directly, thereby inducing a fixed or variable offset. The GMPID section above provides a worked example on how to configure these properties.

### Units

- *Temperature Units* selects between Kelvin, Fahrenheit or Celsius.
- The *Process Units* property allows you to enter the engineering units for the process, while the *Decimal Places* property is used to allow MonicoView 3.1 to display the engineering units in the proper resolution. These are only used to identify the appropriate fields throughout the software. The parameters are saved as part of the MonicoView 3.1 file, but are not used within the module.
- The *Process at 0%* and *Process at 100%* properties are used to scale DC input signals. Enter the desired PV reading for the minimum and maximum input signal levels. For example, if the application accepts an input from a flow sensor with a 4 to 20 mA output that represents 5 to 105 gallons per minute, select Process 420mA for the *Input Type*, enter 5 for the *Process at 0%* setting and enter 105 for the *Process at 100%* setting.
- The *Square Root* property allows the unit to be used in applications in which the measured signal is the square of the PV. This is useful in applications such as the measurement of flow with a differential pressure transducer.

### Available Data

The tables below show the module data values that are available to the Asset Series HMI host.

#### Input/Status

DATA	DESCRIPTION	RANGE	ACCESS
PV1-4	Process Value after slope and offset calculation.	PER Sensor	R
ColdJunc1-4	Cold Junction Calibration value.	N/A	R
InputAlarm1-4	Input out of range indicator.	0 or 1 (bit)	R

## Input/Control

DATA	DESCRIPTION	RANGE	ACCESS
InputFilter1-4	Input Filter.	0 – 60.0 sec	R/W
InputOffset1-4	Offset value added to PV.	Per Sensor	R/W
InputSlope1-4	Slope value applied to PV.	.001 – 10.000	R/W

