



# Monico Asset Gateway With Protocol Conversion Capability and I/O Expansion Capability

## Installation Guide

- Rugged controller with built-in control engine
- Protocol conversion feature converts 13 protocols simultaneously
- Over 300 built-in drivers allows easy data mapping to PLCs, PCs, and SCADA systems
- Built-in web server allows remote view or control from any internet-connected PC or smart phone
- Syncs data logs to FTP servers and Microsoft SQL Server®
- Provides email and SMS text message alerts
- Configured using MonicoView™ 3.1 software with MonicoView Control
- 3 fully isolated serial communication ports (1 RS232 and 2 RS422/485)
- 2 10 BASE T/100 BASE-TX Ethernet connections can connect to an unlimited number of devices via ten protocols simultaneously
- Integrated Asset Gateway rack expansion port. Add up to 4 GEXRACK2 3 port expansion racks
- Cast aluminum case construction supports DIN rail and panel mount



## GENERAL DESCRIPTION

The Monico Asset Gateway is designed to remotely connect, monitor and control equipment in process applications. At the core of the product is MonicoView 3.1 featuring an embedded IEC61131 control engine, that can be configured via Ladder, Function Block, Structured Text, and Instruction List. Additionally, the Monico Asset Gateway is optimized for multi-vendor environments with powerful protocol conversion, built-in data logging and a virtual operator interface for remotely viewing equipment and processes. The Asset Gateway can be expanded to meet almost any application requirement through the use of plug-in digital and analog I/O modules that leverage the Asset Gateway Expansion Racks. The integrated rack port supports 4 GEXRACK2 bases (12 modules). An additional 12 modules can be added using the USB host port (GEXRACK1, 3 GEXRACK2).

Monico's industry leading protocol library offers access to over 300 drivers including PLCs, drives, cameras, bar code readers and many other devices providing easy data mapping to PLCs, PCs, and SCADA Systems. In addition, the Asset Gateway can convert over 13 protocols simultaneously, seamlessly connecting and communicating with disparate devices. Monico Asset Gateways offer numerous communication ports including high-speed RS-232/485 and 10 Base T/100 Base-TX Ethernet ports. Additionally, the Asset Gateway features built-in USB host ports for fast downloads of configuration files and access to trending and data logging information. Eliminate the need for external protocol converters and use an Asset Gateway to connect and control to all your devices.

The Monico Asset Gateway can be programmed with Monico's MonicoView 3.1 software using a simple drag and drop interface to configure data tags, virtual displays, protocol conversion and data logging in minutes. Embedded in MonicoView 3.1 software platform is the IEC 61131 control engine, MonicoView Control which can be written in 4 programming languages including Ladder, Function Block, Structured Text, and Instruction List. The controller comes with MonicoView Control functionality enabled, without the need for additional equipment or modules.

Monico's Asset Gateway is housed in an all-aluminum housing, which provides reliable operation that can withstand even the most demanding environments. The result is an industrially-hardened solution that connects, monitors, and controls disparate equipment in multi-vendor applications.

## CONTENTS OF PACKAGE

- Monico Asset Gateway
- Terminal block for connecting power
- (1) Module port cover
- Downstream port cover
- Installation Guide

## ORDERING INFORMATION

For a quote or ordering information, please contact your Monico Sales Engineer at [sales@monicoinc.com](mailto:sales@monicoinc.com) or 281-350-8751 option 3 to determine the correct preconfigured solution for your application.

## SAFETY SUMMARY

All safety related regulations, local codes and instructions that appear in this document or on equipment must be observed to ensure personal safety and to prevent damage to either the device or equipment connected to it.

Do not use the controller to directly command motors, valves, or other actuators not equipped with safeguards. To do so can be potentially harmful to persons or equipment in the event of a fault to the unit.



### CAUTION: Risk of Danger

Read complete instructions prior to installation and operation of the unit.

### ATTENTION : Risque de danger

Lire les instructions complètes avant l'installation et l'utilisation de l'appareil.



**WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR AREA IS KNOWN TO BE NON-HAZARDOUS.**  
**AVERTISSEMENT - DANGER D'EXPLOSION - NE PAS DÉBRANCHER L'ÉQUIPEMENT À MOINS QUE L'ALIMENTATION ÉLECTRIQUE N'AIT ÉTÉ COUPÉE OU QUE LA ZONE NE SOIT CONNUE COMME ÉTANT NON DANGEREUSE.**



**WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.**  
**AVERTISSEMENT - DANGER D'EXPLOSION - LE REMPLACEMENT DE COMPOSANTS PEUT NUIRE À L'APTITUDE À LA CLASSE I, DIVISION 2.**

## SPECIFICATIONS

### 1. POWER REQUIREMENTS:

Must use a Class 2 circuit according to National Electrical Code (NEC), NFPA-70 or Canadian Electrical Code (CEC), Part I, C22.1 or a Limited Power Supply (LPS) according to IEC 60950-1 or Limited-energy circuit according to IEC 61010-1.

Power connection via removable three position terminal block.

Supply Voltage: 10-30 VDC

	GATEWAY POWER RATINGS (WATTS)			
Input Voltage	10 V	12 V	24 V	30 V
Typical Power Gateway only:	4 W	4 W	5 W	5 W
Maximum Power Gateway only:	9 W	9 W	10 W	10 W
Available Power for Modules:	55 W			
Max Power Gateway With Module(s):	64 W	64 W	67 W	67 W

**2. BATTERY:** Lithium coin cell. Typical lifetime of 6 years, nominal.

### 3. MEMORY:

On Board User Memory: 256 Mbyte of non-volatile Flash memory.

Memory Card: SD slot accepts standard capacity cards.

### 4. COMMUNICATION CAPABILITIES:

**USB Port:** Adheres to USB specification 2.0 (high speed, full speed) only using Type B connection.



**WARNING - DO NOT CONNECT OR DISCONNECT CABLES WHILE POWER IS APPLIED UNLESS AREA IS KNOWN TO BE NON-HAZARDOUS.**

**AVERTISSEMENT - NE PAS CONNECTER OU DÉBRANCHER LES CÂBLES PENDANT QUE L'ALIMENTATION EST APPLIQUÉE SAUF SI LA ZONE EST CONNUE POUR ÊTRE NON DANGEREUSE**

**USB Host Ports:** Comply with Universal Serial Bus Specification Rev 2.0. Support data transfers at (high speed, full speed). Hardware over current protected (0.5 A max per port).

**Serial Ports:** Ports are individually isolated. Format and Baud Rates for each port are individually software programmable up to 115,200 baud. PGM Port: RS232 port via RJ12.

COMMS Ports: RS422/485 ports via RJ45

DH485 TXEN: Transmit enable; open collector,  $V_{OH} = 15$  VDC,  $V_{OL} = 0.5$  V @ 25 mA max.

Port to Port Isolation: 500 Vrms for 1 minute. Signal Isolation: 50 V.

**Ethernet Ports:** 10 BASE-T / 100 BASE-TX

RJ45 jack is wired as a NIC (Network Interface Card).

Isolation from Ethernet network to Gateway: 1500 Vrms

### 5. ENVIRONMENTAL CONDITIONS:

Operating Temperature Range: -40 to 70 °C, or lowest range among equipment used in your Asset Gateway system. Consult the user manual or contact [support@monico.com](mailto:support@monico.com) for further details.

Storage Temperature Range: -40 to 85 °C

Panel Mount Vibration to IEC 68-2-6: Operational 5-500 Hz, 4 g

Panel Mount Shock to IEC 68-2-27: Operational 40 g (10 g, modules w/relays)

DIN Rail Mount Vibration to IEC 68-2-6: Operational 5-500 Hz, 2 g

DIN Rail Mount Shock to IEC 68-2-27: Operational 15 g (10 g, modules w/relays)

Requires DIN Rail type: DIN 1010, DIN 1065, or DIN 3065.

Operating and Storage Humidity: 0 to 85% max. RH non-condensing

Altitude: Up to 2000 meters

Installation Category II, Pollution Degree 2 as defined in IEC/EN 60664-1.

### 6. CERTIFICATIONS AND COMPLIANCES:

#### CE Approved

EN 61326-1 Immunity to Industrial Locations

Emission CISPR 11 Class A

IEC/EN 61010-1

RoHS Compliant

#### ATEX Approved

II 3 G Ex nA IIC T4 Gc

DEMKO 14 ATEX 1387X

EN 60079-0, -15

#### IECEx Approved

Ex nA IIC T4 Gc

IECEx UL 15.0035X

IEC 60079-0, -15

UL Listed: File #E302106

UL Hazardous: File #E317425

#### ABS Type Approval for Shipboard Applications

### 7. CONNECTIONS:

High compression cage-clamp terminal block

Wire Strip Length: 0.3" (7.5 mm)

Wire Gage Capacity: One 14 AWG (1.63 mm) solid, two 18 AWG (1.02 mm) or four 20 AWG (0.81 mm)


Torque: 4.43-5.31 inch-lbs (0.5-0.6 N-m)

### 8. CONSTRUCTION:

Cast aluminum.


### 9. WEIGHT: 2 lb 4.2 oz. (1.03 Kg)

## DIMENSIONS In inches (mm)



## ASSET GATEWAY INSTALLATION PANEL MOUNTING INSTRUCTIONS


The Gateway can be mounted on a DIN rail for normal environments, or bolted to a panel for high vibration environments. Refer to the diagram for the panel mount hole spacing.



## DIN RAIL MOUNT AND CAM OPERATION

DIN rail mounting is only recommended in low vibration environments. Refer to the Specifications section for details.

1. Using a screwdriver, push in and fully rotate the Cam counter-clockwise to push the DIN clip downward against spring pressure locking it open
2. Place the Gateway on the DIN rail
3. Using a screwdriver, push in and rotate the Cam 90 degrees clockwise to release the DIN clip to engage the DIN rail
4. Rotate the Cam an additional 90 degrees clockwise to lock the DIN clip in the closed position.



For hazardous location installation the following shall be taken into consideration:

- When used in a Zone 2 environment, the device shall be panel mounted in at least Zone 2 IECEx/ATEX-Certified tool accessible enclosure with a minimum ingress protection rating of at least IP54 as defined in IEC/EN 60529.
- The equipment shall only be used in an environment of not more than Pollution Degree 2, as defined in IEC/EN 60664-1.
- Must be wired using Division 2 wiring methods as specified in article 501-4(b), 502-4(b), and 503-3(b) of the National Electric Code, NFPA 70 for installation within the United States, or as specified in section 19-152 of Canadian Electrical Code for installation in Canada.

## CONNECTING TO EARTH GROUND

The third pin of the power connector of the Asset Gateway is chassis ground for the unit. Your unit should be connected to earth ground.

The chassis ground is not connected to signal common of the unit. Maintaining isolation between earth ground and signal common is not required to operate your unit. But, other equipment connected to this unit may require isolation between signal common and earth ground. To maintain isolation between signal common and earth ground care must be taken when connections are made to the unit. For example, a power supply with isolation between its signal common and earth ground must be used. Also, plugging in a USB cable may connect signal common and earth ground.<sup>1</sup>

<sup>1</sup> USB's shield may be connected to earth ground at the host. USB's shield in turn may also be connected to signal common.

## POWER SUPPLY REQUIREMENTS

The Monico Asset Gateway requires a 10-30 VDC power supply. Your unit may draw considerably less than the maximum rated power depending upon the features being used, and the applied voltage. As additional features are used your unit will draw increasing amounts of power. Items that could cause increases in current are modules, additional on-board communications, SD card, and other features programmed through MonicoView 3.1 software.

*Note: Modules connected via a GEXRACK1 to the Asset Gateway, are powered by the GEXRACK1 and not the Asset Gateway*

To ensure you do not exceed the capacity of your Asset Gateway power supply, calculate the total power consumption required for all of your planned modules. Each module's maximum power consumption is listed in the Specifications of their Product Bulletin. The total power available for modules is listed in the specifications of the Asset Gateway host.

In any case, it is very important that the power supply is mounted correctly if the unit is to operate reliably. Please take care to observe the following points:

- Voltage range stated is at the power connector, not at the power source.
- The power supply must be mounted close to the unit, with usually not more than 6 feet (1.8 m) of cable between the supply and the operator interface. Ideally, the shortest length possible should be used.
- The wire used to connect the operator interface's power supply should be at least 22-gage wire suitably rated for the temperatures of the environment to which it is being installed. If a longer cable run is used, a heavier gage wire should be used. The routing of the cable should be kept away from large contactors, inverters, and other devices which may generate significant electrical noise.
- A power supply with an NEC Class 2 or Limited Power Source (LPS) and SELV rating is to be used. This type of power supply provides isolation to accessible circuits from hazardous voltage levels generated by a mains power supply due to single faults. SELV is an acronym for "safety extra-low voltage." Safety extra-low voltage circuits shall exhibit voltages safe to touch both under normal operating conditions and after a single fault, such as a breakdown of a layer of basic insulation or after the failure of a single component has occurred. A suitable disconnect device shall be provided by the end user.
- Peak efficiency (Gateway) occurs at the low side of the voltage range (approx. 12 V), recommended for high temperature applications.

## EMC INSTALLATION GUIDELINES

Although Monico products are designed with a high degree of immunity to Electromagnetic Interference (EMI), proper installation and wiring methods must be followed to ensure compatibility in each application. The type of the electrical noise, source or coupling method into a unit may be different for various installations. Cable length, routing, and shield termination are very important and can mean the difference between a successful or troublesome installation. Listed are some EMI guidelines for a successful installation in an industrial environment.

1. A unit should be mounted in a metal enclosure, which is properly connected to protective earth.
2. Use shielded cables for all Signal and Control inputs. The shield connection should be made as short as possible. The connection point for the shield depends somewhat upon the application. Listed below are the recommended methods of connecting the shield, in order of


their effectiveness.

- a. Connect the shield to earth ground (protective earth) at one end where the unit is mounted.
- b. Connect the shield to earth ground at both ends of the cable, usually when the noise source frequency is over 1 MHz.
3. Never run Signal or Control cables in the same conduit or raceway with AC power lines, conductors, feeding motors, solenoids, SCR controls, and heaters, etc. The cables should be run through metal conduit that is properly grounded. This is especially useful in applications where cable runs are long and portable two-way radios are used in close proximity or if the installation is near a commercial radio transmitter. Also, Signal or Control cables within an enclosure should be routed as far away as possible from contactors, control relays, transformers, and other noisy components.
4. Long cable runs are more susceptible to EMI pickup than short cable runs.
5. In extremely high EMI environments, the use of external EMI suppression devices such as Ferrite Suppression Cores for signal and control cables is effective. The following EMI suppression devices (or equivalent) are recommended:  
Fair-Rite part number 0443167251  
Line Filters for input power cables:  
Schaffner # FN2010-1/07
6. To protect relay contacts that control inductive loads and to minimize radiated and conducted noise (EMI), some type of contact protection network is normally installed across the load, the contacts or both. The most effective location is across the load.
  - a. Using a snubber, which is a resistor-capacitor (RC) network or metal oxide varistor (MOV) across an AC inductive load is very effective at reducing EMI and increasing relay contact life.
  - b. If a DC inductive load (such as a DC relay coil) is controlled by a transistor switch, care must be taken not to exceed the breakdown voltage of the transistor when the load is switched. One of the most effective ways is to place a diode across the inductive load. However external diode protection at the load is always a good design practice to limit EMI. Although the use of a snubber or varistor could be used.
7. Care should be taken when connecting input and output devices to the

instrument. When a separate input and output common is provided, they should not be mixed. Therefore a sensor common should NOT be connected to an output common. This would cause EMI on the sensitive input common, which could affect the instrument's operation. 8. For GEXRACK1 connection, recommend Tripp Lite Model: U023-006 6 ft cable.

## I/O MODULE INSTALLATION

The physical order of all installed modules must match the modules order as set in MonicoView 3.1 database. Torque screws to 6.0 pound-force inch [96 ounce-force inch] (0.68 Nm).



## COMMUNICATING WITH THE GATEWAY CONFIGURING AN ASSET GATEWAY

The Gateway is configured using MonicoView 3.1 software. MonicoView 3.1 software is available as a no charge download from Monico's website. MonicoView 3.1 updates for new features and drivers are posted on the website as they become available. By configuring the Asset Gateway using the latest MonicoView 3.1 version, you are assured that your unit has the most up to date feature set. MonicoView 3.1 software can configure the controller through the RS232 PGM port, USB port, ethernet port or SD card.

The USB port is connected using a standard USB cable with a Type B connector. The driver needed to use the USB port will be installed as part of MonicoView configuration.

The RS232 PGM port uses a programming cable made by Monico to connect to the DB9 COM port of your computer. If you choose to make your own cable, use the "Monico Asset Gateway Port Pin Out Diagram" for wiring information.

The SD card can be used to program a Gateway by placing a configuration file and firmware on the SD card. The card is then inserted into the target controller and powered. Refer to the MonicoView 3.1 literature for more information on the proper names and locations of the files.


### SYSTEM LEDs

COLOR	STATUS
GREEN (STS)	Bootloader/Power
GREEN (SD)	File system SD Card

### USB HOST LEDs

COLOR	STATUS
OFF	Not operational
RED	Error
GREEN	Normal operation

## USB, DATA TRANSFERS FROM THE SD CARD




In order to transfer data from the SD card via the USB port, a driver must be installed on your computer. This driver is installed with MonicoView 3.1 software and is located in the folder C:\Program Files\Monico\MonicoView 3.1\Device\ after installation. This may have already been accomplished if your controller was configured using the USB port.

Once the driver is installed, connect the controller to your PC with a USB cable, and follow "Mounting the SD" instructions in the MonicoView 3.1 user manual.

## INSERTION/REMOVAL OF THE SD CARD

Insert the SD card into the slot provided with the card oriented as shown. The card is inserted properly when the end of the card is flush with the Asset Gateway case. To remove the SD card, push in slightly on the card.

Warning: Do not remove the SD card while power is applied.



## ETHERNET COMMUNICATIONS

Ethernet communications can be established at either 10 BASE-T or 100 BASE-TX. The Asset Gateway unit's RJ45 jack is wired as a NIC (Network Interface Card). It auto-detects remote transmit and receive pairs and correctly assigns the transmit and receive pairs. This feature enables the user to use whichever type of cable (cross-over or straight) is available.

The Ethernet connector contains two LEDs. A yellow LED in the upper right, and a green LED in the upper left. The LEDs represent the following statuses:

LED COLOR	DESCRIPTION
YELLOW solid	Link established.
YELLOW flashing	Data being transferred.
GREEN (OFF)	10 BASE-T Communications
GREEN (ON)	100 BASE-TX Communications

A 12-digit MAC address label is provided for each Ethernet port. Refer to the MonicoView 3.1 manual and Monico's website for additional information on Ethernet communications.


## RS232 PORTS

The Asset Gateway has a single RS232 port. The port can be used for either master or slave protocols with any Asset Gateway configuration.

ASSET GATEWAY RS232 TO A PC			
Gxx: RJ12	Name	PC: DB9	Name
4	COMM	1	DCD
5	Tx	2	Rx
2	Rx	3	Tx
	N/C	4	DTR
3	COMM	5	GND
	N/C	6	DSR
1	CTS	7	RTS
6	RTS	8	CTS
	N/C	9	RI

## RS422/485 COMMS PORT

The Gateway has two RS422/485 ports. These ports can be configured to act as either RS422 or RS485.



## Examples of RS485 2-Wire Connections


ASSET GATEWAY TO RJ11			
GXX: RJ45	Name	RLC: RJ11	Name
5	TxEN	2	TxEN
6	COMM	3	COMM
1	TxB	5	B-
2	TxA	4	A+

## DH485 COMMUNICATIONS

The Monico Asset Gateway's RS422/485 COMMS port can also be used for Allen Bradley DH485 communications.

ASSET GATEWAY TO AB SLC 500			
RJ45: RLC	Name	RJ45: A-B	Name
1	TxB	1	A
2	TxA	2	B
3, 8	RxA	-	24 V
4, 7	RxB	-	COMM
5	TxEN	5	TxEN
6	COMM	4	SHIELD
4, 7	TxB	-	COMM
3, 8	TxA	-	24 V





## SOFTWARE/UNIT OPERATION

### MONICOVIEW 3.1 SOFTWARE

MonicoView 3.1 software is available as a no charge download from Monico's website. The latest version of the software is always available from the website, and updating your copy is free.

### FACTORY RESET BUTTON

The factory reset button is located on the front of the unit.

### ASSET GATEWAY TROUBLESHOOTING

If for any reason you have trouble operating, connecting, or simply have questions concerning your new Asset Gateway unit, contact Monico's technical support.

Email: [support@monicoinc.com](mailto:support@monicoinc.com)

Website: [www.monicoinc.com](http://www.monicoinc.com)

Phone: +1 (281) 350-8751

### BATTERY & TIME KEEPING



**WARNING - EXPLOSION HAZARD - DISCONNECT POWER AND ENSURE THE AREA IS KNOWN TO BE NON-HAZARDOUS BEFORE SERVICING/REPLACING THE UNIT AND BEFORE INSTALLING OR REMOVING I/O WIRING AND BATTERY.**


**AVERTISSEMENT - DANGER D'EXPLOSION - DÉBRANCHEZ L'ALIMENTATION ET ASSUREZ-VOUS QUE LA ZONE NE SOIT NON DANGEREUSE AVANT DE L'ENTRETIEN / REMPLACEMENT DE L'UNITÉ ET AVANT D'INSTALLER OU D'ENLEVER LE CÂBLAGE D'ENTRÉE/SORTIE ET LA BATTERIE.**

A battery is used to keep time when the unit is without power. Typical accuracy (at 25°C) of the time keeping is less than one minute per month drift. This battery does not affect the unit's memory, all configurations and data is stored in non-volatile memory.

### Changing the Battery

To change the battery, first remove power to the unit. Remove all cables from the unit and any external module if installed. Remove the four TORX screws holding the metal cover to the unit, two per side. Slide the metal cover forward to gain access to the battery. Remove the old battery\* from the holder and replace with the new battery. Replace metal cover with the four TORX screws. Reinstall external module if equipped, reconnect cables and re-apply power. Using MonicoView 3.1 software, enter the correct time and date.

Remove 4 Torx  
T10 screws



\* Please note that the old battery must be disposed of in a manner that complies with your local waste regulations. The battery must not be disposed of in fire, or in a manner whereby it may be damaged and its contents could come into contact with human skin.

The battery used by the Monico Asset Gateway is an industrial temperature grade (-40°C to 85°C) lithium type BR2032.

This page intentionally left blank.

## LIMITED WARRANTY

(a) Red Lion Controls Inc. and Monico Monitoring Inc. (the "Company") warrants that all Products shall be free from defects in material and workmanship under normal use for the period of time provided in "Statement of Warranty Periods" (available at [www.redlion.net](http://www.redlion.net)) current at the time of shipment of the Products (the "Warranty Period"). **EXCEPT FOR THE ABOVE-STATED WARRANTY, COMPANY MAKES NO WARRANTY WHATSOEVER WITH RESPECT TO THE PRODUCTS, INCLUDING ANY (A) WARRANTY OF MERCHANTABILITY; (B) WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE; OR (C) WARRANTY AGAINST INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS OF A THIRD PARTY; WHETHER EXPRESS OR IMPLIED BY LAW, COURSE OF DEALING, COURSE OF PERFORMANCE, USAGE OF TRADE OR OTHERWISE.** Customer shall be responsible for determining that a Product is suitable for Customer's use and that such use complies with any applicable local, state or federal law.

(b) The Company shall not be liable for a breach of the warranty set forth in paragraph (a) if (i) the defect is a result of Customer's failure to store, install, commission or maintain the Product according to specifications; (ii) Customer alters or repairs such Product without the prior written consent of Company.

(c) Subject to paragraph (b), with respect to any such Product during the Warranty Period, Company shall, in its sole discretion, either (i) repair or replace the Product; or (ii) credit or refund the price of Product provided that, if Company so requests, Customer shall, at Company's expense, return such Product to Company.

(d) **THE REMEDIES SET FORTH IN PARAGRAPH (c) SHALL BE THE CUSTOMER'S SOLE AND EXCLUSIVE REMEDY AND COMPANY'S ENTIRE LIABILITY FOR ANY BREACH OF THE LIMITED WARRANTY SET FORTH IN PARAGRAPH (a).**